

DISCLAIMER: These Standard Operating Procedures (SOP's) are for the exclusive use of Navy Public Works Center (PWC) Norfolk. They are promulgated as guidance for their NAVFAC Commands. If intended to be used by other activities, they must be tailored to each activity's particular requirements and must be reviewed/approved by the activity's safety professionals prior to use.

Standard Operating Procedure
Guy Wire Installation

Safety Equipment Required:

Gloves
Hard hat
Safety glasses
Safety shoes

Equipment required:

Cutting torch
Hand tools
Bucket truck

PROCEDURE

1. For boom/bucket truck operation follow SOP 621.2 STM 25
2. Bring wire to the site.
3. Measure amount of wire needed, cut wire from roll. Follow SOP 621.2 STM 27.
4. Remove old wire.
5. Install new wire.
6. Install turnbuckles, tighten wire.
7. Dispose of old wire properly. Coil wire, secure both ends to coil and place in metal dumpster.
8. Clean up the job site.