ILD SINGLE Key Unlocking Procedure

NOTE: Handle and key always rotate CCW to unlock.

1



Push key forward with the lever until detent is engaged.

2



Whether the handle is straight up or down, rotate 90° CCW until it stops.

3

Insert key and rotate 180° CCW.



4



Push and hold the handle in (A) and rotate 90° CCW (B) until it stops. The door is now unlocked.

ILD SINGLE Key Locking Procedure

NOTE: Handle and key always rotate CW to lock.

1



Push and hold the handle in (A) and rotate 90° CW (B) until it stops.

2

Rotate key 180° CW and remove.



3



Rotate handle 90° CW until it stops.

4



Push to release detent and retract key into key guide.

ILD Single Key
Operating Procedure

NAVFAC ESC
DoD Lock Program, Code CI661
1100 23rd Avenue
Port Hueneme, CA 93043-4370

Technical Support Hotline:
Toll Free: (800) 290-7607, Commercial: (805) 982-1212
DSN: 551-1212, FAX: (805) 982-1253
Website: https://portal.navfac.navy.mil/go/locks