

HUNTERS POINT ANNEX
TREASURE ISLAND NAVAL STATION
PCB VERIFICATION SAMPLING RESULTS

AREA 3

Prepared for Western Division Naval
Facilities, Engineering Command

August 1988

Prepared by
ERM-WEST

1777 Botelho Drive, Suite 260
Walnut Creek, California 94596-5022

(415) 946-0455

Underground Tank & Spill Contract
N62474-85-C-5627
Delivery Order # 0034 and # 0036

TABLE OF CONTENTS

	<u>Page</u>
PROJECT ORGANIZATION AND RESPONSIBILITY	1
VERIFICATION SAMPLING PROGRAM	2
Sample Layout Procedures	3
Sampling and Sample Tracking	4
August 5-8, 1988 Sampling	4
ANALYTICAL PROCEDURES	5
RESULTS	6
August 5-8, 1988 Results	6
Background and Blank Samples	6
CONCLUSIONS AND RECOMMENDATIONS	6
REFERENCES	8
APPENDIX A - Chain of Custody Records Laboratory Analytical Summaries	
APPENDIX B - Laboratory QA/QC Procedures	

LIST OF FIGURES

<u>Figure No.</u>		<u>Following Page</u>
3-1	PCB Site - Work Areas	2
3-2	Area 3 Verification Sampling Grid	3

LIST OF TABLES

<u>Table No.</u>		<u>Following Page</u>
3-1	Verification Soil Sampling Results for Area 3	8

HUNTERS POINT ANNEX
TREASURE ISLAND NAVAL STATION

AREA 3 - VERIFICATION SOIL SAMPLING SUMMARY
FOR CLEANUP OF PCB CONTAMINATED SOILS NEAR FORMER BUILDING 503

This report summarizes the Area 3 verification sampling results for the last phase of the interim cleanup of Poly-chlorinated Biphenyl (PCB) contaminated soils near former Building 503 at Hunters Point Annex. Area 1 and 2 verification sampling results for Phase I and Phase II of the interim cleanup were summarized in references 1, 2 and 3.

PROJECT ORGANIZATION AND RESPONSIBILITY

Four groups are directly involved in the cleanup of the site: the Navy, an excavation and disposal contractor, the sample verification consultant, and an analytical laboratory. The PCB cleanup project is directed by the Western Division Naval Facilities Engineering Command (WESTDIV), San Bruno, California. WESTDIV organizes, contracts, and coordinates the cleanup work using contractors and consultants; communicates with the regulatory agencies; inspects the site; and tracks work progress.

The cleanup contractor is American Environmental Management Corp., Oakland, California. The contractor is responsible for excavation and removal of soil from the PCB site, site containment, and health and safety of American Environmental personnel.

Sampling of the site is performed by ERM-WEST, Walnut Creek, California. ERM-WEST is responsible for sampling the site and reporting the PCB results to the Navy; setting-up the verification sampling grid; overseeing health and safety of ERM-West personnel; and reporting sampling results.

Central Coast Analytical Services, San Luis Obispo, California is the laboratory used to perform the PCB analytical procedures. Central Coast Analytical Services is a certified hazardous waste laboratory and the laboratory used during the Area 1 and Area 2 cleanup phases. (References 1, 2 and 3)

VERIFICATION SAMPLING PROGRAM

Contaminated soils in Area 3, as shown in Figure 3-1, were identified, excavated, and removed by American Environmental Management Corp. Contaminated soils were manifested and disposed at a Class 1 landfill.

The decision to verify the soil clean-up work in Area 3, through the development and preparation of a formal verification sampling plan, was based on field samples taken and analyzed by a McGraw Edison field PCB kit. The correlation between field sample results and certified laboratory reports has been confirmed and previously discussed and reported in both the Interim Report and addendum (Reference 1, 2 and 3). Experience and comparison of split samples analyzed concurrently by the field test kit and a certified analytical laboratory consistently indicated that the field kit was conservatively showing PCB concentrations higher than the certified laboratory. The field test kit was therefore used as a screening device to help direct field activities.




Figure 3-1
PCB Site-Work Areas



The following section summarizes the verification sampling program for Area 3. The agreed interim cleanup level for this site is 25 mg/kg of PCB. Detailed laboratory reports for the verification sample analysis are presented in Appendix A. The U.S. Environmental Protection Agency (USEPA) protocol was used to design the verification sampling program (Reference 4).

Sample Layout Procedures

The layout of the verification sampling program for Area 3 is shown on Figure 3-2. The location of sampling points was based on USEPA protocol for verification sampling (Reference 4, EPA manual on "Verification of PCB Spill Cleanup by Sampling and Analysis", Interim Report No. 2, August, 1985). Each point was spaced at 7.8 foot intervals. This spacing was based on a spill radius of 26.0 feet (longest length of Area 3 was 51 feet), a sample size of 37 (reference Table 4 of the above manual), and a sample spacing based on 0.3 times the radius of the spill area (Table 2 of above manual).

The number of sample grid points established in the field exceeded the 37 sample size referenced above. Additional grid points were identified on the outside periphery of the excavation to confirm that the extent of the surface PCB contamination had been accurately identified. The total number of grid points sampled and analyzed was 56.

As indicated on Figure 3-2, three of the sample points have been triangulated and located relative to the existing pumping station. These three points will allow re-establishment of the sampling grid at a future time, if necessary.



Notes :

1. Contours indicate approximate depth of excavation below existing ground surface.
2. Distance between adjacent points: 7.8 ft.

Distance (ft) to Pumping Station

Grid Point	NWCorner	SWCorner
3E-11	31.9	30.0
3D-18	39.3	20.5
3G-5	43.2	51.3

Approx. Scale
1 inch = 8 ft.



Figure 3-2

**Area 3
Verification
Sampling Grid**

ERM-West 7/88

400.58/ASC/7.14.88
REV. 7.20.88JPT

Sampling and Sample Tracking

The grid point locations based on aforementioned layout were sampled on August 5 and 8, 1988. To track samples from the field to the laboratory, chain of custody documentation was prepared and sealed with the field-to-laboratory transport container. Chain of custody forms prepared and used during the sampling program are presented in Appendix A.

August 5-8, 1988 Sampling. On August 5, 1988 the interior of the excavation was sampled. The ground water was pumped out from the excavation before sampling. At each grid point, a six ounce surface soil sample was taken with a wooden disposable tongue depressor and placed in a glass jar; depth of sample was approximately two centimeters. Depth of the excavation ranged from one foot to approximately eight feet below the existing grade. The Teflon-capped sample glass jars were iced prior to transporting to the laboratory.

On August 8, 1988 the periphery of the site, outside the excavation, was sampled using a hollow stem drill rig. The drill rig was used to break through the asphalt paving and to push a steel or brass tube for retrieval of undisturbed samples at depths varying between 1.33 and 3.0 feet. The depth of sample was previously confirmed with the DHS before drilling and follows the procedures established during the Area 1 and 2 sampling program. Samples inaccessible to the drill rig were hand augered. After sample retrieval, sample tubes were covered with Teflon and capped prior to icing and transporting to the laboratory.

ANALYTICAL PROCEDURES

Once the samples were received at the Central Coast Analytical Services laboratory the samples were prepared, extracted, and analyzed for PCBs. Sample preparation and extraction generally followed EPA method 3550 - Sonication Extraction. However, instead of a 1mm X 1mm sieve required by the EPA method, Central Coast used a #10 sieve (2mm X 2mm) to be consistent with sample preparation required by California Administrative Code, Title 22, Division 4, Chapter 30, Section 66700 (c) (1).

At the request of the DHS, the samples received at the laboratory were air dried before analysis for PCBs. This was done after determination of percent moisture in the original sample. Central Coast's detection limits were such that a 20 gram wet weight sample was used and mixed with Na_2SO_4 then sonicated. The extraction solvent was 1:1 hexane:acetone (B & J) chromatography grade. The extract sample was filtered and reduced in volume using a Kuderna-Danish concentrator.

PCBs, if present in the sample extract, were identified using EPA method 8080 - Organochlorine Pesticides and PCBs.

Central Coast's "Quality Assurance/Quality Control Procedure" as summarized in Appendix B, requires blanks, duplicates, and spikes to be analyzed once per batch, once per matrix type or once per 20 samples, whichever is more frequent. For this project, however, duplicates were run once per batch, once per matrix type or once per 10 samples analyzed, whichever was more frequent.

August 5-8, 1988 Results

RESULTS

Table 3-1 tabulates the samples analyzed by Central Coast Analytical Services for the August 5-8, 1988 sampling program. The established interim cleanup level for this site is 25 mg/kg of PCB. As indicated in Table 3-1, the samples taken on August 5-8, 1987 and analyzed by Central Coast Analytical Services are reported to be below the cleanup criteria of 25 ppm.

Background and Blank Samples

As part of the quality assurance program, a soil background (BL-1) and blank (BL-2) were collected previously during Area 2 verification sampling (reference 3).

Trace levels of PCBs were detected in both soil samples BL-1 and BL-2. Both the occurrences were a result of factors not directly influencing the verification sample data (reference 3). Compared to the PCB concentrations found in the actual verification samples, those found in samples BL-1 and BL-2 are not significant (refer Table 3-1).

CONCLUSIONS AND RECOMMENDATIONS

Analytical results from soil samples obtained on August 5 and 8, 1988 using EPA Verification Sampling Protocol indicate that the interim cleanup goal of 25 ppm or less has been achieved for Area 3. The Area 3 excavation should be backfilled with acceptable engineered fill and compacted sufficiently to prevent soil subsidence. The surface of the entire removal area should be covered with an impermeable barrier such as asphalt to prevent surface water infiltration and surface erosion.

The PCB removal area will be investigated in the Hunters Point Annex Remedial Investigation/Feasibility Study (RI/FS) to further characterize any remaining low-level PCB contamination at the site. Upon completion of the RI/FS, long-term remedial measures to protect the public health and environment will be implemented as appropriate.

References:

1. PCB Verification Sampling Results, Interim Report, ERM-West, April 1987.
2. Addendum to the "PCB Verification Sampling Results", Attachment to a letter from the U.S. Navy to the Department of Health Services, June 25, 1987.
3. PCB Verification Sampling Results, Area 2; ERM-West; December 1987.
4. Verification of PCB Spill Cleanup by Sampling and Analysis, USEPA, August 1985.
5. Quality Assurance Project Plan, Naval Station, Treasure Island, Hunters Point Annex; Harding - Lawson Associates; May, 1988.
6. Work Plan Volume 2B, Sampling Plan - Group II Sites, Naval Station, Treasure Island, Hunters Point Annex; Harding - Lawson Associates; May, 1988.
7. PCB Verification Sampling Plan for Area 3, ERM-West, July 1988.

TABLE 3-1

HUNTERS POINT ANNEX
TREASURE ISLAND NAVAL STATION

VERIFICATION SOIL SAMPLING RESULTS
FROM CENTRAL COAST ANALYTICAL SERVICES
FOR AREA 3

Sample Description	August 5-8, 1988		
	Percent Moisture	PCBs ¹ , D.L. ²	mg/kg Concentration ³
3A-9	7.8	1.0	<1.0
3A-11	7.4	1.0	<1.0
3A-13	22	1.0	<1.0
3B-6	4.4	1.0	<1.0
3B-8	13	1.0	4
3B10	22	1.0	9
3B12	13	1.0	<1.0
3B14	25	1.0	<1.0
3B16	8.0	1.0	<1.0
3B18	7.9	1.0	<1.0
3C-5	7.2	1.0	<1.0
3C-7	22	1.0	5
3C-9	20	1.0	<1.0
3C-11	20	1.0	<1.0
3C-13	22	1.0	6
3C-15	11	1.0	5
3C-17	6.7	1.0	<1.0
3C-19	30	1.0	<1.0
3D-4	6.5	1.0	<1.0
3D-6	19	1.0	2
3D-8	16	1.0	16
3D-10	14	1.0	14
3D-12	18	1.0	<1.0
3D-14	17	1.0	4
3D-16	12	1.0	<1.0
3D-18	11	1.0	<1.0
3E-5	12	1.0	<1.0
3E-7	32	1.0	15
3E-9	21	1.0	14
3E-11	17	1.0	<1.0
3E-13	23	1.0	3

TABLE 3-1 (continued)
VERIFICATION SOIL SAMPLING RESULTS
FOR AREA 3

Sample Description	August 5-8, 1988		
	Percent Moisture	PCBs ¹ , D.L. ²	mg/kg Concentration ³
3E-15	13	1.0	<1.0
3E-17	13	1.0	1.0
3F-4	8.0	1.0	<1.0
3F-6	20	1.0	7.0
3F-8	19	1.0	4.0
3F-10	14	1.0	2.0
3F-12	19	1.0	<1.0
3F-14	17	1.0	<1.0
3F-16	16	1.0	<1.0
3G-5	11	1.0	<1.0
3G-7	13	1.0	<1.0
3G-9	23	1.0	9.0
3G-11	18	1.0	2.0
3G-13	22	1.0	2.0
3G-15	5.3	1.0	<1.0
3H-6	7.1	1.0	<1.0
3H-8	17	1.0	<1.0
3H-10	15	1.0	<1.0
3H-12	9.0	1.0	1.0
3H-14	12	1.0	<1.0
3J-9	11	1.0	<1.0
3J-11	17	1.0	2.0
3J-13	19	1.0	<1.0
3K-10	8.9	1.0	<1.0
3K-12	8.4	1.0	18.0
BL-1 ⁴	--	0.02	0.17
BL-2 ⁴	0.15	0.02	0.15

Notes:

1. Only PCBs detected were Aroclor 1260.
2. D.L. is the detection limit
3. Conc. is the reported concentration of the PCB by the laboratory analysis.
4. PCB Verification Sampling Results, Area 2; ERM-West; 1987.

APPENDIX A

CHAIN OF CUSTODY RECORDS
LABORATORY ANALYTICAL SUMMARIES

ER West

1777 Botelho Drive • Suite 260 • Walnut Creek, CA • 94596 • (415) 946-0455

Chain of Custody Record

Job # 40058						Collection				GC				GC/MS		Inorg	Other	Remarks <div style="border: 1px solid black; padding: 5px; display: inline-block;">5-Day Turnaround</div> EPA Protocol					
Job Location HUNTER'S PT.						Container type	ICED	Preservative	Sampling method	TPH-Extraction	BTEX/Total Fuel HCs	601 / 8010 Halocarbons	602 / 8020 Aromatics	604 / 8040 Phenols	8080 Pest/PCBs	624-8240 Purgables	625-8270 BNAs & Pest (SVs)		Dioxins	Metals	Wet Chemistry	% moisture	Number of Containers
Sampler (signature) <i>ASC / Don Lapin</i>																							
Printed name ARUNCHEMBURKAR / Don Lapin																							
Lab Report Recipient																							
Telephone No.																							
Receiving Lab CENTRAL COAST ANA. SER.																							
Address 141 SUBURBAN ROAD, SUITE G-4																							
Address SAN LUIS OBISPO, CA 93401																							
Sample ID#	Time	W-water S-soil	C-comp G-grab	Volume																			
32-11	1124	S	G		glass jar	Y	N														1	PCB 8080	
34-10	1129																						% Moisture
36-9	1136																						
36-11	1142																						
36-13	1147																						
3F-14	1151																						
3F-12	1157																						
3F-10	1202																						
3F-8	1206																						
3F-6	1212																						
Precautions:						Conc: <input checked="" type="checkbox"/> Lo <input type="checkbox"/> Med <input type="checkbox"/> HI						Ship Via						Total Number of Containers: 10					
Sample Relinquished By		Date		Time		Received By		Date		Time		Reason for Transfer (List Shipping Bill Number)											
Anun		08/05																					
Company <i>ERM-W</i>						Company																	
Company						Company																	
LABORATORY— <input type="checkbox"/> Samples Intact <input type="checkbox"/> Samples at 4°C <input type="checkbox"/> Samples not leaking <input type="checkbox"/> # of containers matches C-of-C <input type="checkbox"/> Container tags match C-of-C <input type="checkbox"/> Cooler seals Intact Please Complete Lab sample custodian Signature _____ Date _____ Time _____ Sample Disposition <input type="checkbox"/> Return to Site <input type="checkbox"/> Discard <input type="checkbox"/> Hold _____ days																							

E Y-West

1777 Batetho Drive • Suite 260 • Walnut Creek, CA • 94596 • (415) 444-4555

Date 8.5.88 Weather C 54°F 65-70°F Page 2 of 3

Chain of Custody Record

Job # 40058					Collection			GC					GC/MS		Inorg	Other	Number of Containers	Remarks				
Job Location HUNTER'S PT.					Container type	ICED	Preservative	Sampling method	TPH-Extraction	BTEX/Total Fuel HCs	801/8010 Halocarbons	802/8020 Aromatics	804/8040 Phenols	808/8080 Pest/PCBs	624-8240 Purgeables	625-8270 BNAs & Pest (SVs)			Dioxins	Metals	Wet Chemistry	% Moisture
Sampler (signature) ASC / <i>Don Lapin</i>																						
Printed name ARUN CHEMBURKAR / DON LAPIN																						
Lab Report Recipient																						
Telephone No.																						
Receiving Lab CENTRAL COAST ANAL. SER.																						
Address 141 SUBURBAN ROAD, SUITE G-4																						
SAN LUIS OBISPO, CA 93401																						
Sample ID#	Time	Weather Seal	Comp Grab	Volume																	EPA Protocol	
3E-15	1217	S	G		Glass Jar	N		7560													PCB 8080	
3E-13	1221							7561													% Moisture	
3E-11	1223							7562														
3E-9	1228							7563														
3E-7	1231							7564														
3D-12	1238							7565														
3D-10	1241							7566														
3D-8	1246																					
3D-6	1251							7567														
3D-4 3C-7	1258							7568														
Precautions:					Conc: <input checked="" type="checkbox"/> Lo <input type="checkbox"/> Med <input type="checkbox"/> HI Ship Via										Total Number of Containers: 9							
Sample Relinquished By		Date		Time	Received By		Date		Time		Reason for Transfer (List Shipping Bill Number)											
Arun		08		05	Maria Hancock		8/7		1220		1234											
Company					Company																	
Company					Company																	
LABORATORY—																						
Please Complete		<input type="checkbox"/> Samples Intact		<input type="checkbox"/> Samples at 4°C		<input type="checkbox"/> Samples not leaking		<input type="checkbox"/> # of containers matches C-of-C		<input type="checkbox"/> Container tags match C-of-C		<input type="checkbox"/> Cooler seals Intact										
Lab sample custodian		Signature		Date		Time		Sample Disposition		<input type="checkbox"/> Return to Site		<input type="checkbox"/> Discard		<input type="checkbox"/> Hold _____ days								

7/24/88

AUG 12 '88 14:05 CENTRAL COAST ANALYT P02

West

1. doteltho Drive • Suite 260 • Walnut Creek, CA • 94596 • (415) 940-4555

Date 8/12/88 Weather Clear 65-70 F Page 2 of 2

Chain of Custody / Record

Job # 4-0058					Collection			GC				GC/MS		Inorg	Other	Remarks 5-Day Turn					
Job Location HUNTER'S PT.					Container type	ICED	Preservative	Sampling method	TPH-Extraction	BTEX/Total Fuel HCs	601/8010 Halocarbons	602/8020 Aromatics	604/8040 Phenols	605/8080 Pest/PCBs	621-8240 Purgeables		625-8270 BNAs & Pest (SVs)	Dioxins	Metals	Wet Chemistry	
Sampler (signature) ASC /																					
Printed name ARUNCHEMBURAR /																					
Lab Report Recipient																					
Telephone No.																					
Receiving Lab CENTRAL COAST ANAL. SER.																					
Address 141 SUBURBAN ROAD, SUITE G-4					Number of Containers																
SAN LUIS OBISPO, CA 93401																					
Sample ID#	Time	Weather Seal	Comp Grab	Volume	EPA Protocol																
3D-8	1302	S	G	6	✓	N	7569													1	PCB 8080
3C-9	1305				↓		7570													1	+ % Noise
3C-11	1309					7571														1	
3B-8	1316					7572														1	
3B-10	1318					7573														1	
3B-12	1321					7574														1	
3C-13	1328					7575														1	
3C-15	1332					7576														1	
3D-14	1337					7577														1	

Precautions:				Conc: <input checked="" type="checkbox"/> Lo <input type="checkbox"/> Med <input type="checkbox"/> HI				Ship Via				Total Number of Containers: 9			
Sample Relinquished By		Date	Time	Received By		Date	Time	Reason for Transfer (List Shipping Bill Number)							
Arun		08/05		Munir Houtch		8/8	1834								
Company				Company											
Company				Company											

LABORATORY—		<input type="checkbox"/> Samples Intact	<input type="checkbox"/> Samples at 4°C	<input type="checkbox"/> Samples not leaking	<input type="checkbox"/> # of containers matches C-of-C	<input type="checkbox"/> Container legs match C-of-C	<input type="checkbox"/> Cooler/Seals Intact		
Please Complete Lab sample custodian		Signature	Date	Time	Sample Disposition		<input type="checkbox"/> Return to Site	<input type="checkbox"/> Discard	<input type="checkbox"/> Hold _____ days

ERM-West

Botelho Drive • Suite 260 • Walnut Creek, CA • 94596 • (415) 46-0455

Date 8/8/88 Weather Cool, Windy, 14-24

Chain of Custody Record

Job # 40058					Collection			GC				GC/MS		Inorg	Other	Number of Containers	Remarks				
Job Location Hunters Pt. S.F.					Container type	ICED	Preservative	Sampling method 6" Hollow Stem Auger	TPH-Extraction	BTEX Total Fuel HCs	601 / 8010 Halocarbons	602 / 8020 Aromatics	604 / 8040 Phenols	606 / 8080 Pests/PCBs	624-8240 Pesticides			625-8270 BNAs & Pests (SVs)	Dioxins	Metals	Wet Chemistry
Sampler (signature) Arun Chemburkar + Cheryl Seath																					
Printed name ARUN CHEMBURKAR + CHERYL SEATH																					
Lab Report Recipient																					
Telephone No.																					
Receiving Lab CENTRAL COAST ANALYTICAL					5 DAY Turn Around!																
Address SUBURBAN BD. STE. C-4																					
SAN LUIS OBISPO, CA. 93401																					
Sample ID#	Time	W-water S-soil	C-comp G-grab	Volume																	
30-18 (1.5-2')	1038	S	G	1/2 lb.	2x6" Brass Tube	Y	N	CALIF. MOD.					X						1	PCB EPA	
30-19 (2-2.5')	1056												X						1	method 8080	
30-17 (2-2.5')	1113												X						1	and	
30-18 (2-2.5')	1129												X						1	1/2 Moisture	
30-16 (2-2.5')	1142												X						1		
30-14 (2-2.5')	1153												X						1		
3A-13 (2-2.5')	1205												X						1		
3A-11 (2-2.5')	1218												X						1		
3B-6 (2-2.5')	1228												X						1		
3A-9 (1.5-2')	1141												X						1		

Precautions:

Conc: ☒ Lo ☐ Med ☐ HI

Ship Via Bus

Total Number of Containers:

10

Sample Relinquished By	Date	Time	Received By	Date	Time	Reason for Transfer (List Shipping Bill Number)
Cheryl Seath	8/9/88	0914	John Moulton	8/9/88	1321	
Company ERM-West			Company			
Cheryl Seath (for Arun)	8/9/88	1900				
Company ERM-West			Company			

LABORATORY—

Please Complete
Lab sample custodian☐ Samples
Intact

Signature

☐ Samples
at 4°C☐ Samples
not leaking

Date

☐ # of containers
matches C-of-C

Time

Sample Disposition

☐ Container tags
match C-of-C☐ Return to Site☐ Cooler seals
Intact☐ Discard☐ Hold _____ days

7/29/88

AUG 17 '88 16:45 CENTRAL COAST ANALYT P02

ERM-West

1777 Botelho Drive • Suite 260 • Walnut Creek, CA • 94596 • (415) 946-0455

Chain of Custody Record

Job # 40058					Collection			GC				GC/MS		Inorg	Other	Remarks 5 DAY TURN AROUND!					
Job Location Hunters Pt. S.F.																					
Sampler (signature) <i>Cheryl E. Seath</i> & <i>Armen Chem. Barker</i>																					
Printed name Cheryl E. Seath & Armen Chem. Barker																					
Lab Report Recipient																					
Telephone No.																Number of Containers					
Receiving Lab Central Coast Analytical																					
Address 141 SUBURBAN RD. STE. L-4																					
SAN LUIS OBISPO, CA. 93401																					
Sample ID#	Time	W-water S-soil	C-comp G-grab	Volume	Container type	ICED	Preservative	Sampling method	TPH-Extraction	BTEX/Total Fuel HCs	601 / 8010 Halocarbons	602 / 8020 Aromatics	604 / 8040 Phenols	808 / 8080 Pest/PCBs	624-8240 Purgeables	625-8270 BNAs & Pest (SVs)	Dioxins	Metals	Wet Chemistry		
3C-5 (1.5-2')	1342	S	G	1.5 lb.	2x6" brass tubes	Y	N	CALIF. MODIFIED						X						1	TEST METALS
3D-4 (2-3')	1352													X						1	EPA 8080
3E-5 (2-2.5')	1406													X						1	FOR PCB'S
3F-4 (2-2.5')	1420													X						1	AND %
3G-5 (2.5-3')	1435													X						1	MOISTURE
3H-6 (2.5-3')	1451													X						1	
3H-8 (2-2.5')	1506													X						1	
3J-9 (2-2.5')	1520													X						1	
3K-10 (2.5-3')	1608													X						1	
3K-10 (2.5-3')	1620													X						1	

Precautions:

Conc: ☒ Lo ☐ Med ☐ HI

Ship Via **bus**

Total Number of Containers:

10

Sample Relinquished By	Date	Time	Received By	Date	Time	Reason for Transfer (List Shipping Bill Number)
------------------------	------	------	-------------	------	------	---

Cheryl E. Seath
Company

Armen Chem. Barker
Company

8/8/88 15:00

ERM-West

Cheryl Seath (for ASE)
Company

Company

8/8/88 8/9/88

ERM-West

LABORATORY—

Please Complete

Lab sample custodian

☐ Samples Intact

Signature

☐ Samples at 4°C

Date

☐ Samples not leaking

Time

☐ # of containers matches C-of-C

Sample Disposition

☐ Container bags match C-of-C

Return to Site

☐ Cooler seals intact

Discard

☐ Hold days

22 AUG 1988

AUG 17 '88 16:45 CENTRAL COAST ANALYT P03



1777 Botelho Drive • Suite 260 • Walnut Creek, CA • 94596 • (415) 946-0455

Chain of Custody Record

Job # 40058					Collection			GC				GC/MS		Inorg	Other	Remarks 5 DAY TURN AROUND TIME! EPA Protocol				
Job Location <i>Hunters Pt. B.F.</i>					Container type	ICED	Preservative	Sampling method	TPH-Extraction	BTEX/Total Fuel HCs	601 / 8010 Halocarbons	602 / 8020 Aromatics	604 / 8040 Phenols	606 / 8080 Pesticides/PCBs	624-8240 Purgeables		625-8270 BNA's & Pesticides (SVs)	Dioxins	Metals	Wet Chemistry
Sampler (signature) <i>Anna Chamberlain & Cheryl Seath</i>																				
Printed name <i>Anna Chamberlain & Cheryl Seath</i>																				
Lab Report Recipient																				
Telephone No.					Number of Containers															
Receiving Lab <i>Central Coast Analytical</i>																				
Address <i>41 SUBURBAN RD. STE C-4 SAN LUIS OBISPO, CA 93401</i>																				
Sample ID#	Time	W-water Seal	C-comp G-grab	Volume																
92 3K-12 (2.5-3') 1645	S	G	.5 lb.	3x6" Brass Tube	Y	N	6" Hollow Stem Auger						X						1	
93 3F-16 (2.0-2.5') 1657	S	G	"	"															1	
94 3E-17 (2-2.5') 1713	S	G	"	"									X						1	
95 3G-15 (1.5-2') 1605	S	G	.25 lb.	1x6" Brass Tube	Y	N	Hand Auger						X						1	
96 3H-12 (1.5-2') 1625													X						1	
97 3J-13 (1.5-2') 1640													X						1	
98 3H-14 (1.5-2') 1702													X						1	
99 3D-16 (1.5-2') 1715													X						1	

Precautions: Conc: ☒ Lo ☐ Med ☐ Hi Ship Via _____ Total Number of Containers: **8**

Sample Relinquished By	Date	Time	Received By	Date	Time	Reason for Transfer (List Shipping Bill Number)
<i>Cheryl Seath</i> Company <i>ERM-West</i>	<i>8/9/88</i>	<i>0914</i>	<i>Tim Threlkeld</i> Company	<i>8/11/88</i>	<i>1521</i>	
<i>Cheryl Seath (for Anna)</i> Company <i>ERM-West</i>	<i>8/8/88</i>	<i>1900</i>				

LABORATORY—
Please Complete

☐ Samples Intact
☐ Samples at 4°C
☐ Samples not leaking
☐ # of containers matches C-of-C
☐ Container legs match C-of-C
☐ Cooler seals intact

Lab sample custodian Signature _____ Date _____ Time _____
 Sample Disposition ☐ Return to Site ☐ Discard ☐ Hold _____ days

AUG 17 '88 16:46 CENTRAL COAST ANALYT P04

AUG 15 '88 10:46 CENTRAL COAST ANALYT

P02

AIR, WATER and HAZARDOUS WASTE LABORATORY CERTIFIED by CALIFORNIA DEPT of HEALTH SERVICES

Central
Coast
Analytical
Services

Central Coast
Analytical Services
141 Suburban Road, Suite C-4
San Luis Obispo, California 93401
(805) 543-2553
EPA METHOD 808/8080 - PCB'S

Lab Number: E-7550
Collected: 08/05/88
Received: 08/07/88
Tested: 08/09/88
Collected by: A. Chemburkar

ERM-WEST
1777 Botelho Dr.
Walnut Creek, CA 94596


SAMPLE DESCRIPTION:
3J-11, Soil

Compound Analyzed	Detection Limit milligrams/Kg	Concentration milligrams/Kg
PCB 1016	1.	not found
PCB 1221	1.	not found
PCB 1232	1.	not found
PCB 1242	1.	not found
PCB 1248	1.	not found
PCB 1254	1.	not found
PCB 1260	1.	2.

Compounds listed as "not found" would have been reported if present at or above the listed detection limits. Sample was extracted 08/08/88.

Percent Moisture: 17%. Tested by EPA Method 160.3 on 08/08/88 by ACF.

Respectfully submitted,


Mary Havlicek, Ph.D.
President

MSD #5
E7550pc.wr1/34
MH/jc/sc/sc

Central
Coast
Analytical
Services

Central Coast
Analytical Services
141 Suburban Road, Suite C-4
San Luis Obispo, California 93401
(805) 543-2553
EPA METHOD 608/8080 - PCB'S

Lab Number: E-7551
Collected: 08/05/88
Received: 08/07/88
Tested: 08/09/88
Collected by: A. Chemburkar

ERM-WEST
1777 Botelho Dr.
Walnut Creek, CA 94596


SAMPLE DESCRIPTION:
3H-10, Soil

Compound Analyzed	Detection Limit milligrams/Kg	Concentration milligrams/Kg
PCB 1016	1.	not found
PCB 1221	1.	not found
PCB 1232	1.	not found
PCB 1242	1.	not found
PCB 1248	1.	not found
PCB 1254	1.	not found
PCB 1260	1.	not found

Compounds listed as "not found" would have been reported if present at or above the listed detection limits. Sample was extracted 08/08/88.

Percent Moisture: 15%. Tested by EPA Method 160.3 on 08/08/88 by ACF.

Respectfully submitted,



Mary Havlicek, Ph.D.
President

MSD #5
E7551pc.wr1/35
MH/bl/sc/sc

Central
Coast
Analytical
Services

Central Coast
Analytical Services
141 Suburban Road, Suite C-4
San Luis Obispo, California 93401
(805) 543-2553
EPA METHOD 608/8080 - PCB'S

Lab Number: E-7552
Collected: 08/05/88
Received: 08/07/88
Tested: 08/09/88
Collected by: A. Chemburkar

ERM-WEST
1777 Botelho Dr.
Walnut Creek, CA 94596

SAMPLE DESCRIPTION:
3G-9, Soil

Compound Analyzed	Detection Limit milligrams/Kg	Concentration milligrams/Kg
PCB 1016	1.	not found
PCB 1221	1.	not found
PCB 1232	1.	not found
PCB 1242	1.	not found
PCB 1248	1.	not found
PCB 1254	1.	not found
PCB 1260	1.	9.

Compounds listed as "not found" would have been reported if present at or above the listed detection limits. Sample was extracted 08/08/88.

Percent Moisture: 23%. Tested by EPA Method 160.3 on 08/08/88 by ACF.

Respectfully submitted,



Mary Havlicek, Ph.D.
President

MSD #5
E7552pc.wr1/35
MH/bl/gh/gh

Central
Coast
Analytical
Services

Central Coast
Analytical Services
141 Suburban Road, Suite C-4
San Luis Obispo, California 93401
(805) 543-2553
EPA METHOD 608/8080 - PCB'S

Lab Number: E-7553
Collected: 08/05/88
Received: 08/07/88
Tested: 08/09/88
Collected by: A. Chemburkar

ERM-WEST
1777 Botelho Dr.
Walnut Creek, CA 94596

SAMPLE DESCRIPTION:
3G-11, Soil

Compound Analyzed	Detection Limit milligrams/Kg	Concentration milligrams/Kg
PCB 1016	1.	not found
PCB 1221	1.	not found
PCB 1232	1.	not found
PCB 1242	1.	not found
PCB 1248	1.	not found
PCB 1254	1.	not found
PCB 1260	1.	2.

Compounds listed as "not found" would have been reported if present at or above the listed detection limits. Sample was extracted 08/08/88.

Percent Moisture: 18%. Tested by EPA Method 160.3 on 08/08/88 by ACF.

Respectfully submitted,



Mary Havlicek, Ph.D.
President

MSD #5
E7553pc.wr1/34
MH/jc/sc/sc

Central
Coast
Analytical
Services

Central Coast
Analytical Services
141 Suburban Road, Suite C-4
San Luis Obispo, California 93401
(805) 543-2553
EPA METHOD 608/8080 - PCB'S

Lab Number: E-7554
Collected: 08/05/88
Received: 08/07/88
Tested: 08/09/88
Collected by: A. Chemburkar

ERM-WEST
1777 Botelho Dr.
Walnut Creek, CA 94596

SAMPLE DESCRIPTION:
3G-13, Soil

Compound Analyzed	Detection Limit milligrams/Kg	Concentration milligrams/Kg
PCB 1016	1.	not found
PCB 1221	1.	not found
PCB 1232	1.	not found
PCB 1242	1.	not found
PCB 1248	1.	not found
PCB 1254	1.	not found
PCB 1260	1.	2.

Compounds listed as "not found" would have been reported if present at or above the listed detection limits. Sample was extracted 08/08/88.

Percent Moisture: 22%. Tested by EPA Method 160.3 on 08/08/88 by ACF.

Respectfully submitted,

Mary Havlicek
Mary Havlicek, Ph.D.
President

MSD #5
E7554pc.wr1/34
MH/jc/sc/sc

Central
Coast
Analytical
Services

Central Coast
Analytical Services
141 Suburban Road, Suite C-4
San Luis Obispo, California 93401
(805) 543-2553
EPA METHOD 608/8080 - PCB'S

Lab Number: E-7555
Collected: 08/05/88
Received: 08/07/88
Tested: 08/09/88
Collected by: A. Chemburkar

ERM-WEST
1777 Botelho Dr.
Walnut Creek, CA 94596


SAMPLE DESCRIPTION:
3F-14, Soil

Compound Analyzed	Detection Limit milligrams/Kg	Concentration milligrams/Kg
PCB 1016	1.	not found
PCB 1221	1.	not found
PCB 1232	1.	not found
PCB 1242	1.	not found
PCB 1248	1.	not found
PCB 1254	1.	not found
PCB 1260	1.	not found

Compounds listed as "not found" would have been reported if present
at or above the listed detection limits. Sample was extracted 08/08/88.

Percent Moisture: 17%. Tested by EPA Method 160.3 on 08/08/88 by ACF.

Respectfully submitted,



Mary Havlicek, Ph.D.
President

MSD #5
E7555pc.wr1/35
MH/bl/sc/sc

Central
Coast
Analytical
Services

Central Coast
Analytical Services
141 Suburban Road , Suite C-4
San Luis Obispo, California 93401
(805) 543-2553
EPA METHOD 608/8080 - PCB'S

Lab Number: E-7556
Collected: 08/05/88
Received: 08/07/88
Tested: 08/09/88
Collected by: A. Chemburkar

ERM-WEST
1777 Botelho Dr.
Walnut Creek, CA 94596

SAMPLE DESCRIPTION:
3F-12, Soil

Compound Analyzed	Detection Limit milligrams/Kg	Concentration milligrams/Kg
PCB 1016	1.	not found
PCB 1221	1.	not found
PCB 1232	1.	not found
PCB 1242	1.	not found
PCB 1248	1.	not found
PCB 1254	1.	not found
PCB 1260	1.	not found

Compounds listed as "not found" would have been reported if present at or above the listed detection limits. Sample was extracted 08/08/88.

Percent Moisture: 19%. Tested by EPA Method 160.3 on 08/08/88 by ACF.

Respectfully submitted,

Mary Havlicek

Mary Havlicek, Ph.D.
President

MSD #5
E7556pc.wr1/35
MH/bl/sc/sc

Central
Coast
Analytical
Services

Central Coast
Analytical Services
141 Suburban Road, Suite C-4
San Luis Obispo, California 93401
(805) 543-2553
EPA METHOD 608/8080 - PCB'S

Lab Number: E-7557
Collected: 08/05/88
Received: 08/07/88
Tested: 08/09/88
Collected by: A. Chemburkar

ERM-WEST
1777 Botelho Dr.
Walnut Creek, CA 94596


SAMPLE DESCRIPTION:
3F-10, Soil

Compound Analyzed	Detection Limit milligrams/Kg	Concentration milligrams/Kg
PCB 1016	1.	not found
PCB 1221	1.	not found
PCB 1232	1.	not found
PCB 1242	1.	not found
PCB 1248	1.	not found
PCB 1254	1.	not found
PCB 1260	1.	2.

Compounds listed as "not found" would have been reported if present at or above the listed detection limits. Sample was extracted 08/08/88.

Percent Moisture: 14%. Tested by EPA Method 160.3 on 08/08/88 by ACF.

Respectfully submitted,



Mary Havlicek, Ph.D.
President

MSD #5
E7557pc.wr1/34
MH/jc/sc/sc

Central
Coast
Analytical
Services

Central Coast
Analytical Services
141 Suburban Road , Suite C-4
San Luis Obispo, California 93401
(805) 543-2553
EPA METHOD 608/8080 - PCB'S

Lab Number: E-7558
Collected: 08/05/88
Received: 08/07/88
Tested: 08/09/88
Collected by: A. Chemburkar

ERM-WEST
1777 Botelho Dr.
Walnut Creek, CA 94596

SAMPLE DESCRIPTION:
3F-8, Soil

Compound Analyzed	Detection Limit milligrams/Kg	Concentration milligrams/Kg
PCB 1016	1.	not found
PCB 1221	1.	not found
PCB 1232	1.	not found
PCB 1242	1.	not found
PCB 1248	1.	not found
PCB 1254	1.	not found
PCB 1260	1.	4.

Compounds listed as "not found" would have been reported if present at or above the listed detection limits. Sample was extracted 08/08/88.

Percent Moisture: 19%. Tested by EPA Method 160.3 on 08/08/88 by ACF.

Respectfully submitted,

Mary Havlicek
Mary Havlicek, Ph.D.
President

MSD #5
E7558pc.wr1/34
MH/jc/sc/sc

Central
Coast
Analytical
Services

Central Coast
Analytical Services
141 Suburban Road , Suite C-4
San Luis Obispo, California 93401
(805) 543-2553
EPA METHOD 608/8080 - PCB'S

Lab Number: E-7559
Collected: 08/05/88
Received: 08/07/88
Tested: 08/09/88
Collected by: A. Chemburkar

ERM-WEST
1777 Botelho Dr.
Walnut Creek, CA 94596

SAMPLE DESCRIPTION:
3F-6, Soil

Compound Analyzed	Detection Limit milligrams/Kg	Concentration milligrams/Kg
PCB 1016	1.	not found
PCB 1221	1.	not found
PCB 1232	1.	not found
PCB 1242	1.	not found
PCB 1248	1.	not found
PCB 1254	1.	not found
PCB 1260	1.	7.

Compounds listed as "not found" would have been reported if present at or above the listed detection limits. Sample was extracted 08/08/88.

Percent Moisture: 20%. Tested by EPA Method 160.3 on 08/08/88 by ACF.

Respectfully submitted,

Mary Havlicek
Mary Havlicek, Ph.D.
President

MSD #5
E7559pc.wr1/35
MH/bl/sc/sc

AUG 15 '88 10:47 CENTRAL COAST ANALYT P03

AIR, WATER and HAZARDOUS WASTE LABORATORY CERTIFIED by CALIFORNIA DEPT of HEALTH SERVICES

Central
Coast
Analytical
Services

Central Coast
Analytical Services
141 Suburban Road, Suite C-4
San Luis Obispo, California 93401
(805) 543-2553
EPA METHOD 608/8080 - PCB'S

Lab Number: E-7560
Collected: 08/05/88
Received: 08/07/88
Tested: 08/09/88
Collected by: A. Chemburkar

ERM-WEST
1777 Botelho Dr.
Walnut Creek, CA 94596

SAMPLE DESCRIPTION:
3E-15, Soil

Compound Analyzed	Detection Limit milligrams/Kg	Concentration milligrams/Kg
PCB 1016	1.	not found
PCB 1221	1.	not found
PCB 1232	1.	not found
PCB 1242	1.	not found
PCB 1248	1.	not found
PCB 1254	1.	not found
PCB 1260	1.	not found

Compounds listed as "not found" would have been reported if present
at or above the listed detection limits. Sample was extracted 08/08/88.

Percent Moisture: 13%. Tested by EPA Method 160.3 on 08/08/88 by ACF.

Respectfully submitted,

Mary Havlicek

Mary Havlicek, Ph.D.
President

MSD #5
E7560pc.wr1/35
RM/b1/sc/sc

Central
Coast
Analytical
Services

Central Coast
Analytical Services
141 Suburban Road , Suite C-4
San Luis Obispo, California 93401
(805) 543-2553
EPA METHOD 608/8080 - PCB'S

Lab Number: E-7561
Collected: 08/05/88
Received: 08/07/88
Tested: 08/11/88
Collected by: A. Chemburkar

ERM-WEST
1777 Botelho Dr.
Walnut Creek, CA 94596


SAMPLE DESCRIPTION:
3E-13, Soil

Compound Analyzed	Detection Limit milligrams/Kg	Concentration milligrams/Kg
PCB 1016	1.	not found
PCB 1221	1.	not found
PCB 1232	1.	not found
PCB 1242	1.	not found
PCB 1248	1.	not found
PCB 1254	1.	not found
PCB 1260	1.	3.

Compounds listed as "not found" would have been reported if present
at or above the listed detection limits. Sample was extracted 08/08/88.

Percent Moisture: 23%. Tested by EPA Method 160.3 on 08/08/88 by ACF.

Respectfully submitted,



Mary Havlicek, Ph.D.
President

MSD #5
E7561pc.wr1/35
MH/bl/sc/sc

Central
Coast
Analytical
Services

Central Coast
Analytical Services
141 Suburban Road, Suite C-4
San Luis Obispo, California 93401
(805) 543-2553
EPA METHOD 608/8080 - PCB'S

Lab Number: E-7562
Collected: 08/05/88
Received: 08/07/88
Tested: 08/09/88
Collected by: A. Chemburkar

ERM-WEST
1777 Botelho Dr.
Walnut Creek, CA 94596


SAMPLE DESCRIPTION:
3E-11, Soil

Compound Analyzed	Detection Limit milligrams/Kg	Concentration milligrams/Kg
PCB 1016	1.	not found
PCB 1221	1.	not found
PCB 1232	1.	not found
PCB 1242	1.	not found
PCB 1248	1.	not found
PCB 1254	1.	not found
PCB 1260	1.	not found

Compounds listed as "not found" would have been reported if present
at or above the listed detection limits. Sample was extracted 08/08/88.

Percent Moisture: 17%. Tested by EPA Method 160.3 on 08/08/88 by ACF.

Respectfully submitted,


Mary Havlicek, Ph.D.
President

MSD #5
E7562pc.wr1/35
MH/bl/sc/sc

Central
Coast
Analytical
Services

Central Coast
Analytical Services
141 Suburban Road, Suite C-4
San Luis Obispo, California 93401
(805) 543-2553
EPA METHOD 608/8080 - PCB'S

Lab Number: E-7563
Collected: 08/05/88
Received: 08/07/88
Tested: 08/11/88
Collected by: A. Chemburkar

ERM-WEST
1777 Botelho Dr.
Walnut Creek, CA 94596


SAMPLE DESCRIPTION:
3E-9, Soil

Compound Analyzed	Detection Limit milligrams/Kg	Concentration milligrams/Kg
PCB 1016	1.	not found
PCB 1221	1.	not found
PCB 1232	1.	not found
PCB 1242	1.	not found
PCB 1248	1.	not found
PCB 1254	1.	not found
PCB 1260	1.	14.

Compounds listed as "not found" would have been reported if present at or above the listed detection limits. Sample was extracted 08/08/88.

Percent Moisture: 21%. Tested by EPA Method 160.3 on 08/08/88 by ACF.

Respectfully submitted,


Mary Havlicek, Ph.D.
President

MSD #5
E7563pc2.wr1/35
MH/bl/sc/sc

Central
Coast
Analytical
Services

Central Coast
Analytical Services
141 Suburban Road , Suite C-4
San Luis Obispo, California 93401
(805) 543-2553
EPA METHOD 608/8080 - PCB'S

Lab Number: E-7564
Collected: 08/05/88
Received: 08/07/88
Tested: 08/11/88
Collected by: A. Chemburkar

ERM-WEST
1777 Botelho Dr.
Walnut Creek, CA 94596


SAMPLE DESCRIPTION:
3E-7, Soil

Compound Analyzed	Detection Limit milligrams/Kg	Concentration milligrams/Kg
PCB 1016	1.	not found
PCB 1221	1.	not found
PCB 1232	1.	not found
PCB 1242	1.	not found
PCB 1248	1.	not found
PCB 1254	1.	not found
PCB 1260	1.	15.

Compounds listed as "not found" would have been reported if present at or above the listed detection limits. Sample was extracted 08/08/88.

Percent Moisture: 32%. Tested by EPA Method 160.3 on 08/08/88 by ACF.

Respectfully submitted,


Mary Havlicek, Ph.D.
President

MSD #5
E7564pc.wr1/35
MH/bl/sc/sc

Central
Coast
Analytical
Services

Central Coast
Analytical Services
141 Suburban Road , Suite C-4
San Luis Obispo, California 93401
(805) 543-2553
EPA METHOD 608/8080 - PCB'S

Lab Number: E-7565
Collected: 08/05/88
Received: 08/07/88
Tested: 08/09/88
Collected by: A. Chemburkar

ERM-WEST
1777 Botelho Dr.
Walnut Creek, CA 94596


SAMPLE DESCRIPTION:
3D-12, Soil

Compound Analyzed	Detection Limit milligrams/Kg	Concentration milligrams/Kg
PCB 1016	1.	not found
PCB 1221	1.	not found
PCB 1232	1.	not found
PCB 1242	1.	not found
PCB 1248	1.	not found
PCB 1254	1.	not found
PCB 1260	1.	not found

Compounds listed as "not found" would have been reported if present
at or above the listed detection limits. Sample was extracted 08/08/88.

Percent Moisture: 18%. Tested by EPA Method 160.3 on 08/08/88 by ACF.

Respectfully submitted,


Mary Havlicek, Ph.D.
President

MSD #5
E7565pc.wr1/35
MH/bl/sc/sc

Central
Coast
Analytical
Services

Central Coast
Analytical Services
141 Suburban Road , Suite C-4
San Luis Obispo, California 93401
(805) 543-2553
EPA METHOD 608/8080 - PCB'S

Lab Number: E-7566
Collected: 08/05/88
Received: 08/07/88
Tested: 08/11/88
Collected by: A. Chemburkar

ERM-WEST
1777 Botelho Dr.
Walnut Creek, CA 94596


SAMPLE DESCRIPTION:
3D-10, Soil

Compound Analyzed	Detection Limit milligrams/Kg	Concentration milligrams/Kg
PCB 1016	1.	not found
PCB 1221	1.	not found
PCB 1232	1.	not found
PCB 1242	1.	not found
PCB 1248	1.	not found
PCB 1254	1.	not found
PCB 1260	1.	14.

Compounds listed as "not found" would have been reported if present
at or above the listed detection limits. Sample was extracted 08/08/88.

Percent Moisture: 14%. Tested by EPA Method 160.3 on 08/08/88 by ACF.

Respectfully submitted,


Mary Havlicek, Ph.D.
President

MSD #5
E7566pc.wr1/35
MH/bl/sc/sc

Central
Coast
Analytical
Services

Central Coast
Analytical Services
141 Suburban Road , Suite C-4
San Luis Obispo, California 93401
(805) 543-2553
EPA METHOD 608/8080 - PCB'S

Lab Number: E-7567
Collected: 08/05/88
Received: 08/07/88
Tested: 08/09/88
Collected by: A. Chemburkar

ERM-WEST
1777 Botelho Dr.
Walnut Creek, CA 94596


SAMPLE DESCRIPTION:
3D-6, Soil

Compound Analyzed	Detection Limit milligrams/Kg	Concentration milligrams/Kg
PCB 1016	1.	not found
PCB 1221	1.	not found
PCB 1232	1.	not found
PCB 1242	1.	not found
PCB 1248	1.	not found
PCB 1254	1.	not found
PCB 1260	1.	2.

Compounds listed as "not found" would have been reported if present
at or above the listed detection limits. Sample was extracted 08/08/88.

Percent Moisture: 19%. Tested by EPA Method 160.3 on 08/08/88 by ACF.

Respectfully submitted,



Mary Havlicek, Ph.D.
President

MSD #5
E7567pc.wr1/35
MH/bl/sc/sc

Central
Coast
Analytical
Services

Central Coast
Analytical Services
141 Suburban Road , Suite C-4
San Luis Obispo, California 93401
(805) 543-2553
EPA METHOD 608/8080 - PCB'S

Lab Number: E-7568
Collected: 08/05/88
Received: 08/07/88
Tested: 08/11/88
Collected by: A. Chemburkar

ERM-WEST
1777 Botelho Dr.
Walnut Creek, CA 94596


SAMPLE DESCRIPTION:
3C-7, Soil

Compound Analyzed	Detection Limit milligrams/Kg	Concentration milligrams/Kg
PCB 1016	1.	not found
PCB 1221	1.	not found
PCB 1234	1.	not found
PCB 1242	1.	not found
PCB 1248	1.	not found
PCB 1254	1.	not found
PCB 1260	1.	5.

Compounds listed as "not found" would have been reported if present at or above the listed detection limits. Sample was extracted 08/08/88.

Percent Moisture: 22%. Tested by EPA Method 160.3 on 08/08/88 by ACF.

Respectfully submitted,



Mary Havlicek, Ph.D.
President

MSD #5
E7568pc.wr1/35
MH/bl/sc/sc

Central
Coast
Analytical
Services

Central Coast
Analytical Services
141 Suburban Road, Suite C-4
San Luis Obispo, California 93401
(805) 543-2553
EPA METHOD 608/8080 - PCB'S

Lab Number: E-7569
Collected: 08/05/88
Received: 08/07/88
Tested: 08/09/88
Collected by: A. Chemburkar

ERM-WEST
1777 Botelho Dr.
Walnut Creek, CA 94596

SAMPLE DESCRIPTION:
3D-8, Soil

Compound Analyzed	Detection Limit milligrams/Kg	Concentration milligrams/Kg
PCB 1016	1.	not found
PCB 1221	1.	not found
PCB 1232	1.	not found
PCB 1242	1.	not found
PCB 1248	1.	not found
PCB 1254	1.	not found
PCB 1260	1.	not found

Compounds listed as "not found" would have been reported if present
at or above the listed detection limits. Sample was extracted 08/08/88.

Percent Moisture: 16%. Tested by EPA Method 160.3 on 08/08/88 by ACF.

Respectfully submitted,

Mary Havlicek
Mary Havlicek, Ph.D.
President

MSD #5
E7569pc.wr1/35
MH/bl/sc/jl

Central
Coast
Analytical
Services

Central Coast
Analytical Services
141 Suburban Road, Suite C-4
San Luis Obispo, California 93401
(805) 543-2553
EPA METHOD 608/8080 - PCB'S

Lab Number: E-7570
Collected: 08/05/88
Received: 08/07/88
Tested: 08/09/88
Collected by: A. Chemburkar

ERM-WEST
1777 Botelho Dr.
Walnut Creek, CA 94596


SAMPLE DESCRIPTION:
3C-9, Soil

Compound Analyzed	Detection Limit milligrams/Kg	Concentration milligrams/Kg
PCB 1016	1.	not found
PCB 1221	1.	not found
PCB 1232	1.	not found
PCB 1242	1.	not found
PCB 1248	1.	not found
PCB 1254	1.	not found
PCB 1260	1.	not found

Compounds listed as "not found" would have been reported if present
at or above the listed detection limits. Sample was extracted 08/08/88.

Percent Moisture: 20%. Tested by EPA Method 160.3 on 08/08/88 by ACF.

Respectfully submitted,


Mary Havlicek, Ph.D.
President

MSD #5
E7570pc.wr1/35
MH/bl/sc/jl

Central
Coast
Analytical
Services

Central Coast
Analytical Services
141 Suburban Road , Suite C-4
San Luis Obispo, California 93401
(805) 543-2553
EPA METHOD 608/8080 - PCB'S

Lab Number: E-7571
Collected: 08/05/88
Received: 08/07/88
Tested: 08/09/88
Collected by: A. Chemburkar

ERM-WEST
1777 Botelho Dr.
Walnut Creek, CA 94596


SAMPLE DESCRIPTION:
3C-11, Soil

Compound Analyzed	Detection Limit milligrams/Kg	Concentration milligrams/Kg
PCB 1016	1.	not found
PCB 1221	1.	not found
PCB 1232	1.	not found
PCB 1242	1.	not found
PCB 1248	1.	not found
PCB 1254	1.	not found
PCB 1260	1.	not found

Compounds listed as "not found" would have been reported if present
at or above the listed detection limits. Sample was extracted 08/08/88.

Percent Moisture: 20%. Tested by EPA Method 160.3 on 08/08/88 by ACF.

Respectfully submitted,


Mary Havlicek, Ph.D.
President

MSD #5
E7571pc.wr1/35
MH/bl/sc/jl

Central
Coast
Analytical
Services

Central Coast
Analytical Services
141 Suburban Road , Suite C-4
San Luis Obispo, California 93401
(805) 543-2553
EPA METHOD 608/8080 - PCB'S

Lab Number: E-7572
Collected: 08/05/88
Received: 08/07/88
Tested: 08/09/88
Collected by: A. Chemburkar

ERM-WEST
1777 Botelho Dr.
Walnut Creek, CA 94596


SAMPLE DESCRIPTION:
38-8, Soil

Compound Analyzed	Detection Limit milligrams/Kg	Concentration milligrams/Kg
PCB 1016	1.	not found
PCB 1221	1.	not found
PCB 1232	1.	not found
PCB 1242	1.	not found
PCB 1248	1.	not found
PCB 1254	1.	not found
PCB 1260	1.	4.

Compounds listed as "not found" would have been reported if present at or above the listed detection limits. Sample was extracted 08/08/88.

Percent Moisture: 13%. Tested by EPA Method 160.3 on 08/08/88 by ACF.

Respectfully submitted,



Mary Havlicek, Ph.D.
President

MSD #5
E7572pc.wr1/35
MH/bl/sc/jl

Central
Coast
Analytical
Services

Central Coast
Analytical Services
141 Suburban Road , Suite C-4
San Luis Obispo, California 93401
(805) 543-2553
EPA METHOD 608/8080 - PCB'S

Lab Number: E-7573
Collected: 08/05/88
Received: 08/07/88
Tested: 08/09/88
Collected by: A. Chemburkar

ERM-WEST
1777 Botelho Dr.
Walnut Creek, CA 94596


SAMPLE DESCRIPTION:
3B-10, Soil

Compound Analyzed	Detection Limit milligrams/Kg	Concentration milligrams/Kg
PCB 1016	1.	not found
PCB 1221	1.	not found
PCB 1232	1.	not found
PCB 1242	1.	not found
PCB 1248	1.	not found
PCB 1254	1.	not found
PCB 1260	1.	9.

Compounds listed as "not found" would have been reported if present at or above the listed detection limits. Sample was extracted 08/08/88.

Percent Moisture: 22%. Tested by EPA Method 160.3 on 08/08/88 by ACF.

Respectfully submitted,


Mary Havlicek, Ph.D.
President

MSD #5
E7573pc.wr1/35
MH/bl/sc/sc

R, WATER and HAZARDOUS WASTE LABORATORY CERTIFIED by CALIFORNIA DEPT of HEALTH SERVICES

Central
Coast
Analytical
Services

Central Coast
Analytical Services
141 Suburban Road , Suite C-4
San Luis Obispo, California 93401
(805) 543-2553
EPA METHOD 608/8080 - PCB'S

Lab Number: E-7574
Collected: 08/05/88
Received: 08/07/88
Tested: 08/09/88
Collected by: A. Chemburkar

ERM-WEST
1777 Botelho Dr.
Walnut Creek, CA 94596


SAMPLE DESCRIPTION:
3B-12, Soil

Compound Analyzed	Detection Limit milligrams/Kg	Concentration milligrams/Kg
PCB 1016	1.	not found
PCB 1221	1.	not found
PCB 1232	1.	not found
PCB 1242	1.	not found
PCB 1248	1.	not found
PCB 1254	1.	not found
PCB 1260	1.	not found

Compounds listed as "not found" would have been reported if present
at or above the listed detection limits. Sample was extracted 08/08/88.

Percent Moisture: 13%. Tested by EPA Method 160.3 on 08/08/88 by ACF.

Respectfully submitted,



Mary Havlicek, Ph.D.
President

Central
Coast
Analytical
Services

Central Coast
Analytical Services
141 Suburban Road, Suite C-4
San Luis Obispo, California 93401
(805) 543-2553
EPA METHOD 608/8080 - PCB'S

Lab Number: E-7575
Collected: 08/05/88
Received: 08/07/88
Tested: 08/09/88
Collected by: A. Chemburkar

ERM-WEST
1777 Botelho Dr.
Walnut Creek, CA 94596


SAMPLE DESCRIPTION:
3C-13, Soil

Compound Analyzed	Detection Limit milligrams/Kg	Concentration milligrams/Kg
PCB 1016	1.	not found
PCB 1221	1.	not found
PCB 1232	1.	not found
PCB 1242	1.	not found
PCB 1248	1.	not found
PCB 1254	1.	not found
PCB 1260	1.	6.

Compounds listed as "not found" would have been reported if present
at or above the listed detection limits. Sample was extracted 08/08/88.

Percent Moisture: 22%. Tested by EPA Method 160.3 on 08/08/88 by ACF.

Respectfully submitted,


Mary Havlicek, Ph.D.
President

MSD #5
E7575pc.wr1/35
MH/bl/sc/sc

Central
Coast
Analytical
Services

Central Coast
Analytical Services
141 Suburban Road, Suite C-4
San Luis Obispo, California 93401
(805) 543-2553
EPA METHOD 608/8080 - PCB'S

Lab Number: E-7576
Collected: 08/05/88
Received: 08/07/88
Tested: 08/09/88
Collected by: A. Chemburkar

ERM-WEST
1777 Botelho Dr.
Walnut Creek, CA 94596


SAMPLE DESCRIPTION:
3C-15, Soil

Compound Analyzed	Detection Limit milligrams/Kg	Concentration milligrams/Kg
PCB 1016	1.	not found
PCB 1221	1.	not found
PCB 1232	1.	not found
PCB 1242	1.	not found
PCB 1248	1.	not found
PCB 1254	1.	not found
PCB 1260	1.	5.

Compounds listed as "not found" would have been reported if present
at or above the listed detection limits. Sample was extracted 08/08/88.

Percent Moisture: 11%. Tested by EPA Method 160.3 on 08/08/88 by ACF.

Respectfully submitted,



Mary Havlicek, Ph.D.
President

MSD #5
E7576pc.wr1/35
MH/bl/sc/sc

Central
Coast
Analytical
Services

Central Coast
Analytical Services
141 Suburban Road , Suite C-4
San Luis Obispo, California 93401
(805) 543-2553
EPA METHOD 608/8080 - PCB'S

Lab Number: E-7577
Collected: 08/05/88
Received: 08/07/88
Tested: 08/09/88
Collected by: A. Chemburkar

ERM-WEST
1777 Botelho Dr.
Walnut Creek, CA 94596


SAMPLE DESCRIPTION:
3D-14, Soil

Compound Analyzed	Detection Limit milligrams/Kg	Concentration milligrams/Kg
PCB 1016	1.	not found
PCB 1221	1.	not found
PCB 1232	1.	not found
PCB 1242	1.	not found
PCB 1248	1.	not found
PCB 1254	1.	not found
PCB 1260	1.	4.

Compounds listed as "not found" would have been reported if present at or above the listed detection limits. Sample was extracted 08/08/88.

Percent Moisture: 17%. Tested by EPA Method 160.3 on 08/08/88 by ACF.

Respectfully submitted,



Mary Havlicek, Ph.D.
President

MSD #5
E7577pc.wr1/35
MH/bl/sc/sc

Central
Coast
Analytical
Services

Central Coast
Analytical Services
141 Suburban Road , Suite C-4
San Luis Obispo, California 93401
(805) 543-2553
EPA METHOD 608/8080 - PCB'S

Lab Number: E-7678
Collected: 08/08/88 @ 1205
Received: 08/09/88
Tested: 08/11/88
Collected by: CS/AC

ERM-WEST
1777 Botelho Dr.
Walnut Creek, CA 94596


SAMPLE DESCRIPTION:
3A-13 (2.0 to 2.5 Feet), Soil Grab

Compound Analyzed	Detection Limit milligrams/Kg	Concentration milligrams/Kg
PCB 1016	1.	not found
PCB 1221	1.	not found
PCB 1232	1.	not found
PCB 1242	1.	not found
PCB 1248	1.	not found
PCB 1254	1.	not found
PCB 1260	1.	not found

Compounds listed as "not found" would have been reported if present
at or above the listed detection limits. Sample was extracted 08/10/88.

Percent Moisture: 22%. Tested by EPA method 160.3 on 08/15/88 by PD.

Respectfully submitted,



Mary Havlicek, Ph.D.
President

MSD #5
E7678pc.wr1/35
MH/b1/sc/sc

Central
Coast
Analytical
Services

Central Coast
Analytical Services
141 Suburban Road , Suite C-4
San Luis Obispo, California 93401
(805) 543-2553
EPA METHOD 608/8080 - PCB'S

Lab Number: E-7679
Collected: 08/08/88 @ 1218
Received: 08/09/88
Tested: 08/11/88
Collected by: CS/AC

ERM-WEST
1777 Botelho Dr.
Walnut Creek, CA 94596


SAMPLE DESCRIPTION:
3A-11 (2.0 to 2.5 Feet), Soil Grab

Compound Analyzed	Detection Limit milligrams/Kg	Concentration milligrams/Kg
PCB 1016	1.	not found
PCB 1221	1.	not found
PCB 1232	1.	not found
PCB 1242	1.	not found
PCB 1248	1.	not found
PCB 1254	1.	not found
PCB 1260	1.	not found

Compounds listed as "not found" would have been reported if present
at or above the listed detection limits. Sample was extracted 08/10/88.

Percent Moisture: 7.4%. Tested by EPA method 160.3 on 08/15/88 by PD.

Respectfully submitted,



Mary Havlicek, Ph.D.
President

MSD #5
E7679pc.wr1/36
MH/bl/sc/sc

Central
Coast
Analytical
Services

Central Coast
Analytical Services
141 Suburban Road, Suite C-4
San Luis Obispo, California 93401
(805) 543-2553
EPA METHOD 608/8080 - PCB'S

Lab Number: E-7680
Collected: 08/08/88 @ 1228
Received: 08/09/88
Tested: 08/11/88
Collected by: CS/AC

ERM-WEST
1777 Botelho Dr.
Walnut Creek, CA 94596

SAMPLE DESCRIPTION:
3B-6 (2.0 to 2.5 Feet), Soil Grab

Compound Analyzed	Detection Limit milligrams/Kg	Concentration milligrams/Kg
PCB 1016	1.	not found
PCB 1221	1.	not found
PCB 1232	1.	not found
PCB 1242	1.	not found
PCB 1248	1.	not found
PCB 1254	1.	not found
PCB 1260	1.	not found

Compounds listed as "not found" would have been reported if present
at or above the listed detection limits. Sample was extracted 08/10/88.

Percent Moisture: 4.4%. Tested by EPA method 160.3 on 08/15/88 by PD.

Respectfully submitted,

Mary Havlicek

Mary Havlicek, Ph.D.
President

MSD #5
E7680pc.wr1/35
MH/bl/sc/sc

Central
Coast
Analytical
Services

Central Coast
Analytical Services
141 Suburban Road, Suite C-4
San Luis Obispo, California 93401
(805) 543-2553
EPA METHOD 608/8080 - PCB'S

Lab Number: E-7681
Collected: 08/08/88 @ 1141
Received: 08/09/88
Tested: 08/11/88
Collected by: CS/AC

ERM-WEST
1777 Botelho Dr.
Walnut Creek, CA 94596

SAMPLE DESCRIPTION:
3A-9 (1.5 to 2.0 Feet), Soil Grab

Compound Analyzed	Detection Limit milligrams/Kg	Concentration milligrams/Kg
PCB 1016	1.	not found
PCB 1221	1.	not found
PCB 1232	1.	not found
PCB 1242	1.	not found
PCB 1248	1.	not found
PCB 1254	1.	not found
PCB 1260	1.	not found

Compounds listed as "not found" would have been reported if present
at or above the listed detection limits. Sample was extracted 08/10/88.

Percent Moisture: 7.8%. Tested by EPA method 160.3 on 08/15/88 by PD.

Respectfully submitted,

Mary Havlicek
Mary Havlicek, Ph.D.
President

MSD #5
E7681pc.wr1/35
MH/bl/jl/sc

Central
Coast
Analytical
Services

Central Coast
Analytical Services
141 Suburban Road, Suite C-4
San Luis Obispo, California 93401
(805) 543-2553
EPA METHOD 608/8080 - PCB'S

Lab Number: E-7683
Collected: 08/08/88 @ 1352
Received: 08/09/88 @ 1800
Tested: 08/11/88
Collected by: CS/AC

ERM-WEST
1777 Botelho Dr.
Suite 260
Walnut Creek, CA 94596

SAMPLE DESCRIPTION:
Job #40058, Hunter's Point S.F.,
3D-4 (2.5 to 3.0 Feet), Soil

Compound Analyzed	Detection Limit milligrams/Kg	Concentration milligrams/Kg
PCB 1016	1.	not found
PCB 1221	1.	not found
PCB 1232	1.	not found
PCB 1242	1.	not found
PCB 1248	1.	not found
PCB 1254	1.	not found
PCB 1260	1.	not found

Compounds listed as "not found" would have been reported if present at or above the listed detection limits. Sample was extracted 08/10/88.

Percent Moisture: 6.5%. Tested by EPA method 160.3 on 08/15/88 by PD.

Respectfully submitted,

Mary Havlicek
Mary Havlicek, Ph.D.
President

ECD
E7683pc.wr1/36
MH/bl/sc/sc

Central
Coast
Analytical
Services

Central Coast
Analytical Services
141 Suburban Road, Suite C-4
San Luis Obispo, California 93401
(805) 543-2553
EPA METHOD 608/8080 - PCB'S

Lab Number: E-7684
Collected: 08/08/88 @ 1406
Received: 08/09/88 @ 1800
Tested: 08/11/88
Collected by: CS/AC

ERM-WEST
1777 Botelho Dr.
Suite 260
Walnut Creek, CA 94596

SAMPLE DESCRIPTION:
Job #40058, Hunter's Point S.F.,
3E-5 (2.0 to 2.5 Feet), Soil

Compound Analyzed	Detection Limit milligrams/Kg	Concentration milligrams/Kg
PCB 1016	1.	not found
PCB 1221	1.	not found
PCB 1232	1.	not found
PCB 1242	1.	not found
PCB 1248	1.	not found
PCB 1254	1.	not found
PCB 1260	1.	not found

Compounds listed as "not found" would have been reported if present at or above the listed detection limits. Sample was extracted 08/10/88.

Percent Moisture: 12%. Tested by EPA method 160.3 on 08/15/88 by PD.

Respectfully submitted,

Mary Havlicek

Mary Havlicek, Ph.D.
President

ECD
E7684pc.wr1/36
MH/bl/sc/sc

Central
Coast
Analytical
Services

Central Coast
Analytical Services
141 Suburban Road, Suite C-4
San Luis Obispo, California 93401
(805) 543-2553
EPA METHOD 608/8080 - PCB'S

Lab Number: E-7685
Collected: 08/08/88 @ 1420
Received: 08/09/88 @ 1800
Tested: 08/11/88
Collected by: CS/AC

ERM-WEST
1777 Botelho Dr.
Suite 260
Walnut Creek, CA 94596


SAMPLE DESCRIPTION:
Job #40058, Hunter's Point S.F.,
3F-4 (2.0 to 2.5 Feet), Soil

Compound Analyzed	Detection Limit milligrams/Kg	Concentration milligrams/Kg
PCB 1016	1.	not found
PCB 1221	1.	not found
PCB 1232	1.	not found
PCB 1242	1.	not found
PCB 1248	1.	not found
PCB 1254	1.	not found
PCB 1260	1.	not found

Compounds listed as "not found" would have been reported if present
at or above the listed detection limits. Sample was extracted 08/10/88.

Percent Moisture: 8.0%. Tested by EPA method 160.3 on 08/15/88 by PD.

Respectfully submitted,



Mary Havlicek, Ph.D.
President

ECO
E7685pc.wr1/36
MH/jg/sc/sc

Central
Coast
Analytical
Services

Central Coast
Analytical Services
141 Suburban Road, Suite C-4
San Luis Obispo, California 93401
(805) 543-2553
EPA METHOD 608/8080 - PCB'S

Lab Number: E-7686
Collected: 08/08/88 @ 1435
Received: 08/09/88 @ 1800
Tested: 08/11/88
Collected by: CS/AC

ERM-WEST
1777 Botelho Dr.
Suite 260
Walnut Creek, CA 94596

SAMPLE DESCRIPTION:
Job #40058, Hunter's Point S.F.,
3G-5 (2.5 to 3.0 Feet), Soil

Compound Analyzed	Detection Limit milligrams/Kg	Concentration milligrams/Kg
PCB 1016	1.	not found
PCB 1221	1.	not found
PCB 1232	1.	not found
PCB 1242	1.	not found
PCB 1248	1.	not found
PCB 1254	1.	not found
PCB 1260	1.	not found

Compounds listed as "not found" would have been reported if present at or above the listed detection limits. Sample was extracted 08/10/88.

Percent Moisture: 11%. Tested by EPA method 160.3 on 08/15/88 by PD.

Respectfully submitted,

Mary Havlicek
Mary Havlicek, Ph.D.
President

ECD
E7686pc.wr1/36
MH/jg/sc/sc

Central
Coast
Analytical
Services

Central Coast
Analytical Services
141 Suburban Road, Suite C-4
San Luis Obispo, California 93401
(805) 543-2553
EPA METHOD 608/8080 - PCB'S

Lab Number: E-7687
Collected: 08/08/88 @ 1451
Received: 08/09/88 @ 1800
Tested: 08/11/88
Collected by: CS/AC

ERM-WEST
1777 Botelho Dr.
Suite 260
Walnut Creek, CA 94596

SAMPLE DESCRIPTION:
Job #40058, Hunter's Point S.F.,
3G-7 (2.5 to 3.0 Feet), Soil

Compound Analyzed	Detection Limit milligrams/Kg	Concentration milligrams/Kg
PCB 1016	1.	not found
PCB 1221	1.	not found
PCB 1232	1.	not found
PCB 1242	1.	not found
PCB 1248	1.	not found
PCB 1254	1.	not found
PCB 1260	1.	not found

Compounds listed as "not found" would have been reported if present
at or above the listed detection limits. Sample was extracted 08/10/88.

Percent Moisture: 13%. Tested by EPA method 160.3 on 08/15/88 by PD.

Respectfully submitted,

Mary Havlicek
Mary Havlicek, Ph.D.
President

ECD
E7687pc.wr1/36
MH/jg/sc/sc

Central
Coast
Analytical
Services

Central Coast
Analytical Services
141 Suburban Road, Suite C-4
San Luis Obispo, California 93401
(805) 543-2553
EPA METHOD 608/8080 - PCB'S

Lab Number: E-7688
Collected: 08/08/88 @ 1506
Received: 08/09/88 @ 1800
Tested: 08/11/88
Collected by: CS/AC

ERM-WEST
1777 Botelho Dr.
Suite 260
Walnut Creek, CA 94596

SAMPLE DESCRIPTION:
Job #40058, Hunter's Point S.F.,
3H-6 (2.0 to 2.5 Feet), Soil

Compound Analyzed	Detection Limit milligrams/Kg	Concentration milligrams/Kg
PCB 1016	1.	not found
PCB 1221	1.	not found
PCB 1232	1.	not found
PCB 1242	1.	not found
PCB 1248	1.	not found
PCB 1254	1.	not found
PCB 1260	1.	not found

Compounds listed as "not found" would have been reported if present
at or above the listed detection limits. Sample was extracted 08/10/88.

Percent Moisture: 7.1%. Tested by EPA method 160.3 on 08/15/88 by PD.

Respectfully submitted,

Mary Havlicek

Mary Havlicek, Ph.D.
President

ECO
E7688pc.wr1/36
MH/jc/sc/sc

Central
Coast
Analytical
Services

Central Coast
Analytical Services
141 Suburban Road, Suite C-4
San Luis Obispo, California 93401
(805) 543-2553
EPA METHOD 608/8080 - PCB'S

Lab Number: E-7689
Collected: 08/08/88 @ 1520
Received: 08/09/88 @ 1800
Tested: 08/11/88
Collected by: CS/AC

ERM-WEST
1777 Botelho Dr.
Suite 260
Walnut Creek, CA 94596

SAMPLE DESCRIPTION:
Job #40058, Hunter's Point S.F.,
3H-8 (2.0 to 2.5 Feet), Soil

Compound Analyzed	Detection Limit milligrams/Kg	Concentration milligrams/Kg
PCB 1016	1.	not found
PCB 1221	1.	not found
PCB 1232	1.	not found
PCB 1242	1.	not found
PCB 1248	1.	not found
PCB 1254	1.	not found
PCB 1260	1.	not found

Compounds listed as "not found" would have been reported if present
at or above the listed detection limits. Sample was extracted 08/10/88.

Percent Moisture: 17%. Tested by EPA method 160.3 on 08/15/88 by PD.

Respectfully submitted,

Mary Havlicek

Mary Havlicek, Ph.D.
President

ECD
E7689pc.wr1/36
MH/jc/sc/sc

Central
Coast
Analytical
Services

Central Coast
Analytical Services
141 Suburban Road, Suite C-4
San Luis Obispo, California 93401
(805) 543-2553
EPA METHOD 608/8080 - PCB'S

Lab Number: E-7690
Collected: 08/08/88 @ 1600
Received: 08/09/88 @ 1800
Tested: 08/11/88
Collected by: CS/AC

ERM-WEST
1777 Botelho Dr.
Suite 260
Walnut Creek, CA 94596

SAMPLE DESCRIPTION:
Job #40058, Hunter's Point S.F.,
3J-9 (2.5 to 3.0 Feet), Soil

Compound Analyzed	Detection Limit milligrams/Kg	Concentration milligrams/Kg
PCB 1016	1.	not found
PCB 1221	1.	not found
PCB 1232	1.	not found
PCB 1242	1.	not found
PCB 1248	1.	not found
PCB 1254	1.	not found
PCB 1260	1.	not found

Compounds listed as "not found" would have been reported if present
at or above the listed detection limits. Sample was extracted 08/10/88.

Percent Moisture: 11%. Tested by EPA method 160.3 on 08/15/88 by PD.

Respectfully submitted,



Mary Havlicek, Ph.D.
President

ECD
E7690pc.wr1/36
MH/jc/sc/sc

Central
Coast
Analytical
Services

Central Coast
Analytical Services
141 Suburban Road, Suite C-4
San Luis Obispo, California 93401
(805) 543-2553
EPA METHOD 608/8080 - PCB'S

Lab Number: E-7691
Collected: 08/08/88 @ 1620
Received: 08/09/88 @ 1800
Tested: 08/11/88
Collected by: CS/AC

ERM-WEST
1777 Botelho Dr.
Suite 260
Walnut Creek, CA 94596

SAMPLE DESCRIPTION:
Job #40058, Hunter's Point S.F.,
3K-10 (2.5 to 3.0 Feet), Soil

Compound Analyzed	Detection Limit milligrams/Kg	Concentration milligrams/Kg
PCB 1016	1.	not found
PCB 1221	1.	not found
PCB 1232	1.	not found
PCB 1242	1.	not found
PCB 1248	1.	not found
PCB 1254	1.	not found
PCB 1260	1.	not found

Compounds listed as "not found" would have been reported if present
at or above the listed detection limits. Sample was extracted 08/10/88.

Percent Moisture: 8.9%. Tested by EPA method 160.3 on 08/15/88 by PD.

Respectfully submitted,

Mary Havlicek
Mary Havlicek, Ph.D.
President

ECD
E7691pc.wr1/36
MH/jc/sc/sc

Central
Coast
Analytical
Services

Central Coast
Analytical Services
141 Suburban Road, Suite C-4
San Luis Obispo, California 93401
(805) 543-2553
EPA METHOD 608/8080 - PCB'S

Lab Number: E-7692
Collected: 08/08/88 @ 1645
Received: 08/09/88 @ 1800
Tested: 08/11/88
Collected by: CS/AC

ERM-WEST
1777 Botelho Dr.
Suite 260
Walnut Creek, CA 94596

SAMPLE DESCRIPTION:
Job #40058, Hunter's Point S.F.,
3K-12 (2.5 to 3.0 Feet), Soil

Compound Analyzed	Detection Limit milligrams/Kg	Concentration milligrams/Kg
PCB 1016	1.	not found
PCB 1221	1.	not found
PCB 1232	1.	not found
PCB 1242	1.	not found
PCB 1248	1.	not found
PCB 1254	1.	not found
PCB 1260	1.	18.

Compounds listed as "not found" would have been reported if present
at or above the listed detection limits. Sample was extracted 08/10/88.

Percent Moisture: 8.4%. Tested by EPA method 160.3 on 08/15/88 by PD.

Respectfully submitted,

Mary Havlicek

Mary Havlicek, Ph.D.
President

ECD
E7692pc.wr1/36
MH/jc/sc/sc

Central
Coast
Analytical
Services

Central Coast
Analytical Services
141 Suburban Road, Suite C-4
San Luis Obispo, California 93401
(805) 543-2553
EPA METHOD 608/8080 - PCB'S

Lab Number: E-7693
Collected: 08/08/88 @ 1657
Received: 08/09/88 @ 1800
Tested: 08/11/88
Collected by: CS/AC

ERM-WEST
1777 Botelho Dr.
Suite 260
Walnut Creek, CA 94596


SAMPLE DESCRIPTION:
Job #40058, Hunter's Point S.F.,
3F-16 (2.0 to 2.5 Feet), Soil

Compound Analyzed	Detection Limit milligrams/Kg	Concentration milligrams/Kg
PCB 1016	1.	not found
PCB 1221	1.	not found
PCB 1232	1.	not found
PCB 1242	1.	not found
PCB 1248	1.	not found
PCB 1254	1.	not found
PCB 1260	1.	not found

Compounds listed as "not found" would have been reported if present
at or above the listed detection limits. Sample was extracted 08/10/88.

Percent Moisture: 16%. Tested by EPA method 160.3 on 08/15/88 by PD.

Respectfully submitted,



Mary Havlicek, Ph.D.
President

ECD
E7693pc.wr1/36
MH/bl/sc/sc

Central
Coast
Analytical
Services

Central Coast
Analytical Services
141 Suburban Road, Suite C-4
San Luis Obispo, California 93401
(805) 543-2553
EPA METHOD 608/8080 - PCB'S

Lab Number: E-7694
Collected: 08/08/88 @ 1713
Received: 08/09/88 @ 1800
Tested: 08/11/88
Collected by: CS/AC

ERM-WEST
1777 Botelho Dr.
Suite 260
Walnut Creek, CA 94596

SAMPLE DESCRIPTION:
Job #40058, Hunter's Point S.F.,
3E-17 (2.0 to 2.5 Feet), Soil

Compound Analyzed	Detection Limit milligrams/Kg	Concentration milligrams/Kg
PCB 1016	1.	not found
PCB 1221	1.	not found
PCB 1232	1.	not found
PCB 1242	1.	not found
PCB 1248	1.	not found
PCB 1254	1.	not found
PCB 1260	1.	1.

Compounds listed as "not found" would have been reported if present at or above the listed detection limits. Sample was extracted 08/10/88.

Percent Moisture: 13%. Tested by EPA method 160.3 on 08/15/88 by PD.

Respectfully submitted,



Mary Havlicek, Ph.D.
President

ECD
E7694pc.wr1/36
MH/bl/sc/sc

Central
Coast
Analytical
Services

Central Coast
Analytical Services
141 Suburban Road, Suite C-4
San Luis Obispo, California 93401
(805) 543-2553
EPA METHOD 608/8080 - PCB'S

Lab Number: E-7695
Collected: 08/08/88 @ 1605
Received: 08/09/88 @ 1800
Tested: 08/12/88
Collected by: CS/AC

ERM-WEST
1777 Botelho Dr.
Walnut Creek, CA 94596


SAMPLE DESCRIPTION:
Job #40058, Hunter's Point S.F.,
3G-15 (1.5 to 2.0 Feet), Soil

Compound Analyzed	Detection Limit milligrams/Kg	Concentration milligrams/Kg
PCB 1016	1.	not found
PCB 1221	1.	not found
PCB 1232	1.	not found
PCB 1242	1.	not found
PCB 1248	1.	not found
PCB 1254	1.	not found
PCB 1260	1.	not found

Compounds listed as "not found" would have been reported if present
at or above the listed detection limits. Sample was extracted 08/10/88.

Percent Moisture: 5.3%. Tested by EPA method 160.3 on 08/15/88 by PD.

Respectfully submitted,


Mary Havlicek, Ph.D.
President

MSD #5
E7695pc.wr1/36
MH/bl/sc/sc

Central
Coast
Analytical
Services

Central Coast
Analytical Services
141 Suburban Road, Suite C-4
San Luis Obispo, California 93401
(805) 543-2553
EPA METHOD 608/8080 - PCB'S

Lab Number: E-7696
Collected: 08/08/88 @ 1625
Received: 08/09/88 @ 1800
Tested: 08/12/88
Collected by: CS/AC

ERM-WEST
1777 Botelho Dr.
Walnut Creek, CA 94596

SAMPLE DESCRIPTION:
Job #40058, Hunter's Point S.F.,
3H-12 (1.5 to 2.0 Feet), Soil

Compound Analyzed	Detection Limit milligrams/Kg	Concentration milligrams/Kg
PCB 1016	1.	not found
PCB 1221	1.	not found
PCB 1232	1.	not found
PCB 1242	1.	not found
PCB 1248	1.	not found
PCB 1254	1.	not found
PCB 1260	1.	not found

Compounds listed as "not found" would have been reported if present
at or above the listed detection limits. Sample was extracted 08/10/88.

Percent Moisture: 9.0%. Tested by EPA method 160.3 on 08/15/88 by PD.

Respectfully submitted,

Mary Havlicek

Mary Havlicek, Ph.D.
President

MSD #5
E7696pc.wr1/36
MH/bl/sc/sc

Central
Coast
Analytical
Services

Central Coast
Analytical Services
141 Suburban Road , Suite C-4
San Luis Obispo, California 93401
(805) 543-2553
EPA METHOD 608/8080 - PCB'S

Lab Number: E-7697
Collected: 08/08/88 @ 1640
Received: 08/09/88 @ 1800
Tested: 08/12/88
Collected by: CS/AC

ERM-WEST
1777 Botelho Dr.
Walnut Creek, CA 94596


SAMPLE DESCRIPTION:
Job #40058, Hunter's Point S.F.,
3J-13 (1.5 to 2.0 Feet), Soil

Compound Analyzed	Detection Limit milligrams/Kg	Concentration milligrams/Kg
PCB 1016	1.	not found
PCB 1221	1.	not found
PCB 1232	1.	not found
PCB 1242	1.	not found
PCB 1248	1.	not found
PCB 1254	1.	not found
PCB 1260	1.	not found

Compounds listed as "not found" would have been reported if present
at or above the listed detection limits. Sample was extracted 08/10/88.

Percent Moisture: 19%. Tested by EPA method 160.3 on 08/15/88 by PD.

Respectfully submitted,



Mary Havlicek, Ph.D.
President

MSD #5
E7697pc.wr1/36
MH/bl/sc/sc

Central
Coast
Analytical
Services

Central Coast
Analytical Services
141 Suburban Road, Suite C-4
San Luis Obispo, California 93401
(805) 543-2553
EPA METHOD 608/8080 - PCB'S

Lab Number: E-7698
Collected: 08/08/88 @ 1702
Received: 08/09/88 @ 1800
Tested: 08/12/88
Collected by: CS/AC

ERM-WEST
1777 Botelho Dr.
Walnut Creek, CA 94596

SAMPLE DESCRIPTION:
Job #40058, Hunter's Point S.F.,
3H-14 (1.5 to 2.0 Feet), Soil

Compound Analyzed	Detection Limit milligrams/Kg	Concentration milligrams/Kg
PCB 1016	1.	not found
PCB 1221	1.	not found
PCB 1232	1.	not found
PCB 1242	1.	not found
PCB 1248	1.	not found
PCB 1254	1.	not found
PCB 1260	1.	1.

Compounds listed as "not found" would have been reported if present at or above the listed detection limits. Sample was extracted 08/10/88.

Percent Moisture: 12%. Tested by EPA method 160.3 on 08/15/88 by PD.

Respectfully submitted,

Mary Havlicek
Mary Havlicek, Ph.D.
President

MSD #5
E7698pc.wr1/36
MH/bl/sc/sc

Central
Coast
Analytical
Services

Central Coast
Analytical Services
141 Suburban Road, Suite C-4
San Luis Obispo, California 93401
(805) 543-2553
EPA METHOD 608/8080 - PCB'S

Lab Number: E-7699
Collected: 08/08/88 @ 1715
Received: 08/09/88 @ 1800
Tested: 08/12/88
Collected by: CS/AC

ERM-WEST
1777 Botelho Dr.
Walnut Creek, CA 94596


SAMPLE DESCRIPTION:
Job #40058, Hunter's Point S.F.,
3D-16 (1.5 to 2.0 Feet), Soil

Compound Analyzed	Detection Limit milligrams/Kg	Concentration milligrams/Kg
PCB 1016	1.	not found
PCB 1221	1.	not found
PCB 1232	1.	not found
PCB 1242	1.	not found
PCB 1248	1.	not found
PCB 1254	1.	not found
PCB 1260	1.	not found

Compounds listed as "not found" would have been reported if present
at or above the listed detection limits. Sample was extracted 08/10/88.

Percent Moisture: 12%. Tested by EPA method 160.3 on 08/15/88 by PD.

Respectfully submitted,


Mary Havlicek, Ph.D.
President

MSD #5
E7699pc.wr1/36
MH/bl/sc/sc

Central
Coast
Analytical
Services

Central Coast
Analytical Services
141 Suburban Road, Suite C-4
San Luis Obispo, California 93401
(805) 543-2553
EPA METHOD 608/8080 - PCB'S

Lab Number: E-7672
Collected: 08/08/88 @ 1038
Received: 08/09/88
Tested: 08/11/88
Collected by: CS/AC

ERM-WEST
1777 Botelho Dr.
Walnut Creek, CA 94596

SAMPLE DESCRIPTION:
3D-18 (1.5 to 2.0 Feet), Soil Grab

Compound Analyzed	Detection Limit milligrams/Kg	Concentration milligrams/Kg
PCB 1016	1.	not found
PCB 1221	1.	not found
PCB 1232	1.	not found
PCB 1242	1.	not found
PCB 1248	1.	not found
PCB 1254	1.	not found
PCB 1260	1.	not found

Compounds listed as "not found" would have been reported if present
at or above the listed detection limits. Sample was extracted 08/09/88.

Percent Moisture: 11%. Tested by EPA method 160.3 on 08/15/88 by PD.

Respectfully submitted,

Mary Havlicek
Mary Havlicek, Ph.D.
President

MSD #5
E7672pc.wr1/35
MH/bl/sc/sc

Central
Coast
Analytical
Services

Central Coast
Analytical Services
141 Suburban Road, Suite C-4
San Luis Obispo, California 93401
(805) 543-2553
EPA METHOD 608/8080 - PCB'S

Lab Number: E-7673
Collected: 08/08/88 @ 1056
Received: 08/09/88
Tested: 08/11/88
Collected by: CS/AC

ERM-WEST
1777 Botelho Dr.
Walnut Creek, CA 94596

SAMPLE DESCRIPTION:
3C-19 (2.0 to 2.5 Feet), Soil Grab

Compound Analyzed	Detection Limit milligrams/Kg	Concentration milligrams/Kg
PCB 1016	1.	not found
PCB 1221	1.	not found
PCB 1232	1.	not found
PCB 1242	1.	not found
PCB 1248	1.	not found
PCB 1254	1.	not found
PCB 1260	1.	not found

Compounds listed as "not found" would have been reported if present
at or above the listed detection limits. Sample was extracted 08/09/88.

Percent Moisture: 30%. Tested by EPA method 160.3 on 08/15/88 by PD.

Respectfully submitted,

Mary Havlicek
Mary Havlicek, Ph.D.
President

MSD #5
E7673pc.wr1/35
MH/bl/jl/sc

Central
Coast
Analytical
Services

Central Coast
Analytical Services
141 Suburban Road, Suite C-4
San Luis Obispo, California 93401
(805) 543-2553
EPA METHOD 608/8080 - PCB'S

Lab Number: E-7675
Collected: 08/08/88 @ 1129
Received: 08/09/88
Tested: 08/11/88
Collected by: CS/AC

ERM-WEST
1777 Botelho Dr.
Walnut Creek, CA 94596

SAMPLE DESCRIPTION:
3B-18 (2.0 to 2.5 Feet), Soil Grab

Compound Analyzed	Detection Limit milligrams/Kg	Concentration milligrams/Kg
PCB 1016	1.	not found
PCB 1221	1.	not found
PCB 1232	1.	not found
PCB 1242	1.	not found
PCB 1248	1.	not found
PCB 1254	1.	not found
PCB 1260	1.	not found

Compounds listed as "not found" would have been reported if present
at or above the listed detection limits. Sample was extracted 08/09/88.

Percent Moisture: 7.9%. Tested by EPA method 160.3 on 08/15/88 by PD.

Respectfully submitted,

Mary Havlicek
Mary Havlicek, Ph.D.
President

MSD #5
E7675pc.wr1/35
MH/bl/jl/sc

Central
Coast
Analytical
Services

Central Coast
Analytical Services
141 Suburban Road , Suite C-4
San Luis Obispo, California 93401
(805) 543-2553
EPA METHOD 608/8080 - PCB'S

Lab Number: E-7676
Collected: 08/08/88 @ 1142
Received: 08/09/88
Tested: 08/11/88
Collected by: CS/AC

ERM-WEST
1777 Botelho Dr.
Walnut Creek, CA 94596


SAMPLE DESCRIPTION:
3B-16 (2.0 to 2.5 Feet), Soil Grab

Compound Analyzed	Detection Limit milligrams/Kg	Concentration milligrams/Kg
PCB 1016	1.	not found
PCB 1221	1.	not found
PCB 1232	1.	not found
PCB 1242	1.	not found
PCB 1248	1.	not found
PCB 1254	1.	not found
PCB 1260	1.	not found

Compounds listed as "not found" would have been reported if present
at or above the listed detection limits. Sample was extracted 08/09/88.

Percent Moisture: 8.0%. Tested by EPA method 160.3 on 08/15/88 by PD.

Respectfully submitted,



Mary Havlicek, Ph.D.
President

MSD #5
E7676pc.vr1/35
MH/bl/jl/sc

Central
Coast
Analytical
Services

Central Coast
Analytical Services
141 Suburban Road, Suite C-4
San Luis Obispo, California 93401
(805) 543-2553
EPA METHOD 608/8080 - PCB'S

Lab Number: E-7677
Collected: 08/08/88 @ 1153
Received: 08/09/88
Tested: 08/11/88
Collected by: CS/AC

ERM-WEST
1777 Botelho Dr.
Walnut Creek, CA 94596

SAMPLE DESCRIPTION:
3B-14 (2.0 to 2.5 Feet), Soil Grab

Compound Analyzed	Detection Limit milligrams/Kg	Concentration milligrams/Kg
PCB 1016	1.	not found
PCB 1221	1.	not found
PCB 1232	1.	not found
PCB 1242	1.	not found
PCB 1248	1.	not found
PCB 1254	1.	not found
PCB 1260	1.	not found

Compounds listed as "not found" would have been reported if present at or above the listed detection limits. Sample was extracted 08/09/88.

Percent Moisture: 25%. Tested by EPA method 160.3 on 08/15/88 by PD.

Respectfully submitted,

Mary Havlicek

Mary Havlicek, Ph.D.
President

MSD #5
E7677pc.wr1/35
MH/bl/sc/sc

Central
Coast
Analytical
Services

Central Coast
Analytical Services
141 Suburban Road, Suite C-4
San Luis Obispo, California 93401
(805) 543-2553
EPA METHOD 608/8080 - PCB'S

Lab Number: B-88128
Collected:
Received:
Tested: 8/12/88
Collected by:


CCAS

SAMPLE DESCRIPTION:
Instrument Blank

Compound Analyzed	Detection Limit milligrams/Kg	Concentration milligrams/Kg
PCB 1016	1.	not found
PCB 1221	1.	not found
PCB 1232	1.	not found
PCB 1242	1.	not found
PCB 1248	1.	not found
PCB 1254	1.	not found
PCB 1260	1.	not found

Compounds listed as "not found" would have been reported if present
at or above the listed detection limits.

Respectfully submitted,



Mary Havlicek, Ph.D.
President

AUG 17 '88 17:00 CENTRAL COAST ANALYT P07

LABORATORY CERTIFIED BY CALIFORNIA DEPT OF HEALTH SERVICES

Central
Coast
Analytical
Services

Central Coast
Analytical Services
141 Suburban Road, Suite C-4
San Luis Obispo, California 93401
(805) 543-2553
EPA METHOD 608/8080 - PCB'S

Lab Number: QH-88068
Collected: 08/06/88
Received: 08/06/88
Tested: 08/12/88
Collected by:


CCAS

SAMPLE DESCRIPTION:
Sonic Horn Extraction Blank
08/06/88

Compound Analyzed	Detection Limit milligrams/Kg	Concentration milligrams/Kg
PCB 1016	1.	not found
PCB 1221	1.	not found
PCB 1232	1.	not found
PCB 1242	1.	not found
PCB 1248	1.	not found
PCB 1254	1.	not found
PCB 1260	1.	not found

Compounds listed as "not found" would have been reported if present at or above the listed detection limits. Sample was extracted 08/06/88.

Respectfully submitted,



Mary Havlicek, Ph.D.
President

MSD #5
QH88068pc.wr1/36
MH/bl/sc/sc

AUG 17 '88 16:59 CENTRAL COAST ANALYT P06

AIR, WATER and HAZARDOUS WASTE LABORATORY CERTIFIED by CALIFORNIA DEPT of HEALTH SERVICES

Central
Coast
Analytical
Services

Central Coast
Analytical Services
141 Suburban Road, Suite C-4
San Luis Obispo, California 93401
(805) 543-2553
EPA METHOD 608/8080 - PCB'S

Lab Number: QS-08108-2
Collected: 08/10/88
Received: 08/10/88
Tested: 08/12/88
Collected by:

CCAS


SAMPLE DESCRIPTION:
Sand Spiked With Arochlor 1260

Compound Analyzed	Detection Limit milligrams/Kg	Concentration milligrams/Kg
PCB 1016	0.01	not found
PCB 1221	0.01	not found
PCB 1232	0.01	not found
PCB 1242	0.01	not found
PCB 1248	0.01	not found
PCB 1254	0.01	not found
PCB 1260	0.01	0.06 *

Percent Recovery of Arochlor 1260 = 60%.

Compounds listed as "not found" would have been reported if present
at or above the listed detection limits. Sample was extracted 08/10/88.

Respectfully submitted,



Mary Havlicek, Ph.D.
President

MSD #5
QS810pc2.wr1/36
MH/bl/sc/sc

AUG 17 '88 16:59 CENTRAL COAST ANALYT P05

AIR, WATER and HAZARDOUS WASTE LABORATORY CERTIFIED by CALIFORNIA DEPT of HEALTH SERVICES

Central
Coast
Analytical
Services

Central Coast
Analytical Services
141 Suburban Road, Suite C-4
San Luis Obispo, California 93401
(805) 543-2553
EPA METHOD 808/8080 - PCB'S

Lab Number: QS-08108-1
Collected: 08/10/88
Received: 08/10/88
Tested: 08/12/88
Collected by:

CCAS

SAMPLE DESCRIPTION:
Sand Spiked With Arochlor 1260

Compound Analyzed	Detection Limit milligrams/Kg	Concentration milligrams/Kg
PCB 1016	0.01	not found
PCB 1221	0.01	not found
PCB 1232	0.01	not found
PCB 1242	0.01	not found
PCB 1248	0.01	not found
PCB 1254	0.01	not found
PCB 1260	0.01	0.05 *

Percent Recovery of Arochlor 1260 = 50%.

Compounds listed as "not found" would have been reported if present
at or above the listed detection limits. Sample was extracted 08/10/88.

Respectfully submitted,



Mary Havlicek, Ph.D.
President

MSD #5
QS810pc1.wr1/36
MH/bl/sc/sc

Central
Coast
Analytical
Services

Central Coast
Analytical Services
141 Suburban Road , Suite C-4
San Luis Obispo, California 93401
(805) 543-2553
EPA METHOD 808/8080 - PCB'S

Lab Number: QS-08060-3
Collected: 08/06/88
Received: 08/06/88
Tested: 08/12/88
Collected by:

CCAS

SAMPLE DESCRIPTION:
Sand Spiked With Arochlor 1248

Compound Analyzed	Detection Limit milligrams/Kg	Concentration milligrams/Kg
PCB 1016	0.01	not found
PCB 1221	0.01	not found
PCB 1232	0.01	not found
PCB 1242	0.01	not found
PCB 1248	0.01	0.07 *
PCB 1254	0.01	not found
PCB 1260	0.01	not found

Percent Recovery of Arochlor 1248 = 70%.

Compounds listed as "not found" would have been reported if present
at or above the listed detection limits. Sample was extracted 08/06/88.

Respectfully submitted,

Mary Havlicek

Mary Havlicek, Ph.D.
President

Central
Coast
Analytical
Services

Central Coast
Analytical Services
141 Suburban Road, Suite C-4
San Luis Obispo, California 93401
(805) 543-2553

EPA METHOD 688/8888 - PCB'S

Lab Number: QS-88868-1
Collected: 08/06/88
Received: 08/06/88
Tested: 08/12/88
Collected by:

CCAS


SAMPLE DESCRIPTION:
Sand Spiked With Arochlor 1248

Compound Analyzed	Detection Limit milligrams/Kg	Concentration milligrams/Kg
PCB 1016	0.01	not found
PCB 1221	0.01	not found
PCB 1232	0.01	not found
PCB 1242	0.01	not found
PCB 1248	0.01	0.1 *
PCB 1254	0.01	not found
PCB 1260	0.01	not found

Percent Recovery of Arochlor 1248 = 100%.

Compounds listed as "not found" would have been reported if present at or above the listed detection limits. Sample was extracted 08/06/88.

Respectfully submitted,



Mary Havlicek, Ph.D.
President

Central
Coast
Analytical
Services

Central Coast
Analytical Services
141 Suburban Road , Suite C-4
San Luis Obispo, California 93401
(805) 543-2553
EPA METHOD 808/8080 - PCB'S

Lab Number: B-88118
Collected:
Received:
Tested: 08/11/88
Collected by:

CCAS

SAMPLE DESCRIPTION:
Instrument Blank

Compound Analyzed	Detection Limit milligrams/Kg	Concentration milligrams/Kg
PCB 1016	1.	not found
PCB 1221	1.	not found
PCB 1232	1.	not found
PCB 1242	1.	not found
PCB 1248	1.	not found
PCB 1254	1.	not found
PCB 1260	1.	not found

Compounds listed as "not found" would have been reported if present
at or above the listed detection limits.

Respectfully submitted,

Mary Havlicek
Mary Havlicek, Ph.D.
President

AUG 17 '88 16:55 CENTRAL COAST ANALYT

P01

HEALTH SERVICES

Central
Coast
Analytical
Services

Central Coast
Analytical Services
141 Suburban Road , Suite C-4
San Luis Obispo, California 93401
(805) 543-2553
EPA METHOD 608/8080 - PCB'S

Lab Number: 8-08118
Collected:
Received:
Tested: 08/11/88
Collected by:

CCAS

SAMPLE DESCRIPTION:
Instrument Blank

Compound Analyzed	Detection Limit milligrams/Kg	Concentration milligrams/Kg
PCB 1016	1.	not found
PCB 1221	1.	not found
PCB 1232	1.	not found
PCB 1242	1.	not found
PCB 1248	1.	not found
PCB 1254	1.	not found
PCB 1260	1.	not found

Compounds listed as "not found" would have been reported if present
at or above the listed detection limits.

Respectfully submitted,

Mary Havlicek

Mary Havlicek, Ph.D.
President

RSD #5
808118pc.wr1/35
RH/bl/sc/sc

AUG 17 '88 16:49 CENTRAL COAST ANALYT

P07

ANALYTICAL SERVICES

Central
Coast
Analytical
Services

Central Coast
Analytical Services
141 Suburban Road, Suite C-4
San Luis Obispo, California 93401
(805) 543-2553
EPA METHOD 608/8080 - PCB'S

Lab Number: B-08118
Collected:
Received:
Tested: 08/11/88
Collected by:


CCAS

SAMPLE DESCRIPTION:
Instrument Blank

Compound Analyzed	Detection Limit milligrams/Kg	Concentration milligrams/Kg
PCB 1016	1.	not found
PCB 1221	1.	not found
PCB 1232	1.	not found
PCB 1242	1.	not found
PCB 1248	1.	not found
PCB 1254	1.	not found
PCB 1260	1.	not found

Compounds listed as "not found" would have been reported if present
at or above the listed detection limits.

Respectfully submitted,



Mary Havlicek, Ph.D.
President

MSD #5
B08118pc.wr1/35
MH/bl/sc/sc

AUG 17 '88 16:48 CENTRAL COAST ANALYT

P06

Central
Coast
Analytical
Services

Central Coast
Analytical Services
141 Suburban Road , Suite C-4
San Luis Obispo, California 93401
(805) 543-2553
EPA METHOD 808/8080 - PCB'S

Lab Number: QH-08108
Collected: 08/10/88
Received: 08/10/88
Tested: 08/11/88
Collected by:


CCAS

SAMPLE DESCRIPTION:
Sonic Horn Extraction Blank
08/10/88

Compound Analyzed	Detection Limit milligrams/Kg	Concentration milligrams/Kg
PCB 1016	1.	not found
PCB 1221	1.	not found
PCB 1232	1.	not found
PCB 1242	1.	not found
PCB 1248	1.	not found
PCB 1254	1.	not found
PCB 1260	1.	not found

Compounds listed as "not found" would have been reported if present
at or above the listed detection limits. Sample was extracted 08/10/88.

Respectfully submitted,


Mary Havlicek, Ph.D.
President

MSD #5
QH0810pc.wr1/35
MH/bl/sc/sc

AUG 17 '88 16:48 CENTRAL COAST ANALYT P05

AIR, WATER and HAZARDOUS WASTE LABORATORY CERTIFIED by CALIFORNIA DEPT OF HEALTH SERVICES

Central
Coast
Analytical
Services

Central Coast
Analytical Services
141 Suburban Road, Suite C-4
San Luis Obispo, California 93401
(805) 543-2553
EPA METHOD 808/8080 - PCB'S

Lab Number: QS-08098
Collected: 08/09/88
Received: 08/09/88
Tested: 08/11/88
Collected by:

CCAS


SAMPLE DESCRIPTION:
Sand Spiked With Arochlor 1260

Compound Analyzed	Detection Limit milligrams/Kg	Concentration milligrams/Kg
PCB 1016	0.1	not found
PCB 1221	0.1	not found
PCB 1232	0.1	not found
PCB 1242	0.1	not found
PCB 1248	0.1	not found
PCB 1254	0.1	not found
PCB 1260	0.1	0.3 *

* Percent Recovery of Arochlor 1260 = 60%.

Compounds listed as "not found" would have been reported if present
at or above the listed detection limits. Sample was extracted 08/09/88.

Respectfully submitted,



Mary Havlicek, Ph.D.
President

APPENDIX B

LABORATORY QA/QC PROCEDURES

Central
Coast
Analytical
Services

**CENTRAL COAST
ANALYTICAL SERVICES**

Air, Water & Hazardous Waste Analysis
141 Suburban Road, Suite C-4
San Luis Obispo, California 93401
(805) 543-2553

RECEIVED

NOV 13 1987

ERM-WEST
WALNUT CREEK, CA

August 1, 1986

QUALITY ASSURANCE/QUALITY CONTROL PROCEDURE

1. Chain of Custody samples are stored in locked refrigerators.
2. The assignment of unique laboratory numbers to each sample as it is logged in has been extended to include the assignment of unique log numbers to subsamples on a container-by-container basis.
3. A central standard logbook is maintained for all standards. Information such as suppliers, lot numbers, weight/volume of standards used, date prepared and the name of the analyst preparing the standard are all part of the records kept therein.
4. The laboratory runs calibration standards at a minimum of three concentrations. We bracket sample data with standards.
5. We confirm all positive gas chromatographic results by either a second column or by GC/MS.
6. Blanks, duplicates, and spikes are analyzed once per batch, once per matrix type or once per 20 samples, whichever is more frequent. We have adopted an "all with the final report" filing system.
7. Records of the analysis of blank samples are recorded in individual laboratory notebooks, referred to on laboratory worksheets and documented on instrument use record books.
8. Acceptance limits for quality control samples currently used by our laboratory are summarized in Table I.
9. All analytical and quality control results are reviewed and approved by a supervisor. Data of an unusual nature are brought to the attention of one of our three Ph.D. chemists for final review.
10. Instructions for corrective action in the event of an out-of-control method are as follows: Stop analyses. Conduct investigation. Check mathematics. Check dilutions for systematic error. Check syringes, automatic pipettes, ect. for possible malfunction. Check dates on standards. Remake standards. If instrument malfunction is indicated, arrange for

service. Analyses may resume only when problem has been identified and corrected.

11. Repair and maintenance records are documented for inspection and review.
12. Analytical results including raw data and chromatographs of method blanks, three point standard calibration and quality control samples (matrix spikes and matrix spike duplicates) for the following methods are available for review:

Method Number	Description
632	Carbamates
8030	Acrolein, Acrylonitrile & Acetonitrile
8060	Phthalate Esters
8090	Nitroaromatics & Cyclic Ketones
8120	Chlorinated Hydrocarbons

TABLE I - ACCEPTANCE LIMITS for QUALITY ASSURANCE SAMPLES

ANALYTICAL PROCEDURE or PARAMETER GROUP		SPIKE LEVEL ACCEPTABLE		DUPLICATE ACCEPTABLE
Matrix		ppb	% RANGE	% DIFFERENCE
Metals by AA *	Liquid	10X	80-115	15
	Solid		65-130	30
As	Liquid	468	70-128	25
	Solid	12500	60-135	35
Cd	Liquid	90	80-122	25
	Solid	12500	60-135	35
Cr	Liquid	916	75-120	20
	Solid	20000	60-135	35
Co	Liquid	303	82-115	15
	Solid	12500	60-135	40
Cu	Liquid	110	84-117	15
	Solid	180000	65-130	40
Pb	Liquid	556	85-120	15
	Solid	12000	75-125	25
Hg	Liquid	24	65-133	30
	Solid	6100	40-150	45
Ni	Liquid	121	82-118	15
	Solid	9000	55-140	40
Se	Liquid	45	50-131	40
	Solid	12500	40-150	45
V	Liquid	791	82-123	25
	Solid	9000	55-140	40
Zn	Liquid	1378	85-114	15
	Solid	360000	40-150	45
Tl	Solid	1800	50-145	40
Ag	Solid	1800	12-160	45
Sb	Solid	6100	60-135	35
Be	Solid	16300	55-140	40
Al	Liquid	815	78-125	25

TABLE I - ACCEPTANCE LIMITS for QUALITY ASSURANCE

SAMPLES-Continued

ANALYTICAL PROCEDURE or PARAMETER GROUP		SPIKE LEVEL. ACCEPTABLE		DUPLICATE
Matrix		ppb	% RANGE	% DIFFERENCE
Chlorinated				
Herbicides *	Liquid	300	75-120	25
2,4-D	Liquid	300	75-120	25
Silvex	Liquid	70	75-120	25
2,4,5-T	Liquid	30	75-125	25
Phenols *				
	Liquid	300	40-140	45
	Solid			
2-Chlorophenol	Liquid	100	25-135	45
	Solid	10030	32-140	50
2-Nitrophenol	Liquid	500	D-150	100
	Solid	4020	D-150	100
Phenol	Liquid	300	5-112	75
	Solid	4000	D-150	100
2,4-Dimethyl-phenol	Liquid	300	12-150	75
	Solid	4020	D-150	100
2,4-Dichloro-phenol	Liquid	300	35-140	50
	Solid	10100	19-150	75
2,4,6-Tri-chlorophenol	Liquid	300	20-150	75
	Solid	10020	20-150	75
4-Chloro-3-methylphenol	Liquid	200	22-147	75
	Solid	10020	15-150	75
2,4-Dinitro-phenol	Liquid	500	D-160	100
	Solid	10000	D-150	100
2-Methyl-4,6-dinitrophenol	Liquid	500	5-160	75
	Solid	4020	D-160	100
Pentachloro-phenol	Liquid	100	14-176	75
	Solid	4010	D-180	100
4-Nitrophenol	Liquid	500	D-132	75
	Solid	4010	D-160	100

- TABLE I - ACCEPTANCE LIMITS for QUALITY ASSURANCE SAMPLES

- Continued

ANALYTICAL PROCEDURE or PARAMETER GROUP		SPIKE LEVEL ACCEPTABLE		DUPLICATE ACCEPTABLE
	Matrix	ppb	% RANGE	% DIFFERENCE
=====				
Metals by ICP *	Liquid	10X	50-140	40
As	Liquid	22	70-125	25
Cd	Liquid	2.5	52-140	40
Cr	Liquid	10	46-145	40
Cu	Liquid	11	10-160	75
Pb	Liquid	24	15-155	75
Ni	Liquid	60	58-135	40
Se	Liquid	6	D-200	100
Zn	Liquid	16	10-170	75
Be	Liquid	20	70-125	25
Co	Liquid	120	40-150	50
V	Liquid	70	80-115	15
Carbamate by LC	Liquid	100X	80-115	15
Polychlorinated Biphenyls (see organochlorine pesticides)				
Aromatic Volatile Organics				
Benzene	Liquid	9	64-130	40
Chlorobenzene	Liquid	100	70-127	30
1,2-Dichloro- benzene	Liquid	10	16-170	75
1,3-Dichloro- benzene	Liquid	5	37-150	75
1,4-Dichloro- benzene	Liquid	10	40-170	75
Ethylbenzene	Liquid	10	62-137	40
Toluene	Liquid	100	41-136	75

TABLE I - ACCEPTANCE LIMITS for QUALITY ASSURANCE SAMPLES
- Continued

ANALYTICAL PROCEDURE or PARAMETER GROUP		SPIKE LEVEL ACCEPTABLE		DUPLICATE ACCEPTABLE
Matrix		ppb	% RANGE	% DIFFERENCE

Halogenated Volatile Organics				
Bromodichloro-				
methane	Liquid	0.5	85-115	15
Bromoform	Liquid	50	60-130	30
Carbon				
tetrachloride	Liquid	50	20-140	75
Chlorobenzene	Liquid	50	67-121	25
Chloroethane	Liquid	50	30-150	75
2-Chloroethyl				
vinyl ether	Liquid	133	66-126	30
Chloroform	Liquid	50	60-160	40
Chloromethane	Liquid	24	50-140	50
Dibromochloro-				
methane	Liquid	93	78-118	25
1,2-Dichloro-				
benzene	Liquid	150	85-115	15
1,3-Dichloro-				
benzene	Liquid	50	79-112	25
1,4-Dichloro-				
benzene	Liquid	50	70-124	25
1,1-Dichloro-				
ethane	Liquid	45	80-120	25
1,2-Dichloro-				
ethane	Liquid	45	80-120	25
1,1-Dichloro-				
ethylene	Liquid	50	40-150	60
t-1,2-Dichloro-				
ethylene	Liquid	98	30-150	75
1,2-Dichloro-				
propane	Liquid	39	70-125	25
t-1,3-Dichloro-				
propylene	Liquid	50	22-150	75
1,1,2,2-Tetra-				
chloroethane	Liquid	45	45-135	45
Tetrachloro-				
ethylene	Liquid	35	35-150	75
1,1,1-Tri-				
chloroethane	Liquid	29	45-135	50
1,1,2-Tri-				
chloroethane	Liquid	50	20-150	75
Trichloro-				
ethylene	Liquid	45	80-120	25
Vinyl Chloride	Liquid	32	70-130	25

TABLE I - ACCEPTANCE LIMITS for QUALITY ASSURANCE SAMPLES
- Continued

ANALYTICAL PROCEDURE or PARAMETER GROUP		SPIKE		DUPLICATE
Matrix		LEVEL	ACCEPTABLE	ACCEPTABLE
		ppb	% RANGE	% DIFFERENCE

Base/Neutrals				
Acenapthene	Liquid	100	47-145	45
	Solid	2010	26-130	75
Acenaphthalene	Liquid	2000	31-140	75
	Solid	2020	25-130	75
Anthracene	Liquid	2000	30-140	75
	Solid	4040	32-132	75
Benzo(a)anthracene	Liquid	2000	30-140	75
	Solid	2020	7-150	100
Benzo(b)fluoranthene	Liquid	2000	17-140	100
	Solid	4420	6-150	100
Benzo(k)fluoranthene	Liquid	2000	17-140	100
	Solid	4420	6-150	100
Benzo(ghi)perylene	Liquid	2000	D-180	200
	Solid	62000	40-160	75
Benzo(a)pyrene	Liquid	2000	17-140	100
	Solid	2080	18-130	100
Benzidine	Liquid	2000	0-150	200
	Solid	2010	EPA NOT ABLE TO RECOVER	
Butyl benzyl phthalate	Liquid	2000	D-150	200
	Solid	2020	7-150	100
Bis(2-chloroethoxy)methane	Liquid	2000	D-150	200
	Solid	2020	9-150	100
Bis(2-chloroethyl)ether	Liquid	2000	D-150	200
	Solid	2020	D-150	200
Bis(2-chloroisopropyl)ether	Liquid	2000	D-150	200
	Solid	10020	30-150	75
Bis(2-ethylhexyl)phthal.	Liquid	2000	D-200	200
	Solid	32210	30-150	75
4-Bromophenyl phenyl ether	Liquid	2000	30-150	75
	Solid	2070	30-150	75
2-Chloronaphthalene	Liquid	2000	37-150	75
	Solid	1920	30-150	75
4-chlorophenyl phenyl ether	Liquid	2000	30-150	75
	Solid	2010	15-130	100
Chrysene	Liquid	2000	37-150	75
	Solid	2020	7-150	100
Dibenzo(a,h)anthracene	Liquid	2000	D-170	200
	Solid	61400	34-200	100
Di-n-butyl phthalate	Liquid	2000	D-200	200
	Solid	2010	5-180	100
1,2-Dichlorobenzene	Liquid	100	1-118	125
	Solid	77200	50-128	50

TABLE I - ACCEPTANCE LIMITS for QUALITY ASSURANCE SAMPLES
- Continued

ANALYTICAL PROCEDURE or PARAMETER GROUP		SPIKE LEVEL	ACCEPTABLE % RANGE	DUPLICATE ACCEPTABLE % DIFFERENCE
	Matrix	ppb		
1,3-Dichloro	Liquid	100	1-118	125
benzene	Solid	8540	D-170	200
1,3-Dichloro	Liquid	100	1-118	125
benzene	Solid	54800	29-142	75
3,3-Dichloro-	Liquid	2000	D-300	200
benzidine	Solid	10000	D-300	200
Dimethyl	Liquid	2000	3-130	125
phthalate	Solid	2010	21-140	100
2,4-Dinitro-	Liquid	200	50-158	75
toluene	Solid	2030	18-140	100
2,6-Dinitro-	Liquid	200	50-158	75
toluene	Solid	2030	18-140	100
Di-n-octyl	Liquid	2000	D-200	200
phthalate	Solid	2030	12-170	100
Fluoranthene	Liquid	2000	20-140	100
	Solid	2010	D-170	150
Fluorene	Liquid	2000	20-140	100
	Solid	2010	30-160	100
Hexachloro-	Liquid	2000	26-150	100
benzene	Solid	1610	63-133	50
Hexachloro-	Liquid	2000	D-200	200
butadiene	Solid	2050	0-200	200
Hexachloro-	Liquid	2000	D-200	200
cypentadiene	Solid	2010	EPA NOT ABLE TO RECOVER	
Hexachloro-	Liquid	2000	D-200	200
ethane	Solid	2000	56-151	75
Indeno(1,2,3-	Liquid	2000	D-200	200
cd) pyrene	Solid	50010	34-180	100
Isophorone	Liquid	2000	D-200	200
	Solid	2020	9-142	100
Naphthalene	Liquid	2000	D-200	200
	Solid	152500	55-126	75
Nitrobenzene	Liquid	2000	D-200	200
	Solid	42100	16-150	125
N-Nitrosodi-n-	Liquid	2000	D-200	200
propylamine	Solid	10020	62-180	75
N-Nitrosodi-	Liquid	2000	6-170	100
phenylamine	Solid	10000	0-200	200
Phenanthrene	Liquid	2000	29-136	100
	Solid	2010	26-130	75
Pyrene	Liquid	2000	29-136	100
	Solid	2020	16-160	100
Trichloro-	Liquid	2000	17-170	100
benzene	Solid	2200	3-160	125

TABLE I - ACCEPTANCE LIMITS for QUALITY ASSURANCE SAMPLES
- Continued

ANALYTICAL PROCEDURE or PARAMETER GROUP		SPIKE LEVEL	ACCEPTABLE % RANGE	DUPLICATE ACCEPTABLE % DIFFERENCE
Matrix		ppb		
EPA 624/8240 Purgeable Organics				
Benzene	Liquid	100	68-130	40
	Solid	99	80-100	50
Bromodichloro-	Liquid	100	73-130	30
methane	Solid	10	60-170	50
Bromoform	Liquid	100	52-152	50
	Solid	10	70-150	50
Bromomethane	Liquid	100	22-169	75
Carbon tetra-	Liquid	100	69-149	40
chloride	Solid	10	61-150	50
Chlorobenzene	Liquid	100	75-130	30
	Solid	10	10-150	100
Chloroethane	Liquid	100	14-190	100
2-Chloroethyl				
vinyl ether	Liquid	100	75-150	35
Chloroform	Liquid	100	64-136	40
	Solid	10	85-132	40
Chloromethane	Liquid	100	28-172	75
Dibromochloro-	Liquid	100	62-146	40
methane	Solid	1	33-126	75
1,1-Dichloro-	Liquid	100	60-150	40
ethane	Solid	10	31-150	75
1,2-Dichloro-	Liquid	100	72-132	35
ethane	Solid	10	13-160	100
1,1-Dichloro-	Liquid	100	54-145	40
ethene	Solid	10	10-170	100
1,2-Dichloro-	Liquid	100	71-130	35
ethene	Solid	10	23-147	100
1,2-Dichloro-	Liquid	100	67-136	40
propane	Solid	10	35-144	75
1,3-Dichloro-	Liquid	100	45-157	50
propene	Solid	8	45-140	75
1,3-Dichloro-	Liquid	100	46-154	50
propene	Solid	10	48-142	100
Ethylbenzene	Liquid	100	73-133	40
	Solid	10	43-130	100
Methylene	Liquid	100	8-187	200
Chloride	Solid	10	28-130	200
1,1,2,2-Tetra-	Liquid	100	60-146	40
chloroethane	Solid	10	D-250	300
Tetrachloro-	Liquid	100	67-133	70
ethene	Solid	10	D-250	300

TABLE I - ACCEPTANCE LIMITS for QUALITY ASSURANCE SAMPLES
- Continued

ANALYTICAL PROCEDURE or PARAMETER GROUP		SPIKE LEVEL ACCEPTABLE		DUPLICATE
	Matrix	ppb	% RANGE	ACCEPTABLE % DIFFERENCE
Toluene	Liquid	100	56-140	40
	Solid	10	61-120	45
1,1,1-Tri- chloroethane	Liquid	100	54-150	40
	Solid	10	23-140	150
1,1,2-Tri- chloroethane	Liquid	100	59-149	40
	Solid	10	55-127	50
Trichloro- ethene	Liquid	100	64-136	40
	Solid	10	18-145	150
Trichloro- fluoromethane	Liquid	100	50-164	75
Vinyl chloride	Liquid	100	23-173	180
EPA 8030 PURGEABLE ORGANIC COMPOUNDS				
Acrolein	Liquid	20	61-135	45
Acrylonitrile	Liquid	20	85-124	40
EPA 8060 PHTHALATE ESTERS				
Bis(2-ethyl- hexyl)phthalate	Liquid	1000	74-111	45
Butyl benzyl phthalate	Liquid	1000	66-116	50
Dibutyl- phthalate	Liquid	1000	65-115	50
Diethyl phthalate	Liquid	50	90-110	40
Dimethyl phthalate	Liquid	50	84-110	40
Diethyl phthalate	Liquid	150	73-113	40
EPA 8090 NITROAROMATICS AND CYCLIC KETONES				
2,4-Dinitro- toluene	Liquid	100	55-110	75
2,6-Dinitro- Isophorone	Liquid	50	60-110	75
toluene	Liquid	50	63-110	75
Nitrobenzene	Liquid	100	58-113	75
EPA 8100 POLYNUCLEAR AROMATIC HYDROCARBONS				
Same as EPA 625/8270				

TABLE I - ACCEPTANCE LIMITS for QUALITY ASSURANCE SAMPLES
- Continued

ANALYTICAL PROCEDURE or PARAMETER GROUP		SPIKE		DUPLICATE
Matrix		LEVEL	ACCEPTABLE	ACCEPTABLE
		ppb	% RANGE	% DIFFERENCE
EPA 8120 CHLORINATED HYDROCARBONS				
2-Chloro-naphthalene	Liquid	200	19-157	180
1,2-Dichlorobenzene	Liquid	300	57-125	100
1,3-Dichlorobenzene	Liquid	200	40-146	150
1,4-Dichlorobenzene	Liquid	300	35-153	150
Hexachlorobenzene	Liquid	10	61-134	75
Hexachlorobutadiene	Liquid	30	66-130	75
Hexachloroethane	Liquid	10	63-136	75
1,2,4-Tri-chlorobenzene	Liquid	10	48-148	125
EPA 8140 ORGANOPHOSPORUS PESTICIDES				
Azinphos methyl	Liquid	200	32-141	150
Bolstar	Liquid	40	53-115	75
Chlorpyrifos	Liquid	50	82-116	45
Coumaphos	Liquid	200	70-147	75
Demeton	Liquid	300	46-121	100
Diazinon	Liquid	5	55-112	75
Dichlorvos	Liquid	500	55-117	75
Disulfoton	Liquid	80	60-122	75
Ethoprop	Liquid	50	88-112	45
Fensulfothion	Liquid	100	46-148	150
Fenthion	Liquid	50	33-136	150
Merphos	Liquid	50	76-145	75
Mevinphos	Liquid	500	34-123	150
Naled	Liquid	200	69-119	75
Parathion methyl	Liquid	500	81-115	45
Phorate	Liquid	40	46-117	150
Ronnel	Liquid	50	83-117	45
Stirophos	Liquid	500	54-112	150
Tokuthion	Liquid	50	51-113	150
Trichloronate	Liquid	20	46-161	150

93, 96-98, and 104-115 to new Table IB, entitled "List of Approved Inorganic Test Procedures", adding two new inorganic parameters, Carbonaceous Biochemical Oxygen Demand (CBOD_k) and Nitrate-Nitrite, including an additional test procedure based upon the inductively coupled plasma technique in Table IB for 25 of the metal parameter designations, by including 10 methods approved under the equivalency provisions of §§ 136.4(d) and 136.5(e), and updating references to EPA, Standard Methods, ASTM, AOAC and USGS test procedures; by deleting

former parameter 14 (Chlorinated organic compounds) and by entering the individual chlorinated organic compounds into new Table IC, entitled, "List of Approved Test Procedures for Non-Pesticide Organic Compounds", transferring old parameters 9 (Benzidine) and 94 (Pentachlorophenol) to Table IC, by including the 78 additional proposed non-pesticidal organic parameters and by adding 17 new test procedures in Table IC; by deleting former parameter 95 (Pesticides) and by entering the 68 individual pesticides into new Table ID,

entitled "List of Approved Test Procedures for Pesticides", by including the 2 additional proposed pesticide parameters, and the two new test procedures in Table ID; and by transferring the former radiological parameters (88-103) to new Table IF, entitled "Approved Radiological Test Procedures", adding an EPA reference to the approved test procedures, and updating the Standard Methods, ASTM and USGS references. As revised, Table I reads as follows:

§ 136.3 Identification of Test Procedures.

TABLE IA.—LIST OF APPROVED BIOLOGICAL TEST PROCEDURES

Parameter and units	Method ¹	EPA ²	Reference (Method Number or Page)		
			Standard Methods 15th Ed.	ASTM	USGS
Bacteria:					
1. Coliform (fecal) number per 100 ml	MPN, 5 tube, 3 dilution, or, membrane filter (MF) ³ , single step	p. 132 p. 124	980C 909C		B-0050-77.
2. Coliform (fecal) in presence of chlorine number per 100 ml	MPN, 5 tube, 3 dilution	p. 132 p. 114	908C 908A		
3. Coliform (total) number per 100 ml	MPN, 5 tube, 3 dilution, or, MF ³ single step or two step	p. 108 p. 114	909A 908A		
4. Coliform (total) in presence of chlorine, number per 100 ml	MPN, 5 tube, dilution, or MF ³ with enrichment	p. 111 p. 111	909A 909A		B-0025-77.
5. Fecal streptococci, number per 100 ml	MPN, 5 tube, 3 dilution; MF ³ ; or, plate count	p. 138 p. 108	909 (A + A.5c) 910A		
	p. 143	910C		B0055-77. ⁴	

Table IA Notes

- ¹ The method must be specified when results are reported
- ² "Microbiological Methods for Monitoring the Environment, Water and Wastes, 1978", EPA-600/8-78-017, U.S. Environmental Protection Agency.
- ³ Green, P.E., et al. Methods for Collection and Analysis of Aquatic Biological and Microbiological Samples, "U.S. Geological Survey, Techniques of Water-Resources Investigations, Book 5, Chapter A4, Laboratory Analysis, 1977
- ⁴ 0.45 µm membrane filter or other pore size certified by the manufacturer to fully retain organisms to be cultivated, and free of extractables which could interfere with their growth and development.
- ⁵ Approved only if dissolution of the KF Streptococcus Agar (Section 5.1, USGS Method B-0055-77) is made in a boiling water bath to avoid scorching of the medium.

TABLE IB.—LIST OF APPROVED INORGANIC TEST PROCEDURES

Parameter, units, and method	Reference (method No. or page)				
	EPA 1978	Standard methods 15th Ed.	ASTM	USGS ¹	Other
1. Acidity, as CaCO ₃ , mg/L. Electrometric and point or phenolphthalein end point	305.1	402(4 d)	D1067-70(E)		
2. Alkalinity, as CaCO ₃ , mg/L. Electrometric or colorimetric					
Titration to pH 4.5, manual	310.1	403	D1067(B)	I-1030-78	P. 548. ²
Or automated	310.2			I-2030-78	
3. Aluminum—Total ³ , mg/L. Digestion ³ followed by					
AA direct aspiration	202.1	303C		I-3051-78	
AA furnace	202.2	304			Method 200.7. ⁴
Inductively coupled plasma					
Or colorimetric (Eriochrome cyanine R)		306B			
4. Ammonia (as N), mg/L. Manual distillation ⁵ (at pH 9.5):					
Followed by	350.2	417A			
Nesslerization	350.2	417B	D1426-79(A)	I-3520-78	P. 553. ²
Titration	350.2	417D			
Electrode	350.3		D1426-79(D)		
Automated phenate or	350.1	417F	D1426-79(C)	I-4523-78	
Automated electrode					
5. Arsenic—Total ³ , mg/L. Digestion ³ followed by					
AA direct aspiration	204.1	303A			
AA furnace, or	204.2	304			Method 200.7. ⁴
Inductively coupled plasma					
6. Arsenic—Total ³ , mg/L					
Digestion ³ followed by	206.5				
Hydride	206.3	303E	D2972-78(B)	I-3082-78	
AA furnace	206.2	304			Method 200.7. ⁴
Inductively coupled plasma					
Or, colorimetric (SDCC)	206.4	307B	D2972-78(A)	I-3080-78	
7. Barium—Total ³ , mg/L. Digestion ³ followed by					
AA direct aspiration	208.1	303C		I-3084-78	
AA furnace, or	208.2	304			Method 200.7. ⁴
Inductively coupled plasma					
8. Barium—Total ³ , mg/L. Digestion ³ followed by					
AA direct aspiration	210.1	303C	D3645-78	I-3095-78	
AA furnace	210.2	304			

TABLE IB.—LIST OF APPROVED INORGANIC TEST PROCEDURES—Continued

Parameter, units, and method	Reference (method No. or page)				
	EPA 1979	Standard methods 15th Ed.	ASTM	USGS ¹	Other
Inductively coupled plasma Or colorimetric (aluminum)		309B			Method 200.7. ^a
9. Biochemical oxygen demand (BOD ₅), mg/L: Winkler (Azide modification) Or electrode method	405.1	507		I-1578-78	P. 17. ^a P. 548. ^a
10. Boron—Total, mg/L: Colorimetric (curcumin) or Inductively coupled plasma	212.3	404A		I-3112-78	Method 200.7. ^a P. 544. ^a
11. Bromide, mg/L: Titrimetric	320.1		D1246-77(C)	I-1125-78	
12. Cadmium—Total ² , mg/L: Digestion ³ followed by: AA direct aspiration AA furnace Inductively coupled plasma Volametry ⁴ or Colorimetric (Dithizone)	213.2 213.2	303A or 303B 304	D3557-78 (A or B)	I-3135-78 or I-3136-78	Pg. 557. ^a P. 37. ^a Method 200.7. ^a
13. Calcium—Total ² , mg/L: Digestion ³ followed by Atomic absorption Inductively coupled plasma Or EDTA titration	215.1 215.2	303A 311C	D511-77(C) D511-77(B)	I-3152-78	Method 200.7. ^a
14. Carbonaceous Biochemical oxygen demand (CBOD ₅), mg/L: Winkler (Azide modification) or electrode method with nitrification inhibitor.		507(5 e.8)			
15. Chemical oxygen demand (COD), mg/L: Titrimetric colorimetric Manual or	410.1 410.2 410.3 410.4	508A	D1252-78	I-3560-78 I-3562-78 I-3561-78	P. 550 ^a and P. 17 ^a and (1 ^a)
Automated Spectrophotometric					(1 ^a)
16. Chloride, mg/L: Titrimetric (silver nitrate) or Mercuric nitrate Colorimetric (mercuric nitrate) manual or Automated	325.3 325.1 or 325.2	407A 407B 407D	D512-67(B) D512-67(A) D512-67(C)	I-1183-78 I-1184-78 I-1187-78 I-2187-78	P. 554. ^a
17. Chlorine—Total residual, mg/L: Titrimetric-mercurimetric ¹² Starch end point Iodometric or DPD-FAS Spectrophotometric, DPD, or Electrode	330.1 330.2 330.3 330.4 330.5	408C 408B 408A 408D 408E	D1253-76(A) D1253-76(B)		(1 ^a)
18. Chromium VI dissolved, mg/L: 0.45 micron filtration with: Extraction and atomic absorption, or Colorimetric (Diphenylcarbazide)	218.4	303B		I-1232-78 I-1230-78	
19. Chromium—Total ² , mg/L: Digestion ³ (optional extraction) followed by: AA direct aspiration AA furnace Inductively coupled plasma Or colorimetric (Diphenylcarbazide)	218.3 218.1 218.2	303A or 303B 304	D1687-77(D)	I-3236-78	P. 557. ^a Method 200.7. ^a
20. Cobalt—Total ² , mg/L: Digestion ³ followed by: AA direct aspiration AA furnace, or Inductively coupled plasma	219.1 219.2	303A or 303B 304	D3558-77 (A or B)	I-3240-78 or I-3239-78	P. 37. ^a Method 200.7. ^a
21. Color, platinum cobalt units or dominant wavelength blue, luminance, purity Colorimetric, ADMI Platinum cobalt, or Spectrophotometric	110.1 110.2 110.3	204D 204A 204B		I-1250-78	(1 ^a)
22. Copper—Total ² , mg/L: Digestion ³ followed by: AA direct aspiration AA furnace Inductively coupled plasma Colorimetric (Neocupronine) Bismuthate	220.1 220.2	303A or 303B 304	D1688-77 (D or E)	I-3271-78 or I-3270-78	P. 557. ^a and P. 37. ^a Method 200.7. ^a
23. Cyanide—Total mg/L: Manual distillation with MgCl ₂ Followed by titrimetric Manual or Automated ¹³ spectrophotometric	335.2 335.2 335.2 335.3	412D 412B 412C 412D	D2036-75(A) D2036-75(A) D2036-75(B)	I-3300-78	P. 22. ^a
24. Cyanide amenable to chlorination, mg/L: Manual distillation with MgCl ₂ followed by titrimetric, manual or automated ¹³ spectrophotometric	335.1	412F			
25. Fluoride—Total, mg/L: Manual distillation ¹⁴ Followed by manual titration Automated electrode SPADNS Or automated complexone	340.2 340.1 340.3	413A 413B 413C 413E	D1179-72(B) D1179-72(A)	I-4327-78	
26. Gold—Total ² , mg/L: Digestion ³ followed by: AA direct aspiration Or AA furnace	231.1 231.2	303A 304			
27. Hardness—Total as CaCO ₃ , mg/L: Automated colorimetric EDTA titration Inductively coupled plasma Or atomic absorption (sum of Ca and Mg as their respective carbonates)	130.1 130.2 215.1 242.1	314B 303A	D1126-67(B)	I-1338-78 I-3153-78 I-3448-78	Method 200.7. ^a

TABLE IB.—LIST OF APPROVED INORGANIC TEST PROCEDURES—Continued

Parameter, units, and method	Reference (method No. or page)				
	EPA 1979	Standard methods 15th Ed.	ASTM	USGS ¹	Other
28. Hydrogen ion (pH), pH units: Electrometric	150.1	423	D1293-78(A) or D1293-78(B).	I-1586-78	(¹⁰)
Measurements; or automated electrode					
29. Indium—Total ² , mg/L: Digestion ³ followed by: AA direct aspiration	235.1	303A			
Or AA furnace	235.2	304			
30. Iron—Total ² , mg/L: Digestion ³ followed by: AA direct aspiration	236.1	303A or 303B	D1068-77 (C or D)	I-3381-78	P. 557. ⁹
AA furnace	236.2	304			Method 200.7. ⁴
Inductively coupled plasma					(¹¹)
Or colorimetric (Phenanthroline)		315B	D1068-77(A)		P. 552. ⁹
31. Kjeldahl nitrogen—Total (as N), mg/L: Digestion and distillation	351.3	420A or B			
Followed by titration	351.3	417D	D3590-77		
Resazurinization or	351.3	417B			
Electrode	351.3	417E		I-4551-78	
Automated phenate	351.1			I-4552-78	
Semi-automated block digester	351.2				
Or potentiometric	351.4				
32. Lead—Total ² , mg/L: Digestion ³ followed by: AA direct aspiration	239.1	303A or 303B	D3558-78 (A or B)	I-3399-78	P. 557. ⁹
AA furnace	239.2	304			Method 200.7. ⁴
Inductively coupled plasma					
Voltammetry ⁵ or			D3558-78(C)		
Colorimetric (Dithione)		316B			
33. Magnesium—Total ² , mg/L: Digestion ³ followed by: Atomic absorption	242.1	303A	D511-77(B)	I-3447-78	P. 557. ⁹
Inductively coupled plasma					Method 200.7. ⁴
Or gravimetric		318B	D511-77(A)		
34. Manganese—Total ² , mg/L: Digestion ³ followed by: AA direct aspiration	243.1	303A or 303B	D658-77 (B or C)	I-3454-78	P. 557. ⁹
AA furnace	243.2	304			Method 200.7. ⁴
Inductively coupled plasma					P. 564. ⁹
Or colorimetric (Persulfate)		319B	D658-77(A)		18.
Periodate					
35. Mercury—Total ² , mg/L: Cold vapor, manual or	245.1	303F	D3223-78	I-3462-78	P. 558. ⁹
Automated	245.2				
36. Molybdenum—Total ² , mg/L: Digestion ³ followed by: AA direct aspiration	246.1	303C		I-3490-78	
AA furnace, or	246.2	304			Method 200.7. ⁴
Inductively coupled plasma					
37. Nickel—Total ² , mg/L: Digestion ³ followed by: AA direct aspiration	249.1	303A or 303B	D1886-77 (C or D)	I-3499-78	
AA furnace	249.2	304			Method 200.7. ⁴
Inductively coupled plasma					
Or colorimetric (Heptoxime)		321B			
38. Nitrate (as N), mg/L: Bismite sulfate, or	352.1		D082-71		P. 554. ⁹
Nitrate-nitrite N minus Nitrite N	See parameters 39 and 40.	See parameters 39 and 40.	See parameters 39 and 40.	See parameters 39 and 40.	P. 28. ⁹
39. Nitrate-nitrite (as N), mg/L: Cadmium reduction, manual	353.3	418C	D0867-79(B)		
Or automated; or	353.2	418F	D0867-79(A)	I-4545-78	
Automated hydrazine	353.1				
40. Nitrite (as N), mg/L: Spectrophotometric, manual or	354.1	419	D1254-67	I-4540-78	18.
Automated (Diazotization)					
41. Oil and grease—Total recoverable, mg/L: Gravimetric (extraction)	413.1	503A			
42. Organic carbon—Total (TOC), mg/L: Combustion or oxidation	415.1	505	D2579-78(A) or D2579-78(B)		P. 551. ⁹ and P. 4. ¹⁰
43. Organic nitrogen (as N), mg/L: Total Kjeldahl N minus ammonia N	See parameters 31 and 4	420A	D3580-77 minus D1428-78(A)	See parameters 31 and 4	PP. 552-53. ⁹
44. Orthophosphate (as P), mg/L: Ascorbic acid method, automated	365.1	424G		I-4801-78	P. 561. ⁹
Or manual single reagent or	365.2	424F	D515-78(A)		
Manual two reagent	365.3				
45. Osmium—Total ² , mg/L: Digestion ³ followed by: AA direct aspiration, or	252.1	303C			
AA furnace	252.2	304			
46. Oxygen, dissolved, mg/L: Winkler (Azide modification)	360.2	421B	D1589-80(A)	I-1575-78	P. 550. ⁹
Or electrode	360.1	421F		I-1576-78	
47. Palladium—Total ² , mg/L: Digestion ³ followed by: AA direct aspiration	253.1				P. 527. ¹⁰
Or AA furnace	253.2				P. 528. ¹⁰
48. Phenols, mg/L: Manual distillation	420.1		D1783-70 (A or B)		26.
Followed by manual	420.1				26.
Or automated ¹² colorimetric (4AAP)	420.2				21.
49. Phosphorus (elemental), mg/L: Gas-liquid chromatography					

TABLE IB.—LIST OF APPROVED INORGANIC TEST PROCEDURES—Continued

Parameter, units, and method	Reference (method No. or page)				
	EPA 1979	Standard methods 15th Ed.	ASTM	USGS ¹	Other
50. Phosphorus—Total, mg/L Persulfate digestion Followed by manual or Automated ascorbic acid Reduction or semi-automated block digester	365.2 365.2 or 365.3 365.1 365.4	424C (M) 424F 424G	D515-78(A)	I-4800-78 I-4803-78	P. 561. ²
51. Platinum—Total ³ , mg/L Digestion ² followed by: AA direct aspiration Or AA furnace	255.1 255.2	303A 304			
52. Potassium—Total ³ , mg/L Digestion ² followed by: Atomic absorption Inductively coupled plasma Or flame photometric	258.1 322B	303A 304	D1428-64(A)	I-3630-78	P. 560. ² Method 200.7. ⁴
53. Residue—total, mg/L Gravimetric, 103-105°C	160.3	209A		I-3750-78	
54. Residue—filterable, mg/L Gravimetric, 180°C	160.1	209B		I-1750-78	
55. Residue—nonfilterable, (TSS), mg/L Gravimetric, 103-105°C post washing of residue	160.2	209D		I-3785-78	
56. Residue—settlesable, mg/L Volumetric (Imhoff cone) or gravimetric	160.5	209F			
57. Residue—volatile, mg/L Gravimetric, 550°C	160.4	209E		I-3753-78	
58. Rhodium—Total ³ , mg/L Digestion ² followed by: AA direct aspiration Or AA furnace	265.1 267.2	303A 304			
59. Ruthenium—Total ³ , mg/L Digestion ² followed by: AA direct aspiration Or AA furnace	267.1 267.2	303A 304			
60. Selenium—Total ³ mg/L Digestion ² followed by: AA furnace Inductively coupled plasma Or hydride	270.2 270.3	304 303E	D3859-78	I-3667-78	Method 200.7. ⁴
61. Silica—Dissolved, mg/L 0.45 micron filtration: Followed by manual or Automated colorimetric (Molybdo-silicate), or Inductively coupled plasma	370.1	425C	D659-68(B)	I-1700-78 I-2700-78	Method 200.7. ⁴
62. Silver—Total ³ mg/L Digestion ² followed by: AA direct aspiration AA furnace, or Inductively coupled plasma	272.1 272.1	303A or 303B 304		I-3720-78	P. 557. ² and p. 37. ² Method 200.7. ⁴
63. Sodium—Total ³ , mg/L Digestion ² followed by: Atomic absorption Inductively coupled plasma Or flame photometric	273.1	303A	D1428-64(A) D1125-77(A)	I-3735-78	P. 561. ² Method 200.7. ⁴
64. Specific conductance, mhos/cm Wheatstone bridge	120.1	205		I-1780-78	P. 547. ²
65. Sulfate (as SO ₄), mg/L: Automated methylthymol blue Gravimetric, or Turbidimetric	375.2 375.3 375.4	426A or 426B 426C	D516-68(A) D516-68(B)	I-2822-78	PP. 562-63. ²
66. Sulfide (as S), mg/L: Titrimetric (iodine) or Colorimetric (methylene blue)	376.1 376.2	427D 427C		I-3640-78	
67. Sulfite (as SO ₃), mg/L Titrimetric (iodine iodate)	377.1	428F	D1339-78(C)		
68. Surface tension, mg/L Colorimetric (methylene blue)	425.1	512A	D2330-68(A)		
69. Temperature, °C Thermometric	170.1	212			(??)
70. Thallium—Total ³ mg/L Digestion ² followed by: AA direct aspiration AA furnace, or Inductively coupled plasma	279.1 279.2	303A 304			Method 200.7. ⁴
71. Tin—Total ³ mg/L Digestion ² followed by: AA direct aspiration or AA furnace	282.1 282.2	303A 304		I-3850-78	
72. Titanium—Total ³ mg/L Digestion ² followed by: AA direct aspiration or AA furnace	283.1 283.2	303C 304			
73. Turbidity, NTU Nephelometric	180.1	214A	D1889-71	I-3860-78	
74. Vanadium—Total ³ mg/L Digestion ² followed by: AA direct aspiration AA furnace Inductively coupled plasma Or colorimetric (Gallate acid)	286.1 286.2 D3373-75	303C 304 D3373-75			Method 200.7. ⁴
75. Zinc—Total ³ mg/L Digestion ² followed by: AA direct aspiration AA furnace Inductively coupled plasma Or colorimetric (Zincon)	289.1 289.2 D1691-77(D) D1691-77(C)	303A or 303B 304 D1691-77(D) D1691-77(C)		I-3900-78	P. 557. ² P. 37. ² Method 200.7. ⁴ 20.

Table IB Notes

¹ "Methods for Analysis of Inorganic Substances in Water and Fluvial Sediments," U.S. Department of the Interior, U.S. Geological Survey, Open-File Report 78-678, or "Methods for Determination of Inorganic Substances in Water and Fluvial Sediments," NW Skougstad, et al, U.S. Geological Survey, Techniques of Water-Resources Investigation, Book 5, Chapter A1, 1979.

² "Official Methods of Analysis of the Association of Official Analytical Chemists" methods manual, 13th ed. (1980)

³ For the determination of total metals the sample is not filtered before processing. A digestion procedure is required to solubilize suspended material and to destroy possible organic-metal complexes. Two digestion procedures are given in "Methods for Chemical Analysis of Water and Wastes, 1979." One (§ 4.1.3), is a vigorous digestion using nitric acid. A less vigorous digestion using nitric and hydrochloric acid (§ 4.1.4) is preferred, however, the analyst should be cautioned that this mild digestion may not suffice for all sample types. Particularly, if a colorimetric procedure is to be employed, it is necessary to ensure that all organo-metallic bonds be broken so that the metal is in a reactive state. In those situations, the vigorous digestion is to be preferred making certain that at no time does the sample go to dryness. Samples containing large amounts of organic materials would also benefit by this vigorous digestion. Use of the graphite furnace technique, inductively coupled plasma, as well as determinations for certain elements such as arsenic, the noble metals, mercury, selenium, and tellurium require a modified digestion and in all cases the method write-up should be consulted for specific instructions and/or cautions.

Note: If the digestion procedure for direct aspiration or graphite furnace atomic absorption analysis included in one of the other approved references is different than the above, the EPA procedure must be used.

Dissolved metals are defined as those constituents which will pass through a 0.45 micron membrane filter. Following filtration of the sample, the referenced procedure for total metals must be followed. Sample digestion of the filtrate for dissolved metals, or digestion of the original sample solution for total metals may be omitted for AA (direct aspiration or graphite furnace) and ICP analyses provided the sample has a low COD and the filtrate meets the following criteria:

- (a) is visibly transparent
- (b) has no perceptible odor, and
- (c) is free of particulate or suspended matter following acidification.

* The full text of Method 200.7, "Inductively Coupled Plasma Atomic Emission Spectrometric Method for Trace Element Analysis of Water and Wastes," is given at Appendix C of this Part 136.

* Manual distillation is not required if comparability data on representative effluent samples are on company file to show that the preliminary distillation step is not necessary; however, manual distillation will be required to resolve any controversies.

* Anonymous, Automated Electrode Method, Industrial Method Number 379-75WE, dated February 19, 1976, Technicon AutoAnalyzer II, Technicon Industrial Systems, Tarrytown, New York 10591.

* Carbonaceous biochemical oxygen demand (CBOD₅) must not be confused with the traditional BOD₅ test which measures "total BOD". The addition of the nitrification inhibitor is not a procedural option, but must be included to report the CBOD₅ parameter. A disclaimer whose permit requires reporting the traditional BOD₅ may not use a nitrification inhibitor in the procedure for reporting the results. Only when a disclaimer's permit specifically states CBOD₅ is required can the permittee report data obtained using the nitrification inhibitor.

* American National Standard on Photographic Processing Effluents, Apr. 2, 1975. Available from ANSI, 1430 Broadway, New York, NY 10018.

* The use of normal and differential pulse voltage ramps to increase sensitivity and resolution is acceptable.

* Chemical Oxygen Demand, Method 8000, Hach Handbook of Water Analysis, 1979, Hach Chemical Company, P.O. Box 389, Loveland, Colorado 80537.

* COD Method, Oceanography International Corporation, 512 West Loop, P.O. Box 2960, College Station, Texas 77840.

* The back titration method will be used to resolve controversy.

* National Council of the Paper Industry for Air and Stream Improvement, Inc., Technical Bulletin 253, December 1971.

* Copper, Bismuthomale Method, Method 8508, Hach Handbook of Water Analysis, 1979, Hach Chemical Company, P.O. Box 389, Loveland, Colorado 80537.

* After the manual distillation is completed, the auto-analyzer manifolds in EPA Methods 335.03 (Cyanide) or 420.2 (phenols) are emptied by connecting the re-sample line directly to the sampler. When using the manifold setup shown in Method 335, the buffer 6.2 should be replaced with the buffer 7.6 found in Method 335.2.

* Hydrogen ion (pH) Automated Electrode Method, Industrial Method Number 378-75WA, October 1976, Technicon AutoAnalyzer II, Technicon Industrial Systems, Tarrytown, New York 10591.

* Iron, 1,10-Phenanthroline Method, Method 8008, 1980, Hach Chemical Company, P.O. Box 389, Loveland, Colorado 80537.

* Manganese, Periodate Oxidation Method, Method 8034, Hach Handbook of Wastewater Analysis, 1979, pages 2-113 and 2-117, Hach Chemical Company, Loveland, Colorado 80537.

* Nitrogen, Nitrite, Method 8507, Hach Chemical Company, P.O. Box 389, Loveland, Colorado 80537.

* Goertzel, D., Brown, E., "Methods for Analysis of Organic Substances in Water," U.S. Geological Survey, Techniques of Water-Resources Investigations, Book 5, Chapter A3, p.4 (1972).

* R.F. Addison and R.G. Ackman, "Direct Determination of Elemental Phosphorus by Gas-Liquid Chromatography," Journal of Chromatography, Vol. 47, No. 3, pp. 421-426, 1970.

* Recommended methods for the analysis of silver in industrial wastewaters at concentrations of 1 mg/L and above are inadequate where silver exists as an inorganic halide. Silver halides such as the bromide and chloride are relatively insoluble in reagents such as nitric acid but are readily soluble in an aqueous buffer of sodium thiosulfate and sodium hydroxide to a pH of 12. Therefore, for levels of silver above 1 mg/L, 20 mL of sample should be diluted to 100 mL by adding 40 mL each of 2 M Na₂S₂O₃ and 2M NaOH. Standards should be prepared in the same manner. For levels of silver below 1 mg/L, the recommended method is satisfactory.

* Stevens, K.H., Ficks, J.F., and Smoot, G.F., "Water Temperature-Influential Factors, Field Measurement and Data Presentation," U.S. Geological Survey, Techniques of Water-Resources Investigations, Book 1, Chapter D1, 1975.

* Zinc, Zincon Method, Method 8009, Hach Handbook of Water Analysis, 1979, pages 2-231 and 2-333, Hach Chemical Company, Loveland, Colorado 80537.

* "Selected Analytical Methods Approved and Cited by the United States Environmental Protection Agency," Supplement to the Fifteenth Edition of Standard Methods for the Examination of Water and Wastewater (1981).

* The approved method is that cited in Standard Methods for the Examination of Water and Wastewater, 14th Edition. The colorimetric reaction is conducted at a pH of 10.0 ± 0.2. The approved methods are given on pp. 576-61 of the 14th Edition: Method 510A for distillation, Method 510B for the manual colorimetric procedure, or Method 510C for the manual spectrophotometric procedure.

* ORION Research Instruction Manual, Residual Chlorine Electrode Model 97-70, 1977, Orion Research Incorporated, 840 Memorial Drive, Cambridge, Massachusetts 02138.

TABLE IC.—LIST OF APPROVED TEST PROCEDURES FOR NON-PESTICIDE ORGANIC COMPOUNDS

Parameter ¹	EPA Method Number ^{2, 3}			Other
	GC	GC/MS	HPLC	
1. Acenaphthene	610	625, 1625	610	
2. Acenaphthylene	610	625, 1625	610	
3. Acroline	603	*624, 1624		
4. Acrylonitrile	603	*624, 1624		
5. Anthracene	610	625, 1625	610	
6. Benzene	602	624, 1624		
7. Benzidine		*625, 1625	605	Note 3, p. 1;
8. Benzol(a)anthracene	610	625, 1625	610	
9. Benzol(b)pyrene	610	625, 1625	610	
10. Benzol(b)fluoranthene	610	625, 1625	610	
11. Benzol(g)hapyrene	610	625, 1625	610	
12. Benzol(j)fluoranthene	610	625, 1625	610	
13. Benzyl Chloride				Note 3, p. 130; Note 6, p. 5102.
14. Benzyl Butyl Phthalate	606	625, 1625		
15. Bis(2-chloroethoxy) methane	611	625, 1625		
16. Bis(2-chloroethyl) ether	611	625, 1625		
17. Bis(2-ethylhexyl) phthalate	606	625, 1625		
18. Bromodichloromethane	601	624, 1624		
19. Bromoform	601	624, 1624		
20. Bromomethane	601	624, 1624		
21. 4-Bromophenylphenyl ether	611	625, 1625		
22. Carbon tetrachloride	601	624, 1624		Note 3, p. 130;
23. 4-Chloro-3-methylphenol	604	625, 1625		
24. Chlorobenzene	601, 602	624, 1624		Note 3, p. 130;
25. Chlorobenzene	601	624, 1624		
26. 2-Chlorobutyl vinyl ether	601	624, 1624		
27. Chloroform	601	624, 1624		Note 3, p. 130;
28. Chloromethane	601	624, 1624		
29. 2-Chlorophthalene	612	625, 1625		
30. 2-Chlorophenol	604	625, 1625		
31. 4-Chlorophenylphenyl ether	611	625, 1625		
32. Chrysene	610	625, 1625	610	
33. Dibenzol(a,h)anthracene	610	625, 1625	610	
34. Dibromodichloromethane	601	624, 1624		
35. 1,2-Dichlorobenzene	601, 602, 612	624, 625, 1625		
36. 1,3-Dichlorobenzene	601, 602, 612	624, 625, 1625		
37. 1,4-Dichlorobenzene	601, 602, 612	625, 1624, 1625		
38. 3,3'-Dichlorobenzidine		625, 1625	605	
39. Dichlorodifluoromethane	601			
40. 1,1-Dichloroethane	601	624, 1624		
41. 1,2-Dichloroethane	601	624, 1624		
42. 1,1-Dichloroethene	601	624, 1624		
43. trans-1,2-Dichloroethene	601	624, 1624		
44. 2,4-Dichlorophenol	604	625, 1625		
45. 1,2-Dichloropropene	601	624, 1624		
46. cis-1,3-Dichloropropene	601	624, 1624		
47. trans-1,3-Dichloropropene	601	624, 1624		
48. Diethyl phthalate	606	625, 1625		

TABLE IC.—LIST OF APPROVED TEST PROCEDURES FOR NON-PESTICIDE ORGANIC COMPOUNDS—Continued

Parameter ¹	EPA Method Number ^{1,2}			Other
	GC	GC/MS	HPLC	
49. 2,4-Dimethylphenol	604	625, 1625		
50. Dimethyl phthalate	606	625, 1625		
51. Di-n-butyl phthalate	606	625, 1625		
52. Di-n-octyl phthalate	606	625, 1625		
53. 2,4-Dinitrophenol	604	625, 1625		
54. 2,4-Dinitrotoluene	606	625, 1625		
55. 2,6-Dinitrotoluene	606	625, 1625		
56. Epichlorohydrin				Note 3, p. 130; Note 6, p. S102.
57. Ethylbenzene	602	624, 1624		
58. Fluorobenzene	610	625, 1625	610	
59. Fluorene	610	625, 1625	610	
60. Hexachlorobenzene	612	625, 1625		
61. Hexachlorobutadiene	612	625, 1625		
62. Hexachlorocyclopentadiene	612	625, 1625		
63. Hexachloroethane	612	625, 1625		
64. Isod(1,2,3-cd)pyrene	610	625, 1625	610	
65. Isophorone	609	625, 1625		
66. Methylene Chloride	601	624, 1624		Note 3, p. 130;
67. 2-Methyl-4,6-Dinitrophenol	604	625, 1625		
68. Naphthalene	610	625, 1625		
69. Nitrobenzene	609	625, 1625		
70. 2-Nitrophenol	604	625, 1625		
71. 4-Nitrophenol	604	625, 1625		
72. N-Nitrosodimethylamine	607	625, 1625		
73. N-Nitroso-n-propylamine	607	625, 1625		
74. N-Nitrosodiphenylamine	607	625, 1625		
75. 2,2-dinitro(1-chloropropene)	611	625, 1625		
76. PCB-1016	608		625,	Note 3, p. 43;
77. PCB-1221	608		625,	Note 3, p. 43;
78. PCB-1232	608		625,	Note 3, p. 43;
79. PCB-1242	608		625,	Note 3, p. 43;
80. PCB-1248	608		625,	Note 3, p. 43;
81. PCB-1254	608		625,	Note 3, p. 43;
82. PCB-1280	608		625,	Note 3, p. 43;
83. Pentachlorophenol	604	625, 1625		Note 3, p. 140;
84. Phenanthrene	610	625, 1625	610	
85. Phenol	604	625, 1625		
86. Pyrene	610	625, 1625	610	
87. 2,3,7,8-Tetrachlorodibenzo-p-dioxin		613		
88. 1,1,2,2-Tetrachloroethane	601	624, 1624		Note 3, p. 130;
89. Tetrachloroethane	601	624, 1624		Note 3, p. 130;
90. Toluene	602	624, 1624		
91. 1,2,4-Trichlorobenzene	612	625, 1625		Note 3, p. 130;
92. 1,1,1-Trichloroethane	601	624, 1624		
93. 1,1,2-Trichloroethane	601	624, 1624		Note 3, p. 130;
94. Trichlorobenzene	601	624, 1624		
95. Trichlorofluoromethane	601	624,		
96. 2,4,6-Trichlorophenol	604	625, 1625		
97. Vinyl Chloride	601	624, 1624		

Table IC Notes

¹All parameters are expressed in micrograms per liter (µg/L).²The full text of Methods 601-613, 624, 625, 1624, and 1625, are given at Appendix A, "Test Procedures for Analysis of Organic Pollutants," of the Part 136. The standardized test procedure to be used to determine the method detection limit (MDL) for these test procedures is given at Appendix B, "Definition and Procedure for the Determination of the Method Detection Limit," of the Part 136.³Methods for Benzidine: Chlorinated Organic Compounds, Pentachlorophenol and Pesticides in Water and Wastewater," U.S. Environmental Protection Agency, September, 1978. Method 624 may be extended to screen samples for Acroline and Acrylonitrile. However, when they are known to be present, the preferred method for these two compounds is Method 603 or Method 1624.⁴Method 625 may be extended to include benzidine, hexachlorocyclopentadiene, N-nitrosodimethylamine, and N-nitrosodiphenylamine. However, when they are known to be present, Methods 605, 607, and 612, or Method 1625, are preferred methods for these compounds.⁵625, Screening only.⁶"Selected Analytical Methods Approved and Cited by the United States Environmental Protection Agency," Supplement to the Fifth Edition of Standard Methods for the Examination of Water and Wastewater (1981).⁷Each analyst must make an initial, one-time, demonstration of their ability to generate acceptable precision and accuracy with Methods 601-613, 624, 625, 1624, and 1625 (See Appendix A of this Part 136) in accordance with procedures each in section 8.2 of each of these Methods. Additionally, each laboratory, on an on-going basis must spike and analyze 10% (5% for Methods 624 and 625 and 100% for methods 1624, and 1625) of all samples to monitor and evaluate laboratory data quality in accordance with sections 8.3 and 8.4 of these Methods. When the recovery of any parameter falls outside the warning limits, the analytical results for that parameter in the unspiked sample are suspect and cannot be reported to demonstrate regulatory compliance.

Notes.—These warning limits are promulgated as an "interim final action with a request for comments."

TABLE ID.—LIST OF APPROVED TEST PROCEDURES FOR PESTICIDES¹

Parameter µg/L	Method	EPA ^{1,2}	Standard Methods 15th Ed	ASTM	Other
1. Aldrin	GC	608	508A	D3086	Note 3, p. 7; Note 4, p. 30.
	GC/MS	625			
2. Atrazine	GC				Note 3, p. 83; Note 6, p. S88.
3. Amiocarb	TLC				Note 3, p. 94; Note 6, p. S16.
4. Atraton	GC				Note 3, p. 83; Note 6, p. S88.
5. Atrazine	GC				Note 3, p. 83; Note 6, p. S88.
6. Azinphos methyl	GC				Note 3, p. 25; Note 6, p. S51.
7. Barban	TLC				Note 3, p. 104; Note 6, p. S84.
8. α-BHC	GC	608	508A	D3086	Note 3, p. 7
	GC/MS	625			
9. β-BHC	GC	608		D3086	
	GC/MS	625			
10. δ-BHC	GC	608		D3086	

TABLE ID.—LIST OF APPROVED TEST PROCEDURES FOR PESTICIDES¹—Continued

Parameter µg/L	Method	EPA ²	Standard Methods 15th Ed	ASTM	Other
11. γ -BHC (Lindane)	GC/MS GC GC/MS	625 608 625	509A	D3086	Note 3, p. 7; Note 4, p. 30.
12. Captan	GC		509A		Note 3, p. 7.
13. Carbaryl	TLC				Note 3, p. 84; Note 6, p. S60.
14. Carbophenothion	GC				Note 4, p. 30; Note 6, p. S73.
15. Chlorobenzene	GC GC/MS	608 625	509A	D3086	Note 3, p. 7.
16. Chlorobromophen	TLC				Note 3, p. 104; Note 6, p. S64.
17. 2,4-D	GC		509B		Note 3, p. 115; Note 4, p. 35.
18. 4,4'-DDD	GC GC/MS	608 625	509A	D3086	Note 3, p. 7; Note 4, p. 30.
19. 4,4'-DDE	GC GC/MS	608 625	509A	D3086	Note 3, p. 7; Note 4, p. 30.
20. 4,4'-DDT	GC GC/MS	608 625	509A	D3086	Note 3, p. 7; Note 4, p. 30.
21. Dactacon-O	GC				Note 3, p. 25; Note 6, p. S51.
22. Dactacon-S	GC				Note 3, p. 25; Note 6, p. S51.
23. Dactacon	GC				Note 3, p. 25; Note 4, p. 30; Note 6, p. S51.
24. Dactacon	(X)				Note 3, p. 115.
25. Dactaconthion	GC				Note 4, p. 30; Note 6, p. S73.
26. Dactacon	GC		509A		Note 3, p. 7.
27. Dactacon	GC			D3086	
28. Dactacon	GC GC/MS	608 625	509A		Note 3, p. 7; Note 4, p. 30.
29. Dactacon	GC				Note 4, p. 30; Note 6, p. S73.
30. Dactacon	GC				Note 3, p. 25; Note 6, p. S51.
31. Dactacon	TLC				Note 3, p. 104; Note 6, p. S64.
32. Endosulfan I	GC GC/MS	608 625	509A	D3086	Note 3, p. 7.
33. Endosulfan II	GC GC/MS	608 625	509A	D3086	Note 3, p. 7.
34. Endosulfan sulfate	GC GC/MS	608 625			
35. Endrin	GC GC/MS	608 625	509A	D3086	Note 3, p. 7; Note 4, p. 30.
36. Endrin aldehyde	GC GC/MS	608 625			
37. Ethion	GC				Note 4, p. 30; Note 6, p. S73.
38. Fenitrothion	TLC				Note 3, p. 104; Note 6, p. S64.
39. Fenitrothion-TCA	TLC				Note 3, p. 104; Note 6, p. S64.
40. Heptachlor	GC GC/MS	608 625	509A	D3086	Note 3, p. 7; Note 4, p. 30.
41. Heptachlor epoxide	GC	608	509A	D3086	Note 3, p. 7; Note 4, p. 30; Note 6, p. S73.
42. Isodrin	GC/MS	625			
43. Lurex	GC				Note 4, p. 30; Note 6, p. S73.
44. Malathion	TLC GC			509A	Note 3, p. 104; Note 6, p. S64.
45. Malathion	GC				Note 3, p. 25; Note 4, p. 30; Note 6, p. S51.
46. Methacarb	TLC				Note 3, p. 84; Note 6, p. S60.
47. Methachlor	GC			509A	Note 3, p. 7; Note 4, p. 30.
48. Methachlor	TLC				Note 3, p. 84; Note 6, p. S60.
49. Mirex	GC			509A	Note 3, p. 7.
50. Monuron	TLC				Note 3, p. 104; Note 6, p. S64.
51. Monuron-TCA	TLC				Note 3, p. 104; Note 6, p. S64.
52. Naloxone	TLC				Note 3, p. 104; Note 6, p. S64.
53. Parathion methyl	GC		509A		Note 3, p. 25; Note 4, p. 30.
54. Parathion ethyl	GC		509A		Note 3, p. 25.
55. PCNB	GC		509A		Note 3, p. 7.
56. Permethrin	GC			D3086	
57. Permethrin	GC				Note 3, p. 83; Note 6, p. S68.
58. Propazine	GC				Note 3, p. 83; Note 6, p. S68.
59. Propazine	GC				Note 3, p. 83; Note 6, p. S68.
60. Propazine	TLC				Note 3, p. 104; Note 6, p. S64.
61. Sebacic acid	TLC				Note 3, p. 83; Note 6, p. S68.
62. Sebacic acid	TLC				Note 3, p. 104; Note 6, p. S64.
63. Sebacic acid	GC				Note 3, p. 83; Note 6, p. S68.
64. Sebacic acid	GC		509A		Note 3, p. 7.
65. Sebacic acid	TLC				Note 3, p. 104; Note 6, p. S64.
66. 2,4,5-T	GC		509B		Note 3, p. 115; Note 4, p. 35.
67. 2,4,5-TP (Salves)	GC		509B		Note 3, p. 115.
68. Terbufosazine	GC				Note 3, p. 83; Note 6, p. S68.
69. Terbufosazine	GC	608	509A	D3086	Note 3, p. 7; Note 4, p. 30.
70. Terbufosazine	GC/MS GC	625	509A		Note 3, p. 7.

Table ID Notes

- ¹ Pesticides are listed in this table by common name for the convenience of the reader. Additional pesticides may be found under Table IC, where entries are listed by chemical name.
- ² The full text of methods 608 and 625 are given at Appendix A, "Test Procedures for Analysis of Organic Pollutants," of this Part 136. The standardized test procedure to be used to determine the method detection limit (MDL) for these test procedures is given at Appendix B, "Definition and Procedure for the Determination of the Method Detection Limit," of this Part 136.
- ³ "Methods for Benzidine, Chlorinated Organic Compounds, Pentachlorophenol and Pesticides in Water and Wastewater," U.S. Environmental Protection Agency, September, 1978. This EPA publication includes thin-layer chromatography (TLC) methods.
- ⁴ "Methods for Analysis of Organic Substances in Water," U.S. Geological Survey, Techniques of Water-Resources Investigations, Book 5, Chapter A3 (1972).
- ⁵ This method may be extended to include α -BHC, β -BHC, endosulfan I, endosulfan II, and endrin. However, when they are known to exist, Method 608 is the preferred method.
- ⁶ "Selected Analytical Methods Approved and Cited by the United States Environmental Protection Agency," Supplement to the Fifteenth Edition of *Standard Methods for the Examination of Water and Wastewater* (1981).
- ⁷ Each analyst must make an initial, one-time, demonstration of their ability to generate acceptable precision and accuracy with Methods 608 and 625 (See Appendix A of this Part 136) in accordance with procedures given in Section 8.2 of each of these methods. Additionally, each laboratory, on an on-going basis, must spike and analyze 10% of all samples analyzed with

Method 608 or 5% of all samples analyzed with Method 625 to monitor and evaluate laboratory data quality in accordance with Sections 8.3 and 8.4 of these methods. When the recovery of any parameter falls outside the warning limits, the analytical results for that parameter in the unspliked sample are suspect and cannot be reported to demonstrate regulatory compliance. Note.—These warning limits are promulgated as an "interim final action with a request for comments."

TABLE IE.—LIST OF APPROVED RADIOLOGICAL TEST PROCEDURES

Parameter and units	Methods	EPA ^a	Reference (method No. or page)		
			Standard Methods 15th Ed	ASTM	USGS ^b
1. Alpha-Total, pCi per liter	Proportional or scintillation counter	900.0	703	D1943-66	pp. 75 and 78. ^c
2. Alpha-Counting error, pCi per liter	Proportional or scintillation counter	Appendix B	703	D1943-66	p. 79.
3. Alpha-Counting error, pCi per liter	Proportional counter	900.0	703	D1890-66	pp. 75 and 78. ^c
4. Beta-Counting error, pCi per liter	Proportional counter	Appendix B	703	D1890-66	p. 79.
5. (a) Radium-Total, pCi per liter	Proportional counter	903.0	705	D2460-66	
(b) "Ra, pCi per liter	Scintillation counter	903.1	706	D3454-79	p. 81.

Table IE Notes

- ^a "Prescribed Procedures for Measurement of Radioactivity in Drinking Water," EPA-600/4-80-032 (1980 update), U.S. Environmental Protection Agency, August 1980.
^b Fawcett, M.J. and Brown, Eugene, "Selected Methods of the U.S. Geological Survey of Analysis of Wastewater," U.S. Geological Survey, Open-File Report 76-177 (1978).
^c The method found on p. 75 measures only the dissolved portion while the method on p. 78 measures only the suspended portion. Therefore, the two results must be added to obtain the "total."

5. In § 136.3, paragraph (a) is revised to show that the full text of approved test procedures have been incorporated by reference, into the regulation to read as follows:

§ 136.3 Identification of test procedures.

(a) Parameters or pollutants, for which methods are approved, are listed together with test procedure descriptions and references in Tables IA, IB, IC, ID, and IE. The full text of the referenced test procedures are incorporated by reference into Tables IA, IB, IC, ID, and IE. The references and the sources from which they are available are given in paragraph (b) of this section. These test procedures are incorporated as they exist on the day of approval and a notice of any change in these test procedures will be published

in the Federal Register. The discharge parameter values for which reports are required must be determined by one of the standard analytical test procedures incorporated by reference and described in Tables IA, IB, IC, ID, and IE, or by any alternate test procedure which has been approved by the Administrator under the provisions of paragraph (d) of this section and sections 136.4 and 136.5 of this Part 136. Under certain circumstances (§§ 136.3 (b) or (c) or 40 CFR Part 401.13) other test procedures may be used that may be more advantageous when such other test procedures have been previously approved by the Regional Administrator of the Region in which the discharge will occur, and providing the Director of the State in which such discharge will occur

does not object to the use of such alternate test procedure.

6. In § 136.3, paragraphs (b) and (c) are redesignated as (c) and (d) and a new paragraph (b) is added to itemize the references which are "incorporated by reference" and to identify the sources from which they may be obtained. As added, the new paragraph (b) reads as follows:

§ 136.3 Identification of test procedures.

(b) The full texts of the methods from the following references which are cited in Tables IA, IB, IC, ID, and IE are incorporated by reference into this regulation and may be obtained from the sources identified. All costs cited are subject to change and must be verified from the indicated sources.

REFERENCES, SOURCES, AND COSTS

Table	Parameters	Reference, source and cost
IA—EPA	1-5	"Microbiological Methods for Monitoring the Environment, Water and Wastes," United States Environmental Protection Agency, EPA-600/8-78-017, 1978. Available from: ORD Publications, CERL, U.S. Environmental Protection Agency, Cincinnati, Ohio 45268.
IA—Standard Methods	1-5	
IB—Standard Methods	1-10, 12-46, 50-75	
IC—Standard Methods	1, 8, 11, 12, 15, 17-20, 26, 28, 32, 33, 35, 40, 41, 44, 46, 48, 52-54, 64, 66, 67, 69, 70	Standard Methods for the Examination of Water and Wastewater, Joint Editorial Board, American Public Health Association, American Water Works Association, and Water Pollution Control Federation 15th Edition, 1981. Available from: American Public Health Association, 1015 Fifteenth Street, N.W., Washington, D.C. 20036. Cost: \$50.00 including the Supplement to the Fifteenth Edition.
IE—Standard Methods	1-5	Ibid, 14th Edition.
IB—Standard Methods	48	
IB—Other (Standard Methods Supplement)	11, 47	
IC—Other (Standard Methods Supplement)	13, 56	"Selected Analytical Methods approved and Cited by the United States Environmental Protection Agency," Supplement to the 15th Edition of Standard Methods for the Examination of Water and Wastewater (1981). Available from: American Public Health Association, 1015 Fifteenth Street, N.W., Washington, D.C. 20036. Cost: Included with the 15th Edition of Standard Methods for the Examination of Water and Wastewater.
ID—Other (Standard Methods Supplement)	2-7, 13, 14, 16, 21-23, 25, 29-31, 37, 38, 39, 41-45, 47, 49, 50, 51, 56-63, 65, 68	"Methods for Collection and Analysis of Aquatic Biological and Microbiological Samples," edited by P.E. Gieson, T.A. Ehler, G.A. Ivner, B.W. Lum, and K.V. Slack. U.S. Geological Survey, Techniques of Water-Resources Investigation (USGS TWRI), Book 5, Chapter A4 (1977). Revised edition, 332 pages. Available from: U.S. Geological Survey, Branch of Distribution, 1200 South Eads Street, Arlington, VA 22202. (Authorized agent of the Superintendent of Documents, Government Printing Office.) Cost: \$9.25. Prices are subject to change.
IA—U.S. Geological Survey (USGS)	1, 3, 5	"Methods for Chemical Analysis of Water and Wastes," EPA-600/4-79-020. United States Environmental Protection Agency, March, 1979. Available from: ORD Publications, CERL, U.S. Environmental Protection Agency, Cincinnati, Ohio 45268.
IB—EPA	1-13, 15-48, 50-75	"Annual Book of Standards, Part 31, Water," American Society for Testing and Materials, 1980. Available from: American Society for Testing and Materials, 1916 Race Street, Philadelphia, PA 19103. Cost: available from publisher.
IB—ASTM	1, 2, 4, 6, 8, 11-13, 15-17, 19, 20, 22-25, 27, 28, 30-35, 37-40, 42-44, 46, 48, 50, 52, 60, 61, 63-65, 67, 68, 73-75	
—ASTM	1, 8-11, 15, 18-20, 27, 32, 33, 35, 40, 41, 46, 55, 69	
—ASTM	1-5	

REFERENCES, SOURCES, AND COSTS—Continued

Table	Parameters	Reference, source and cost
IS-USGS	2, 3, 4, 6-13, 15, 16, 18-23, 25, 27, 28, 30-40, 43, 44, 46, 50, 52-55, 57, 60-66, 71, 73, 75.	"Methods for determination of inorganic substances in water and fluvial sediments," NW Saugstad and others, editors USGS-TWRI Book 5, Chapter A1, 1979. \$10.00 Available from U.S. Geological Survey, Branch of Distribution, 1200 South Eads Street, Arlington, VA 22202 (Authorized agent of the Superintendent of Documents, Government Printing Office). Prices are subject to change.
IS-Other (ADAC)	2, 4, 9, 12, 15, 16, 19, 22, 30-35, 38, 42-44, 46, 50, 52, 62-65, 75.	Official Methods of Analysis of the Association of Official Analytical Chemists, methods manual, 13th Edition (1980). Price: \$78.00. Available from: The Association of Official Analytical Chemists, 1111 N. 19th St., Suite 218, Arlington, VA 22209.
IS-Other (ANSI)	9, 12, 15, 20, 22, 23, 36, 62, 75.	"American National Standard on Photographic Processing Effluents," April 2, 1975. Available from American National Standards Institute, 1430 Broadway, New York, New York 10018.
IS-Other (EPA)	3, 5-8, 10, 12, 13, 19, 20, 22, 27, 30, 32-34, 36, 37, 42, 60, 63, 70, 74, 75.	The full text of the inductively coupled plasma optical emission spectroscopic test procedure, Method 200.7, is printed in Appendix C of this Part 136.
IS-Other	21	"An investigation of improved procedures for measurement of Mill Effluent and Flowing Water (Lake Michigan) (Technical Bulletin No. 267, November, 1971). Available from National Council of the Paper Industry for Air and Waste Improvements, Inc., 781 Madison Avenue, East available from publication.
IS-Other	4	Ammonia, Automated Electrode Method, Industrial Method Number 378-75WE, dated February 19 1976, Technicon AutoAnalyzer II Method and price available from Technicon Industrial Systems, Tarrytown, New York 10591.
IS-Other	15	Chemical Oxygen Demand, Method 8000, Hach Handbook of Water Analysis, 1979 Method and price available from Hach Chemical Company, P.O. Box 389, Loveland, Colorado 80537.
IS-Other	15	OIC Chemical Oxygen Demand Method Method and price available from Oceanography International Corporation, 512 West Loop, P.O. Box 2980, College Station, Texas 77840.
IS-Other	17	ORION Research Instruction Manual, Residual Chlorine Electrode Model 97-78, 1977. Method and price available from Orion Research Incorporated, 840 Memorial Drive, Cambridge, Massachusetts 02138.
IS-Other	22	Biochlorinate Method for Copper, Method 8506, Hach Handbook of Water Analysis, 1979 Method and price available from Hach Chemical Company, P.O. Box 389, Loveland, Colorado 80537.
IS-Other	28	Hydrogen Ion (pH) Automated Electrode Method, Industrial Method Number 378-75WA, October 1976, Technicon AutoAnalyzer II Method and Price available from Technicon Industrial Systems, Tarrytown, New York 10591.
IS-Other	30	1, 10-Phenanthroline Method for Iron, Hach Method 8006 Method and price available from Hach Chemical Company, P.O. Box 389, Loveland, Colorado 80537.
IS-Other	34	Pentodate Oxidation Method for Manganese, Method 8004, Hach Handbook for Water Analysis, 1979 Method and Price available from Hach Chemical Company, P.O. Box 389, Loveland, Colorado 80537.
IS-Other	40	Nitrite Nitrogen, Hach Method 8507, Method and price available from Hach Chemical Company, P.O. Box 389, Loveland, Colorado 80537.
IS-Other	75	Zinc Method for Zinc, Method 8009, Hach Handbook for Water Analysis, 1979, Method and price available from Hach Chemical Company, P.O. Box 389, Loveland, Colorado 80537.
IS-Other	49	"Direct Determination of Elemental Phosphorus by Gas-Liquid Chromatography," by R.F. Addison and R.G. Achman, Journal of Chromatography, Volume 47, No. 3, pp. 421-426, 1970 Available in most public libraries. Back volumes of the Journal of Chromatography are available from Elsevier/North-Holland, Inc., Journal Information Centre, 52 Vanderbilt Avenue, New York, NY 10164. Cost available from publisher.
IS-Other (USGS)	69	"Water temperature-influential factors, field measurement, and data presentation," by H.H. Stevens, Jr., J. Ficks, and G.F. Smoot: USGS-TWRI Book 1, Chapter D1, 1975. 65 pages, \$1.60. Available from U.S. Geological Survey, Branch of Distribution, 1200 South Eads Street, Arlington, VA 22202. Prices are subject to change.
IS-Other (USGS)	42	"Methods for analysis of organic substances in water," by D. F. Goertitz and Eugene Brown: USGS-TWRI Book 5, Chapter A3, 1972, 40 pages, \$99. Available from U.S. Geological Survey, Branch of Distribution, 1200 South Eads Street, Arlington, VA 22202. Prices are subject to change.
ID-Other (USGS)	1, 11, 14, 17-20, 23, 25, 28, 29, 35, 37, 40-42, 44, 46, 52, 66, 69	The full texts of Methods 601-613, 624, 625, 1624, and 1625 are printed in appendix A of this Part 136. The full text for determining the method detection limit when using the test procedures is given in Appendix B of this Part 136.
IC-EPA	1-12, 14-55, 57-97	"Methods for Benzidine, Chlorinated Organic Compounds, Pentachlorophenol and Pesticides in Water and Wastewater," Environmental Monitoring and Support Laboratory, United States Environmental Protection Agency, Cincinnati, Ohio 1978. Available from ORD Publications, CERL, U.S. Environmental Protection Agency, Cincinnati, Ohio 45268.
ID-EPA	1, 8-11, 15, 18, 19, 20, 28, 32-36, 40, 41, 69	"Prescribed Procedures for Measurement of Radioactivity in Drinking Water," EPA-600/4-80-032 (1980 Update), United States Environmental Protection Agency, 1980. Available from ORD Publications, CERL, U.S. Environmental Protection Agency, Cincinnati, Ohio 45268.
IC-Other (EPA)	7, 13, 22, 24, 27, 56, 66, 76-83, 88, 89, 91, 93	"Selected Methods of the U.S. Geological Survey of Analysis of Wastewaters," by M.J. Fishman and Eugene Brown, U.S. Geological Survey Open File Report 76-77 (1976) \$13.50 Available from: U.S. Geological Survey, Branch Distribution, 1200 South Eads Street, Arlington, VA 22202.
ID-Other	1-8, 11-13, 15-24, 26, 28, 30-33, 35, 38-41, 43-54, 56-70	
IE-EPA	1-5	
IE-USGS	1-5	

The full texts of all the test procedures cited are available for inspection at the Office of the Federal Register Information Center, Room 8301, 1110 L Street, N.W., Washington, D.C. 20408.

7. In section 136.3 a new paragraph (e) is added together with a new Table II entitled, "Table II, Required Containers, Preservation Techniques, and Holding Times," to read as follows:

§ 136.3 Identification of test procedures.

(e) Sample preservation procedures, container materials, and maximum allowable holding times for parameters cited in Tables IA, IB, IC, ID, and IE are

prescribed in Table II. Any person may apply for a variance from the prescribed preservation techniques, container materials, and maximum holding times applicable to samples taken from a specific discharge. Applications for variances may be made by letters to the Regional Administrator in the Region in which the discharge will occur. Sufficient data should be provided to

assure such variance does not adversely affect the integrity of the sample. Such data will be forwarded by the Regional Administrator to the Director of the Environmental Monitoring and Support Laboratory in Cincinnati, Ohio for technical review and recommendations for action on the variance application. Upon receipt of the recommendations from the Director of the Environmental

Monitoring and Support Laboratory, the Regional Administrator may grant a variance applicable to the specific discharge to the applicant. A decision to approve or deny a variance will be made within 90 days of receipt of the application by the Regional Administrator.

TABLE II.—REQUIRED CONTAINERS, PRESERVATION TECHNIQUES, AND HOLDING TIMES

Parameter No./name	Container ¹	Preservation ^{2,3}	Maximum holding time ⁴
Table IA—Bacterial Tests:			
1-4. Coliform, fecal and total	P, G	Cool, 4°C, 0.008% Na ₂ S ₂ O ₅ ⁵	6 hours.
5. Fecal streptococci	P, G	do	Do.
Table IB—Inorganic Tests:			
1. Acidity	P, G	Cool, 4°C	14 days.
2. Alkalinity	P, G	do	Do.
4. Ammonia	P, G	Cool, 4°C, H ₂ SO ₄ to pH < 2	28 days.
9. Biochemical oxygen demand	P, G	Cool, 4°C	48 hours.
11. Bromide	P, G	None required	28 days.
14. Biochemical oxygen demand, carbonaceous	P, G	Cool, 4°C	48 hours.
15. Chemical oxygen demand	P, G	Cool, 4°C, H ₂ SO ₄ to pH < 2	28 days.
16. Chloride	P, G	None required	Do.
17. Chlorine, total residual	P, G	do	Analyze immediately.
21. Color	P, G	Cool, 4°C	48 hours.
23-24. Cyanide, total and amenable to chlorination	P, G	Cool, 4°C, NaOH to pH > 12, 0.6g ascorbic acid ⁶	14 days. ⁶
25. Fluoride	P	None required	28 days.
27. Hardness	P, G	HNO ₃ to pH < 2, H ₂ SO ₄ to pH < 2	6 months.
28. Hydrogen ion (pH)	P, G	None required	Analyze immediately.
31, 43. Kjeldahl and organic nitrogen	P, G	Cool, 4°C, H ₂ SO ₄ to pH < 2	28 days.
Metals⁷			
18. Chromium VI	P, G	Cool, 4°C	24 hours.
35. Mercury	P, G	HNO ₃ to pH < 2	28 days.
1, 5-8, 10, 12, 13, 19, 20, 22, 26, 29, 30, 32-34, 36, 37, 45, 47, 51, 52, 58-60, 62, 63, 70-72, 74, 75 Metals, except chromium VI and mercury	P, G	do	6 months.
38. Nitrate	P, G	Cool, 4°C	48 hours.
39. Nitrate-nitrite	P, G	Cool, 4°C, H ₂ SO ₄ to pH < 2	28 days.
40. Nitrite	P, G	Cool, 4°C	48 hours.
41. Oil and grease	G	Cool, 4°C, H ₂ SO ₄ to pH < 2	28 days.
42. Organic carbon	P, G	Cool, 4°C, HCl or H ₂ SO ₄ to pH < 2	Do.
44. Orthophosphate	P, G	Filter immediately. Cool, 4°C	48 hours.
45. Oxygen, Dissolved Probe	G Bottle and top	None required	Analyze immediately.
47. Winkler	do	Fix on site and store in dark	8 hours.
48. Phenols	G only	Cool, 4°C, H ₂ SO ₄ to pH < 2	28 days.
49. Phosphorus (elemental)	G	Cool, 4°C	48 hours.
50. Phosphorus, total	P, G	Cool, 4°C, H ₂ SO ₄ to pH < 2	28 days.
53. Residue, total	P, G	Cool, 4°C	7 days.
54. Residue, Filterable	P, G	do	48 hours.
55. Residue, Nonfilterable (TSS)	P, G	do	7 days.
56. Residue, Settleable	P, G	do	48 hours.
57. Residue, volatile	P, G	do	7 days.
61. Silica	P	do	28 days.
64. Specific conductance	P, G	do	Do.
65. Sulfate	P, G	do	Do.
66. Sulfide	P, G	Cool, 4°C add zinc acetate plus sodium hydroxide to pH > 9	7 days.
67. Sulfite	P, G	None required	Analyze immediately.
68. Surfactants	P, G	Cool, 4°C	48 hours.
69. Temperature	P, G	None required	Analyze.
73. Turbidity	P, G	Cool, 4°C	48 hours.
Table IC—Organic Tests ⁸			
13, 18-20, 22, 24-28, 34-37, 39-43, 45-47, 56, 66, 88, 89, 92-95, 97 Purgeable Halocarbons	G, Teflon-lined septum	Cool, 4°C, 0.008% Na ₂ S ₂ O ₅ ⁵	14 days
6, 57, 90. Purgeable aromatic hydrocarbons	do	Cool, 4°C, 0.008% Na ₂ S ₂ O ₅ ⁵ , HCl to pH 2 ⁹	Do.
1, 4. Acroten and acrylonitrile	do	Cool, 4°C, 0.008% Na ₂ S ₂ O ₅ ⁵ , Adjust pH to 4-5 ¹⁰	Do.
23, 30, 44, 49, 53, 67, 70, 71, 83, 85, 96. Phenols ¹¹	G, Teflon-lined cap	Cool, 4°C, 0.008% Na ₂ S ₂ O ₅ ⁵	7 days until extraction, 40 days after extraction.
7, 38. Benzidines ¹²	do	do	7 days until extraction.
14, 17, 48, 50-52. Phthalate esters ¹³	do	Cool, 4°C	7 days until extraction, 40 days after extraction.
72-74. Nitrosamines ¹⁴	do	Cool, 4°C store in dark, 0.008% Na ₂ S ₂ O ₅ ⁵	Do.
76-82. PCBs ¹⁵ acrylonitrile	do	Cool, 4°C	Do.
54, 55, 65, 69. Nitroaromatics and isophorone ¹⁶	do	Cool, 4°C, 0.008% Na ₂ S ₂ O ₅ ⁵ store in dark.	Do.
1, 2, 5, 8-12, 32, 33, 58, 59, 64, 68, 84, 86. Polynuclear aromatic hydrocarbons ¹⁷	do	do	Do.
15, 16, 21, 31, 75. Halothanes ¹⁸	do	Cool, 4°C, 0.008% Na ₂ S ₂ O ₅ ⁵	Do.
28, 35-37, 60-63, 91. Chlorinated hydrocarbons ¹⁹	do	Cool, 4°C	Do.
87. TCOD ²⁰	do	Cool, 4°C, 0.008% Na ₂ S ₂ O ₅ ⁵	Do.
Table ID—Pesticides Tests			
1-70. Pesticides ²¹	do	Cool, 4°C, pH 5-9 ²²	Do.
Table IE—Radiological Tests			
1-6. Alpha, beta and radium	P, G	HNO ₃ to pH < 2	6 months.

¹ Polyethylene (P) or Glass (G)

Table II Notes

* Sample preservation should be performed immediately upon sample collection. For composite chemical samples each aliquot should be preserved at the time of collection. When use of an automated sampler makes it impossible to preserve each aliquot, then chemical samples may be preserved by maintaining at 4°C until compositing and sample splitting is completed.

* When any sample is to be shipped by common carrier or sent through the United States Mails, it must comply with the Department of Transportation Hazardous Materials Regulations (49 CFR Part 172). The person offering such material for transportation is responsible for ensuring such compliance. For the preservation requirements of Table II, the Office of Hazardous Materials, Materials Transportation Bureau, Department of Transportation has determined that the Hazardous Materials Regulations do not apply to the following materials: Hydrochloric acid (HCl) in water solutions at concentrations of 0.04% by weight or less (pH about 1.96 or greater), Nitric acid (HNO₃) in water solutions at concentrations of 0.15% by weight or less (pH about 1.82 or greater), Sulfuric acid (H₂SO₄) in water solutions at concentrations of 0.35% by weight or less (pH about 1.15 or greater), and Sodium hydroxide (NaOH) in water solutions at concentrations of 0.080% by weight or less (pH about 12.30 or less).

* Samples should be analyzed as soon as possible after collection. The times listed are the maximum times that samples may be held before analysis and still be considered valid. Samples may be held for longer periods only if the permittee, or monitoring laboratory, has data on file to show that the specific types of samples under study are stable for the longer time, and has received a variance from the Regional Administrator under § 136.3(e). Some samples may not be stable for the maximum time period given in the table. A permittee, or monitoring laboratory, is obligated to hold the sample for a shorter time if knowledge exists to show that this is necessary to maintain sample stability. See § 136.3(e) for details.

* Should only be used in the presence of residual chlorine.

* Maximum holding time is 24 hours when sulfide is present. Optionally all samples may be tested with lead acetate paper before pH adjustments in order to determine if sulfide is present. If sulfide is present, it can be removed by the addition of cadmium nitrate powder until a negative spot test is obtained. The sample is filtered and then NaOH is added to pH 12.

* Samples should be filtered immediately on-site before adding preservative for dissolved metals.

* Quotient applies to samples to be analyzed by GC, LC, or GC/MS for specific compounds.

* Samples receiving no pH adjustment must be analyzed within seven days of sampling.

* The pH adjustment is not required if scotolun will not be measured. Samples for scotolun receiving no pH adjustment must be analyzed within 3 days of sampling.

* When the extractable analytes of concern fall within a single chemical category, the specified preservative and maximum holding times should be observed for optimum safeguard of sample integrity. When the analytes of concern fall within two or more chemical categories, the sample may be preserved by cooling to 4°C, reducing residual chlorine with 0.008% sodium thiosulfate, storing in the dark, and adjusting the pH to 6-8; samples preserved in this manner may be held for seven days before extraction and for forty days after extraction. Exceptions to the optional preservation and holding time procedure are noted in footnote 5 (re the requirement for thiosulfate reduction of residual chlorine), and footnotes 12, 13 (re the analysis of benzidine).

* If 1,2-diphenylhydrazine is likely to be present, adjust the pH of the sample to 4.0±0.2 to prevent rearrangement to benzidine.

* Extracts may be stored up to 7 days before analysis if storage is conducted under an inert (oxygen-free) atmosphere.

* For the analysis of diphenyltinamine, add 0.008% Na₂S₂O₅ and adjust pH to 7-10 with NaOH within 24 hours of sampling.

* The pH adjustment may be performed upon receipt at the laboratory and may be omitted if the samples are extracted within 72 hours of collection. For the analysis of aldrin, add 0.008% Na₂S₂O₅.

8. Appendices A, B, and C are added to Part 136 to read as follows:

APPENDIX A TO PART 136—METHODS FOR ORGANIC CHEMICAL ANALYSIS OF MUNICIPAL AND INDUSTRIAL WASTEWATER.

Method 601—Purgeable Halocarbons

1. Scope and Application

1.1 This method covers the determination of 29 purgeable halocarbons.

The following parameters may be determined by this method:

Parameter	STORET No.	CAS No.
Bromodichloromethane	32101	75-27-4
Bromotoluene	32104	75-25-2
Bromobenzene	34413	74-83-9
Carbon tetrachloride	32102	56-23-5
Chlorobenzene	34301	108-90-7
Chloroethane	34311	75-00-3
2-Chloroethyl vinyl ether	34578	100-75-8
Chloroform	32106	67-66-3
Chlorobenzene	34418	74-87-3
Dibromodichloromethane	32105	124-48-1
1,2-Dichlorobenzene	34536	95-50-1
1,3-Dichlorobenzene	34566	541-73-1
1,4-Dichlorobenzene	34571	106-46-7
Dichlorodifluoromethane	34868	75-71-8
1,1-Dichloroethane	34406	75-34-3
1,2-Dichloroethane	34531	107-06-2
1,1-Dichloroethane	34501	75-35-4
trans-1,2-Dichloroethane	34546	156-60-5
1,2-Dichloropropane	34541	78-87-5
cis-1,3-Dichloropropane	34704	10061-01-5
trans-1,3-Dichloropropane	34686	10061-02-6
Methylene chloride	34423	75-08-2
1,1,2,2-Tetrachloroethane	34516	78-34-5
Tetrachloroethane	34475	127-18-4
1,1,1-Trichloroethane	34506	71-55-6
1,1,2-Trichloroethane	34511	78-00-5
Tetrachloroethane	39180	78-01-6
Tetrachlorofluoromethane	34488	75-69-4
Vinyl chloride	36715	75-01-4

1.2 This is a purge and trap gas chromatographic (GC) method applicable to the determination of the compounds listed above in municipal and industrial discharges as provided under 40 CFR 136.1. When this method is used to analyze unfamiliar samples for any or all of the compounds above, compound identifications should be supported by at least one additional qualitative technique. This method describes analytical conditions for a second gas chromatographic column that can be used to confirm measurements made with the

primary column. Method 624 provides gas chromatograph/mass spectrometer (GC/MS) conditions appropriate for the qualitative and quantitative confirmation of results for most of the parameters listed above.

1.3 The method detection limit (MDL, defined in Section 12.1) for each parameter is listed in Table 1. The MDL for a specific wastewater may differ from those listed, depending upon the nature of interferences in the sample matrix.

1.4 Any modification of this method, beyond those expressly permitted, shall be considered as a major modification subject to application and approval of alternate test procedures under 40 CFR 136.4 and 136.5.

1.5 This method is restricted to use by or under the supervision of analysts experienced in the operation of a purge and trap system and a gas chromatograph and in the interpretation of gas chromatograms. Each analyst must demonstrate the ability to generate acceptable results with this method using the procedure described in Section 8.2.

2. Summary of Method

2.1 An inert gas is bubbled through a 5-mL water sample contained in a specially-designed purging chamber at ambient temperature. The halocarbons are efficiently transferred from the aqueous phase to the vapor phase. The vapor is swept through a sorbent trap where the halocarbons are trapped. After purging is completed, the trap is heated and backflushed with the inert gas to desorb the halocarbons onto a gas chromatographic column. The gas chromatograph is temperature programmed to separate the halocarbons which are then detected with a halide-specific detector.^{2,3}

2.2 The method provides an optional gas chromatographic column that may be helpful in resolving the compounds of interest from interferences that may occur.

3. Interferences

3.1 Impurities in the purge gas and organic compounds outgassing from the plumbing ahead of the trap account for the majority of contamination problems. The analytical system must be demonstrated to be free from contamination under the conditions of the analysis by running laboratory reagent blanks as described in Section 8.1.3. The use of non-Teflon plastic

tubing, non-Teflon thread sealants, or flow controllers with rubber components in the purge and trap system should be avoided.

3.2 Samples can be contaminated by diffusion of volatile organics (particularly fluorocarbons and methylene chloride) through the septum seal into the sample during shipment and storage. A field reagent blank prepared from reagent water and carried through the sampling and handling protocol can serve as a check on such contamination.

3.3 Contamination by carry-over can occur whenever high level and low level samples are sequentially analyzed. To reduce carry-over, the purging device and sample syringe must be rinsed with reagent water between sample analyses. Whenever an unusually concentrated sample is encountered, it should be followed by an analysis of reagent water to check for cross contamination. For samples containing large amounts of water-soluble materials, suspended solids, high boiling compounds or high organohalide levels, it may be necessary to wash out the purging device with a detergent solution, rinse it with distilled water, and then dry it in a 105°C oven between analyses. The trap and other parts of the system are also subject to contamination; therefore, frequent bakeout and purging of the entire system may be required.

4. Safety

4.1 The toxicity or carcinogenicity of each reagent used in this method has not been precisely defined; however, each chemical compound should be treated as a potential health hazard. From this viewpoint, exposure to these chemicals must be reduced to the lowest possible level by whatever means available. The laboratory is responsible for maintaining a current awareness file of OSHA regulations regarding the safe handling of the chemicals specified in this method. A reference file of material data handling sheets should also be made available to all personnel involved in the chemical analysis. Additional references to laboratory safety are available and have been identified ** for the information of the analyst.

4.2 The following parameters covered by this method have been tentatively classified as known or suspected, human or mammalian carcinogenic: carbon tetrachloride,

chloroform, 1,4-dichlorobenzene, and vinyl chloride. Primary standards of these toxic compounds should be prepared in a hood. A NIOSH/MESA approved toxic gas respirator should be worn when the analyst handles high concentrations of these toxic compounds.

5. Apparatus and Materials

5.1 Sampling equipment, for discrete sampling.

5.1.1 Vial—25-mL capacity or larger, equipped with a screw cap with a hole in the center (Pierce #13075 or equivalent). Detergent wash, rinse with tap and distilled water, and dry at 105 °C before use.

5.1.2 Septum—Teflon-faced silicone (Pierce #12722 or equivalent). Detergent wash, rinse with tap and distilled water, and dry at 105 °C for 1 h before use.

5.2 Purge and trap system—The purge and trap system consists of three separate pieces of equipment: a purging device, trap, and desorber. Several complete systems are now commercially available.

5.2.1 The purging device must be designed to accept 5-mL samples with a water column at least 3 cm deep. The gaseous head space between the water column and the trap must have a total volume of less than 15 mL. The purge gas must pass through the water column as finely divided bubbles with a diameter of less than 3 mm at the origin. The purge gas must be introduced no more than 5 mm from the base of the water column. The purging device illustrated in Figure 1 meets these design criteria.

5.2.2 The trap must be at least 25 cm long and have an inside diameter of at least 0.105 in. The trap must be packed to contain the following minimum lengths of adsorbents: 1.0 cm of methyl silicone coated packing (Section 6.3.3), 7.7 cm of 2,6-diphenylene oxide polymer (Section 6.3.2), 7.7 cm of silica gel (Section 6.3.4), 7.7 cm of coconut charcoal (Section 6.3.1). If it is not necessary to analyze for dichlorodifluoromethane, the charcoal can be eliminated, and the polymer section lengthened to 15 cm. The minimum specifications for the trap are illustrated in Figure 2.

5.2.3 The desorber must be capable of rapidly heating the trap to 180 °C. The polymer section of the trap should not be heated higher than 180 °C and the remaining sections should not exceed 200 °C. The desorber illustrated in Figure 2 meets these design criteria.

5.2.4 The purge and trap system may be assembled as a separate unit or be coupled to a gas chromatograph as illustrated in Figures 3 and 4.

5.3 Gas chromatograph—An analytical system complete with a temperature programmable gas chromatograph suitable for on-column injection and all required accessories including syringes, analytical columns, gases, detector, and strip-chart recorder. A data system is recommended for measuring peak areas.

5.3.1 Column 1—8 ft long x 0.1 in. ID, stainless steel or glass, packed with 1% SP-30 on Carbowax B (60/80 mesh) or

equivalent. This column was used to develop the method performance statements in Section 12. Guidelines for the use of alternate column packings are provided in Section 10.1.

5.3.2 Column 2—6 ft long x 0.1 in. ID, stainless steel or glass, packed with chemically bonded n-octane on Porasil-C (100/120 mesh) or equivalent.

5.3.3 Detector—Electrolytic conductivity or microcoulometric detector. These types of detectors have proven effective in the analysis of wastewaters for the parameters listed in the scope (Section 1.1). The electrolytic conductivity detector was used to develop the method performance statements in Section 12. Guidelines for the use of alternate detectors are provided in Section 10.1.

5.4 Syringes—5-mL glass hypodermic with Luerlok tip (two each), if applicable to the purging device.

5.5 Micro syringes—25-μL, 0.006 in. ID needle.

5.6 Syringe valve—2-way, with Luer ends (three each).

5.7 Syringe—5-mL, gas-tight with shut-off valve.

5.8 Bottle—15-mL, screw-cap, with Teflon cap liner.

5.9 Balance—Analytical, capable of accurately weighing 0.0001 g.

6. Reagents

6.1 Reagent water—Reagent water is defined as a water in which an interferent is not observed at the MDL of the parameters of interest.

6.1.1 Reagent water can be generated by passing tap water through a carbon filter bed containing about 1 lb of activated carbon (Filtrisorb-300, Calgon Corp., or equivalent).

6.1.2 A water purification system (Millipore Super-Q or equivalent) may be used to generate reagent water.

6.1.3 Reagent water may also be prepared by boiling water for 15 min. Subsequently, while maintaining the temperature at 90 °C, bubble a contaminant-free inert gas through the water for 1 h. While still hot, transfer the water to a narrow mouth screw-cap bottle and seal with a Teflon-lined septum and cap.

6.2 Sodium thiosulfate—(ACS) Granular.

6.3 Trap Materials:

6.3.1 Coconut charcoal—6/10 mesh sieved to 26 mesh, Barnebey Cheney, CA-580-26 lot # M-2649 or equivalent.

6.3.2 2,6-Diphenylene oxide polymer—Tenax, (60/80 mesh), chromatographic grade or equivalent.

6.3.3 Methyl silicone packing—3% OV-1 on Chromosorb-W (60/80 mesh) or equivalent.

6.3.4 Silica gel—35/60 mesh, Davison, grade-15 or equivalent.

6.4 Methanol—Pesticide quality or equivalent.

6.5 Stock standard solutions—Stock standard solutions may be prepared from pure standard materials or purchased as certified solutions. Prepare stock standard solutions in methanol using assayed liquids or gases as appropriate. Because of the toxicity of some of the organohalides, primary dilutions of these materials should be prepared in a hood. A NIOSH/MESA approved toxic gas respirator should be used

when the analyst handles high concentrations of such materials.

6.5.1 Place about 9.8 mL of methanol into a 10 mL ground glass stoppered volumetric flask. Allow the flask to stand, unstoppered, for about 10 min or until all alcohol wetted surfaces have dried. Weigh the flask to the nearest 0.1 mg.

6.5.2 Add the assayed reference material:

6.5.2.1 Liquid—Using a 100 μL syringe, immediately add two or more drops of assayed reference material to the flask, then reweigh. Be sure that the drops fall directly into the alcohol without contacting the neck of the flask.

6.5.2.2 Gases—To prepare standards for any of the six halocarbons that boil below 30 °C (bromomethane, chloroethane, chloromethane, dichlorodifluoromethane, trichlorofluoromethane, vinyl chloride), fill a 5-mL valved gas-tight syringe with the reference standard to the 5.0-mL mark. Lower the needle to 5 mm above the methanol meniscus. Slowly introduce the reference standard above the surface of the liquid (the heavy gas will rapidly dissolve into the methanol).

6.5.3 Reweigh, dilute to volume, stopper, then mix by inverting the flask several times. Calculate the concentration in μg/μL from the net gain in weight. When compound purity is assayed to be 98% or greater, the weight can be used without correction to calculate the concentration of the stock standard. Commercially prepared stock standards can be used at any concentration if they are certified by the manufacturer or by an independent source.

6.5.4 Transfer the stock standard solution into a Teflon-sealed screw-cap bottle. Store, with minimal headspace, at -10 to -20 °C and protect from light.

6.5.5 Prepare fresh standards weekly for the six gases and 2-chloroethylvinyl ether. All other standards must be replaced after one month, or sooner if comparison with check standards indicates a problem.

6.6 Secondary dilution standards—Using stock standard solutions, prepare secondary dilution standards in methanol that contain the compounds of interest, either singly or mixed together. The secondary dilution standards should be prepared at concentrations such that the aqueous calibration standards prepared in Sections 7.3.1 or 7.4.1 will bracket the working range of the analytical system. Secondary dilution standards should be stored with minimal headspace and should be checked frequently for signs of degradation or evaporation, especially just prior to preparing calibration standards from them.

6.7 Quality control check sample concentrate—See Section 8.2.1.

7. Calibration

7.1 Assemble a purge and trap system that meets the specifications in Section 5.2. Condition the trap overnight at 180 °C by backflushing with an inert gas flow of at least 20 mL/min. Condition the trap for 10 min once daily prior to use.

7.2 Connect the purge and trap system to a gas chromatograph. The gas chromatograph must be operated using temperature and flow

rate conditions equivalent to those given in Table 1. Calibrate the purge and trap-gas chromatographic system using either the external standard technique (Section 7.3) or the internal standard technique (Section 7.4).

7.3 External standard calibration procedure:

7.3.1 Prepare calibration standards at a minimum of three concentration levels for each parameter by carefully adding 20.0 μ L of one or more secondary dilution standards to 100, 500, or 1000 mL of reagent water. A 25- μ L syringe with a 0.006 in. ID needle should be used for this operation. One of the external standards should be at a concentration near, but above, the MDL (Table 1) and the other concentrations should correspond to the expected range of concentrations found in real samples or should define the working range of the detector. These aqueous standards can be stored up to 24 h, if held in sealed vials with zero headspace as described in Section 9.2. If not so stored, they must be discarded after 1 h.

7.3.2 Analyze each calibration standard according to Section 10, and tabulate peak height or area responses versus the concentration in the standard. The results can be used to prepare a calibration curve for each compound. Alternatively, if the ratio of response to concentration (calibration factor) is a constant over the working range (<10% relative standard deviation, RSD), linearity through the origin can be assumed and the average ratio or calibration factor can be used in place of a calibration curve.

7.4 Internal standard calibration procedure—To use this approach, the analyst must select one or more internal standards that are similar in analytical behavior to the compounds of interest. The analyst must further demonstrate that the measurement of the internal standard is not affected by method or matrix interferences. Because of these limitations, no internal standard can be suggested that is applicable to all samples. The compounds recommended for use as surrogate spikes in Section 8.7 have been used successfully as internal standards, because of their generally unique retention times.

7.4.1 Prepare calibration standards at a minimum of three concentration levels for each parameter of interest as described in Section 7.3.1.

7.4.2 Prepare a spiking solution containing each of the internal standards using the procedures described in Sections 6.5 and 6.8. It is recommended that the secondary dilution standard be prepared at a concentration of 15 μ g/mL of each internal standard compound. The addition of 10 μ L of this standard to 5.0 mL of sample or calibration standard would be equivalent to 30 μ g/L.

7.4.3 Analyze each calibration standard according to Section 10, adding 10 μ L of internal standard spiking solution directly to the syringe (Section 10.4). Tabulate peak height or area responses against concentration for each compound and internal standard, and calculate response factors (RF) for each compound using Equation 1.

Equation 1.

$$RF = \frac{(A_s)(C_u)}{(A_u)(C_s)}$$

where:

A_s = Response for the parameter to be measured.

A_u = Response for the internal standard.

C_u = Concentration of the internal standard.

C_s = Concentration of the parameter to be measured.

If the RF value over the working range is a constant (<10% RSD), the RF can be assumed to be invariant and the average RF can be used for calculations. Alternatively, the results can be used to plot a calibration curve of response ratios, A_s/A_u , vs. RF.

7.5 The working calibration curve, calibration factor, or RF must be verified on each working day by the measurement of a QC check sample.

7.5.1 Prepare the QC check sample as described in Section 8.2.2.

7.5.2 Analyze the QC check sample according to Section 10.

7.5.3 For each parameter, compare the response (Q) with the corresponding calibration acceptance criteria found in Table 2. If the responses for all parameters of interest fall within the designated ranges, analysis of actual samples can begin. If any individual Q falls outside the range, proceed according to Section 7.5.4.

Note: The large number of parameters in Table 2 present a substantial probability that one or more will not meet the calibration acceptance criteria when all parameters are analyzed.

7.5.4 Repeat the test only for those parameters that failed to meet the calibration acceptance criteria. If the response for a parameter does not fall within the range in this second test, a new calibration curve, calibration factor, or RF must be prepared for that parameter according to Section 7.3 or 7.4.

8. Quality Control

8.1 Each laboratory that uses this method is required to operate a formal quality control program. The minimum requirements of this program consist of an initial demonstration of laboratory capability and an ongoing analysis of spiked samples to evaluate and document data quality. The laboratory must maintain records to document the quality of data that is generated. Ongoing data quality checks are compared with established performance criteria to determine if the results of analyses meet the performance characteristics of the method. When results of sample spikes indicate atypical method performance, a quality control check standard must be analyzed to confirm that the measurements were performed in an in-control mode of operation.

8.1.1 The analyst must make an initial, one-time, demonstration of the ability to generate acceptable accuracy and precision with this method. This ability is established as described in Section 8.2.

8.1.2 In recognition of advances that are occurring in chromatography, the analyst is permitted certain options (detailed in Section 10.1) to improve the separations or lower the cost of measurements. Each time such a

modification is made to the method, the analyst is required to repeat the procedure in Section 8.2.

8.1.3 Each day, the analyst must analyze a reagent water blank to demonstrate that interferences from the analytical system are under control.

8.1.4 The laboratory must, on an ongoing basis, spike and analyze a minimum of 10% of all samples to monitor and evaluate laboratory data quality. This procedure is described in Section 8.3.

8.1.5 The laboratory must, on an ongoing basis, demonstrate through the analyses of quality control check standards that the operation of the measurement system is in control. This procedure is described in Section 8.4. The frequency of the check standard analyses is equivalent to 10% of all samples analyzed but may be reduced if spike recoveries from samples (Section 8.3) meet all specified quality control criteria.

8.1.6 The laboratory must maintain performance records to document the quality of data that is generated. This procedure is described in Section 8.5.

8.2 To establish the ability to generate acceptable accuracy and precision, the analyst must perform the following operations.

8.2.1 A quality control (QC) check sample concentrate is required containing each parameter of interest at a concentration of 10 μ g/mL in methanol. The QC check sample concentrate must be obtained from the U.S. Environmental Protection Agency, Environmental Monitoring and Support Laboratory in Cincinnati, Ohio, if available. If not available from that source, the QC check sample concentrate must be obtained from another external source. If not available from either source above, the QC check sample concentrate must be prepared by the laboratory using stock standards prepared independently from those used for calibration.

8.2.2 Prepare a QC check sample to contain 20 μ g/L of each parameter by adding 200 μ L of QC check sample concentrate to 100 mL of reagent water.

8.2.3 Analyze four 5-mL aliquots of the well-mixed QC check sample according to Section 10.

8.2.4 Calculate the average recovery (\bar{X}) in μ g/L, and the standard deviation of the recovery (s) in μ g/L, for each parameter of interest using the four results.

8.2.5 For each parameter compare s and \bar{X} with the corresponding acceptance criteria for precision and accuracy, respectively, found in Table 2. If s and \bar{X} for all parameters of interest meet the acceptance criteria, the system performance is acceptable and analysis of actual samples can begin. If any individual s exceeds the precision limit or any individual \bar{X} falls outside the range for accuracy, then the system performance is unacceptable for that parameter.

Note: The large number of parameters in Table 2 present a substantial probability that one or more will fail at least one of the acceptance criteria when all parameters are analyzed.

8.2.6 When one or more of the parameters tested fail at least one of the acceptance

criteria, the analyst must proceed according to Section 8.2.6.1 or 8.2.6.2.

8.2.6.1 Locate and correct the source of the problem and repeat the test for all parameters of interest beginning with Section 8.2.3.

8.2.6.2 Beginning with Section 8.2.3, repeat the test only for those parameters that failed to meet criteria. Repeated failure, however, will confirm a general problem with the measurement system. If this occurs, locate and correct the source of the problem and repeat the test for all compounds of interest beginning with Section 8.2.3.

8.3 The laboratory must, on an ongoing basis, spike at least 10% of the samples from each sample site being monitored to assess accuracy. For laboratories analyzing one to ten samples per month, at least one spiked sample per month is required.

8.3.1 The concentration of the spike in the sample should be determined as follows:

8.3.1.1 If, as in compliance monitoring, the concentration of a specific parameter in the sample is being checked against a regulatory concentration limit, the spike should be at that limit or 1 to 5 times higher than the background concentration determined in Section 8.3.2, whichever concentration would be larger.

8.3.1.2 If the concentration of a specific parameter in the sample is not being checked against a limit specific to that parameter, the spike should be at 20 µg/L or 1 to 5 times higher than the background concentration determined in Section 8.3.2, whichever concentration would be larger.

8.3.2 Analyze one 5-mL sample aliquot to determine the background concentration (B) of each parameter. If necessary, prepare a new QC check sample concentrate (Section 8.2.1) appropriate for the background concentrations in the sample. Spike a second 5-mL sample aliquot with 10 µL of the QC check sample concentrate and analyze it to determine the concentration after spiking (A) of each parameter. Calculate each percent recovery (P) as $100(A-B)/T$, where T is the known true value of the spike.

8.3.3 Compare the percent recovery (P) for each parameter with the corresponding QC acceptance criteria found in Table 2. These acceptance criteria were calculated to include an allowance for error in measurement of both the background and spike concentrations, assuming a spike to background ratio of 5:1. This error will be accounted for to the extent that the analyst's spike to background ratio approaches 5:1.¹ If spiking was performed at a concentration lower than 20 µg/L, the analyst must use either the QC acceptance criteria in Table 2, or optional QC acceptance criteria calculated for the specific spike concentration. To calculate optional acceptance criteria for the recovery of a parameter: (1) Calculate accuracy (X') using the equation in Table 3, substituting the spike concentration (T) for C; (2) calculate overall precision (S') using the equation in Table 3, substituting X' for X; (3) calculate the range for recovery at the spike concentration as $100 X' / T \pm 2.44(100 S' / T)\%$.

8.3.4 If any individual P falls outside the designated range for recovery, that parameter has failed the acceptance criteria. A check

standard containing each parameter that failed the criteria must be analyzed as described in Section 8.4.

8.4 If any parameter fails the acceptance criteria for recovery in Section 8.3, a QC check standard containing each parameter that failed must be prepared and analyzed.

Note: The frequency for the required analysis of a QC check standard will depend upon the number of parameters being simultaneously tested, the complexity of the sample matrix, and the performance of the laboratory. If the entire list of parameters in Table 2 must be measured in the sample in Section 8.3, the probability that the analysis of a QC check standard will be required is high. In this case the QC check standard should be routinely analyzed with the spiked sample.

8.4.1 Prepare the QC check standard by adding 10 µL of QC check sample concentrate (Sections 8.2.1 or 8.3.2) to 5 mL of reagent water. The QC check standard needs only to contain the parameters that failed criteria in the test in Section 8.3.

8.4.2 Analyze the QC check standard to determine the concentration measured (A) of each parameter. Calculate each percent recovery (P) as $100(A/T)\%$, where T is the true value of the standard concentration.

8.4.3 Compare the percent recovery (P) for each parameter with the corresponding QC acceptance criteria found in Table 2. Only parameters that failed the test in Section 8.3 need to be compared with these criteria. If the recovery of any such parameter falls outside the designated range, the laboratory performance for that parameter is judged to be out of control, and the problem must be immediately identified and corrected. The analytical result for that parameter in the unspiked sample is suspect and may not be reported for regulatory compliance purposes.

8.5 As part of the QC program for the laboratory, method accuracy for wastewater samples must be assessed and records must be maintained. After the analysis of five spiked wastewater samples as in Section 8.3, calculate the average percent recovery (\bar{P}) and the standard deviation of the percent recovery (s_p). Express the accuracy assessment as a percent recovery interval from $\bar{P} - 2s_p$ to $\bar{P} + 2s_p$. If $\bar{P} = 90\%$ and $s_p = 10\%$, for example, the accuracy interval is expressed as 70–110%. Update the accuracy assessment for each parameter on a regular basis (e.g. after each five to ten new accuracy measurements).

8.6 It is recommended that the laboratory adopt additional quality assurance practices for use with this method. The specific practices that are most productive depend upon the needs of the laboratory and the nature of the samples. Field duplicates may be analyzed to assess the precision of the environmental measurements. When doubt exists over the identification of a peak on the chromatogram, confirmatory techniques such as gas chromatography with a dissimilar column, specific element detector, or mass spectrometer must be used. Whenever possible, the laboratory should analyze standard reference materials and participate in relevant performance evaluation studies.

8.7 The analyst should monitor both the performance of the analytical system and the

effectiveness of the method in dealing with each sample matrix by spiking each sample, standard, and reagent water blank with surrogate halocarbons. A combination of bromochloromethane, 2-bromo-1-chloropropane, and 1,4-dichlorobutane is recommended to encompass the range of the temperature program used in this method. From stock standard solutions prepared as in Section 8.5, add a volume to give 750 µg of each surrogate to 45 mL of reagent water contained in a 50-mL volumetric flask, mix and dilute to volume for a concentration of 15 ng/µL. Add 10 µL of this surrogate spiking solution directly into the 5-mL syringe with every sample and reference standard analyzed. Prepare a fresh surrogate spiking solution on a weekly basis. If the internal standard calibration procedure is being used, the surrogate compounds may be added directly to the internal standard spiking solution (Section 7.4.2).

9. Sample Collection, Preservation, and Handling

9.1 All samples must be iced or refrigerated from the time of collection until analysis. If the sample contains free or combined chlorine, add sodium thiosulfate preservative (10 mg/40 mL is sufficient for up to 5 ppm Cl₂) to the empty sample bottle just prior to shipping to the sampling site. EPA Methods 330.4 and 330.5 may be used for measurement of residual chlorine.² Field test kits are available for this purpose.

9.2 Grab samples must be collected in glass containers having a total volume of at least 25 mL. Fill the sample bottle just to overflowing in such a manner that no air bubbles pass through the sample as the bottle is being filled. Seal the bottle so that no air bubbles are entrapped in it. If preservative has been added, shake vigorously for 1 min. Maintain the hermetic seal on the sample bottle until time of analysis.

9.3 All samples must be analyzed within 14 days of collection.³

10. Procedure

10.1 Table 1 summarizes the recommended operating conditions for the gas chromatograph. Included in this table are estimated retention times and MDL that can be achieved under these conditions. An example of the separations achieved by Column 1 is shown in Figure 5. Other packed columns, chromatographic conditions, or detectors may be used if the requirements of Section 8.2 are met.

10.2 Calibrate the system daily as described in Section 7.

10.3 Adjust the purge gas (nitrogen or helium) flow rate to 40 mL/min. Attach the trap inlet to the purging device, and set the purge and trap system to purge (Figure 3). Open the syringe valve located on the purging device sample introduction needle.

10.4 Allow the sample to come to ambient temperature prior to introducing it to the syringe. Remove the plunger from a 5-mL syringe and attach a closed syringe valve. Open the sample bottle (or standard) and carefully pour the sample into the syringe barrel to just short of overflowing. Replace the syringe plunger and compress the sample. Open the syringe valve and vent any residual

air while adjusting the sample volume to 5.0 mL. Since this process of taking an aliquot destroys the validity of the sample for future analysis, the analyst should fill a second syringe at this time to protect against possible loss of data. Add 10.0 µL of the surrogate spiking solution (Section 8.7) and 10.0 µL of the internal standard spiking solution (Section 7.4.2), if applicable, through the valve bore, then close the valve.

10.5 Attach the syringe-syringe valve assembly to the syringe valve on the purging device. Open the syringe valves and inject the sample into the purging chamber.

10.6 Close both valves and purge the sample for 11.0 ± 0.1 min at ambient temperature.

10.7 After the 11-min purge time, attach the trap to the chromatograph, adjust the purge and trap system to the desorb mode (Figure 4), and begin to temperature program the gas chromatograph. Introduce the trapped materials to the GC column by rapidly heating the trap to 180 °C while backflushing the trap with an inert gas between 20 and 60 mL/min for 4 min. If rapid heating of the trap cannot be achieved, the GC column must be used as a secondary trap by cooling it to 30 °C (subambient temperature, if poor peak geometry or random retention time problems persist) instead of the initial program temperature of 45 °C.

10.8 While the trap is being desorbed into the gas chromatograph, empty the purging chamber using the sample introduction syringe. Wash the chamber with two 5-mL flushes of reagent water.

10.9 After desorbing the sample for 4 min, condition the trap by returning the purge trap system to the purge mode. Wait 15 s then close the syringe valve on the purging device to begin gas flow through the trap. The trap temperature should be maintained at 180 °C. After approximately 7 min, turn off the trap heater and open the syringe valve to stop the gas flow through the trap. When the trap is cool, the next sample can be analyzed.

10.10 Identify the parameters in the sample by comparing the retention times of the peaks in the sample chromatogram with those of the peaks in standard chromatograms. The width of the retention time window used to make identifications should be based upon measurements of actual retention time variations of standards over the course of a day. Three times the standard deviation of a retention time for a compound can be used to calculate a suggested window size; however, the experience of the analyst should weigh heavily in the interpretation of chromatograms.

10.11 If the response for a peak exceeds the working range of the system, prepare a dilution of the sample with reagent water from the aliquot in the second syringe and reanalyze.

11. Calculations

11.1 Determine the concentration of individual compounds in the sample.

11.1.1 If the external standard calibration procedure is used, calculate the concentration of the parameter being measured from the peak response using the calibration curve or calibration factor determined in Section 7.3.2.

11.1.2 If the internal standard calibration procedure is used, calculate the concentration in the sample using the response factor (RF) determined in Section 7.4.3 and Equation 2

Equation 2.

$$\text{Concentration } (\mu\text{g/L}) = \frac{(A_s)(C_u)}{(A_u)(\text{RF})}$$

where:

A_s = Response for the parameter to be measured.

A_u = Response for the internal standard.

C_u = Concentration of the internal standard.

11.2 Report results in µg/L without correction for recovery data. All QC data obtained should be reported with the sample results.

12. Method Performance

12.1 The method detection limit (MDL) is defined as the minimum concentration of a substance that can be measured and reported with 99% confidence that the value is above zero.¹ The MDL concentrations listed in Table 1 were obtained using reagent water.² Similar results were achieved using representative wastewaters. The MDL actually achieved in a given analysis will vary depending on instrument sensitivity and matrix effects.

12.2 This method is recommended for use in the concentration range from the MDL to 1000 × MDL. Direct aqueous injection techniques should be used to measure concentration levels above 1000 × MDL.

12.3 This method was tested by 20 laboratories using reagent water, drinking water, surface water, and three industrial wastewaters spiked at six concentrations over the range 8.0 to 500 µg/L.³ Single

operator precision, overall precision, and method accuracy were found to be directly related to the concentration of the parameter and essentially independent of the sample matrix. Linear equations to describe these relationships are presented in Table 3.

References

1. 40 CFR Part 136, Appendix B.
2. Bellar, T.A., and Lichtenberg, J.J. "Determining Volatile Organics at Microgram-per-Litre Levels by Gas Chromatography." *Journal of the American Water Works Association*, 66, 739 (1974).
3. Bellar, T.A., and Lichtenberg, J.J. "Semi-Automated Headspace Analysis of Drinking Waters and Industrial Waters for Purgeable Volatile Organic Compounds." *Proceedings from Symposium on Measurement of Organic Pollutants in Water and Wastewater*, American Society for Testing and Materials, STP 686, C.E. Van Hall, editor, 1978.
4. "Carcinogens—Working With Carcinogens." Department of Health, Education, and Welfare, Public Health Service, Center for Disease Control, National Institute for Occupational Safety and Health, Publication No. 77-206, August 1977.
5. "OSHA Safety and Health Standards, General Industry" (29 CFR 1910), Occupational Safety and Health Administration, OSHA 2206 (Revised, January 1976).
6. "Safety in Academic Chemistry Laboratories." American Chemical Society Publication, Committee on Chemical Safety, 3rd Edition, 1979.
7. Provost, L.P., and Elder, R.S. "Interpretation of Percent Recovery Data," *American Laboratory*, 15, 58-63 (1983). (The value 2.44 used in the equation in Section 8.3.3 is two times the value 1.22 derived in this report.)
8. "Methods 330.4 (Titrimetric, DPD-FAS) and 330.5 (Spectrophotometric, DPD) for Chlorine, Total Residual." *Methods for Chemical Analysis of Water and Wastes*, EPA 600/4-79-020, U.S. Environmental Protection Agency, Environmental Monitoring and Support Laboratory, Cincinnati, Ohio 45268, March 1979.
9. "EPA Method Validation Study 23, Method 601 (Purgeable Halocarbons)." Report for EPA Contract 68-03-2856 (in preparation).
10. "Method Validation Data for EPA Method 601." Memorandum from B. Potter, U.S. Environmental Protection Agency, Environmental Monitoring and Support Laboratory, Cincinnati, Ohio 45268, November 10, 1983.

TABLE 1.—CHROMATOGRAPHIC CONDITIONS AND METHOD DETECTION LIMITS

Parameter	Retention time (min)		Method detection limit (µg/L)
	Column 1	Column 2	
Chloromethane	1.50	5.28	0.08
Bromomethane	2.17	7.05	1.18
Dichlorodifluoromethane	2.62	nd	1.81
Vinyl chloride	2.67	5.28	0.18
Chloroethane	3.33	8.68	0.52
Ethylene chloride	5.25	10.1	0.25
Tetrachloromethane	7.18	nd	nd
1,1-Dichloroethane	7.93	7.72	0.13
1,2-Dichloroethane	9.30	12.6	0.07
trans-1,2-Dichloroethane	10.1	9.38	0.10

TABLE 1.—CHROMATOGRAPHIC CONDITIONS AND METHOD DETECTION LIMITS—Continued

Parameter	Retention time (min)		Method detection limit (µg/L)
	Column 1	Column 2	
Chloroform	10.7	12.1	0.05
1,2-Dichloroethane	11.4	15.4	0.03
1,1,1-Trichloroethane	12.6	13.1	0.03
Carbon tetrachloride	13.0	14.4	0.12
Bromodichloromethane	13.7	14.8	0.10
1,2-Dichloropropane	14.9	16.6	0.04
cis-1,3-Dichloropropene	15.2	16.6	0.34
Trichloroethene	15.8	13.1	0.12
Dibromochloromethane	16.5	16.6	0.06
1,1,2-Trichloroethane	16.5	18.1	0.02
trans-1,3-Dichloropropene	16.5	18.0	0.20
2-Chlorostyrene	16.0	nd	0.13
Bromoform	19.2	19.2	0.20
1,1,2,2-Tetrachloroethane	21.6	nd	0.03
Tetrachloroethene	21.7	15.0	0.03
Chlorobenzene	24.2	18.8	0.25
1,3-Dichlorobenzene	34.0	22.4	0.32
1,2-Dichlorobenzene	34.8	23.5	0.15
1,4-Dichlorobenzene	35.4	22.3	0.24

Column 1 conditions: Carbowax B (80/80 mesh) coated with 1% SP-1000 packed in an 8 ft x 0.1 in. ID stainless steel or glass column with helium carrier gas at 40 mL/min flow rate. Column temperature held at 45 °C for 3 min then programmed at 6 °C/min to 220 °C and held for 15 min.
 Column 2 conditions: Porapak Q (100/120 mesh) coated with n-octane packed in a 6 ft x 0.1 in. ID stainless steel or glass column with helium carrier gas at 40 mL/min flow rate. Column temperature held at 50 °C for 3 min then programmed at 6 °C/min to 170 °C and held for 4 min.
 nd = not determined.

TABLE 2.—CALIBRATION AND QC ACCEPTANCE CRITERIA—METHOD 601*

Parameter	Range for Q (µg/L)	Limit for s (µg/L)	Range for \bar{x} (µg/L)	Range P ₁ (%)
Bromodichloromethane	15.2-24.8	4.3	10.7-32.0	42-172
Bromoform	14.7-25.3	4.7	5.0-29.3	13-158
Bromomethane	11.7-28.3	7.6	3.4-24.5	D-144
Carbon tetrachloride	13.7-26.3	5.6	11.8-25.3	43-143
Chlorobenzene	14.4-25.6	5.0	10.2-27.4	38-150
Chloroethane	15.4-24.6	4.4	11.3-25.2	46-137
2-Chlorostyrene	12.0-28.0	8.3	4.5-35.5	14-186
Chloroform	15.0-25.0	4.5	12.4-24.0	49-133
Chloromethane	11.9-28.1	7.4	D-34.9	D-193
Dibromochloromethane	13.1-26.9	6.3	7.9-35.1	24-191
1,2-Dichlorobenzene	14.0-26.0	5.5	1.7-38.9	D-208
1,3-Dichlorobenzene	9.9-30.1	9.1	6.2-32.6	7-187
1,4-Dichlorobenzene	13.9-26.1	5.5	11.5-25.5	42-143
1,1-Dichloroethane	16.8-23.2	3.2	11.2-24.6	47-132
1,2-Dichloroethane	14.3-25.7	5.2	13.0-26.5	51-147
1,1-Dichloroethene	12.6-27.4	6.6	10.2-27.3	28-167
trans-1,2-Dichloroethane	12.8-27.2	6.4	11.4-27.1	38-155
1,2-Dichloropropene	14.8-25.2	5.2	10.1-29.9	44-156
cis-1,3-Dichloropropene	12.8-27.2	7.3	6.2-33.8	22-178
trans-1,3-Dichloropropene	12.8-27.2	7.3	6.2-33.8	22-178
Methylene chloride	15.5-24.5	4.0	7.0-27.8	25-162
1,1,2,2-Tetrachloroethane	9.8-30.2	9.2	6.6-31.8	8-184
Tetrachloroethene	14.0-26.0	5.4	8.1-29.6	26-162
1,1,1-Trichloroethane	14.2-25.8	4.9	10.8-24.8	41-138
1,1,2-Trichloroethane	15.7-24.3	3.9	9.6-25.4	39-138
Trichloroethene	15.4-24.6	4.2	9.2-26.6	35-146
Trichlorofluoromethane	13.3-26.7	6.0	7.4-28.1	21-156
Vinyl chloride	13.7-26.3	5.7	8.2-29.9	28-163

Q = Concentration measured in QC check sample, in µg/L (Section 7.5.3).

s = Standard deviation of four recovery measurements, in µg/L (Section 8.2.4).

\bar{x} = Average recovery for four recovery measurements, in µg/L (Section 8.2.4).

P, P₁ = Percent recovery measured (Section 8.3.2, Section 8.4.2).

D = Detected; result must be greater than zero.

* Criteria were calculated assuming a QC check sample concentration of 20 µg/L.

Note: These criteria are based directly upon the method performance data in Table

3. Where necessary, the limits for recovery have been broadened to assure applicability

of the limits to concentrations below those used to develop Table 3.

TABLE 3.—METHOD ACCURACY AND PRECISION AS FUNCTIONS OF CONCENTRATION—METHOD 601

Parameter	Accuracy, as recovery, \bar{x} (%) (µg/L)	Single analyst precision, s (%) (µg/L)	Overall precision, \bar{s} (%) (µg/L)
Bromodichloromethane	1.12C - 1.02	0.11 \bar{x} + 0.04	0.20 \bar{x} + 1.00
Bromoform	0.96C - 2.05	0.12 \bar{x} + 0.58	0.21 \bar{x} + 2.41
Bromomethane	0.78C - 1.27	0.26 \bar{x} + 0.27	0.36 \bar{x} + 0.84
Carbon tetrachloride	0.96C - 1.04	0.15 \bar{x} + 0.38	0.20 \bar{x} + 0.38
Chlorobenzene	1.00C - 1.23	0.15 \bar{x} - 0.02	0.18 \bar{x} + 1.21
Chloroethane	0.99C - 1.53	0.14 \bar{x} - 0.13	0.17 \bar{x} + 0.83
2-Chlorostyrene	1.00C	0.20 \bar{x}	0.35 \bar{x}
Chloroform	0.93C - 0.39	0.13 \bar{x} + 0.15	0.19 \bar{x} - 0.02
Chloromethane	0.77C - 0.18	0.28 \bar{x} - 0.31	0.52 \bar{x} + 1.31
Dibromochloromethane	0.94C - 2.72	0.11 \bar{x} + 1.10	0.24 \bar{x} + 1.68
1,2-Dichlorobenzene	0.93C - 1.70	0.20 \bar{x} - 0.97	0.13 \bar{x} + 6.13

TABLE 3.—METHOD ACCURACY AND PRECISION AS FUNCTIONS OF CONCENTRATION—METHOD 601—Continued

Parameter	Accuracy, as recovery, \bar{X} ($\mu\text{g/L}$)	Single analyst precision, s_x ($\mu\text{g/L}$)	Overall precision, S ($\mu\text{g/L}$)
1,3-Dichlorobenzene	0.94C ± 0.43	0.14X ± 2.33	0.26X ± 2.34
1,4-Dichlorobenzene	0.93C ± 0.08	0.15X ± 0.24	0.20X ± 0.41
1,1-Dichloroethene	0.95C ± 1.08	0.08X ± 0.17	0.14X ± 0.94
1,2-Dichloroethene	1.04C ± 1.08	0.11X ± 0.70	0.15X ± 0.84
1,1-Dichloroethane	0.98C ± 0.87	0.21X ± 0.23	0.29X ± 0.40
trans-1,2-Dichloroethene	0.97C ± 0.18	0.11X ± 1.48	0.17X ± 1.48
1,2-Dichloropropane*	1.00C	0.13X	0.23X
cis-1,3-Dichloropropene*	1.00C	0.18X	0.32X
trans-1,3-Dichloropropene*	1.00C	0.18X	0.32X
Methylene chloride	0.91C ± 0.83	0.11X ± 0.33	0.21X ± 1.43
1,1,2,2-Tetrachloroethene	0.95C ± 0.19	0.14X ± 2.41	0.23X ± 2.78
Tetrachloroethene	0.94C ± 0.08	0.14X ± 0.38	0.18X ± 2.21
1,1,1-Trichloroethene	0.90C ± 0.18	0.15X ± 0.04	0.20X ± 0.37
1,1,2-Trichloroethene	0.86C ± 0.20	0.13X ± 0.14	0.19X ± 0.87
Trichloroethene	0.87C ± 0.48	0.13X ± 0.03	0.23X ± 0.30
Trichlorofluoromethane	0.89C ± 0.07	0.15X ± 0.67	0.26X ± 0.81
Vinyl chloride	0.97C ± 0.36	0.13X ± 0.65	0.27X ± 0.40

\bar{X} = Expected recovery for one or more measurements of a sample containing a concentration of C, in $\mu\text{g/L}$.

s_x = Expected single analyst standard deviation of measurements at an average concentration found of \bar{X} , in $\mu\text{g/L}$.

S = Expected interlaboratory standard deviation of measurements at an average concentration found of \bar{X} , in $\mu\text{g/L}$.

C = True value for the concentration, in $\mu\text{g/L}$.

\bar{X} = Average recovery found for measurements of samples containing a concentration of C, in $\mu\text{g/L}$.

* Estimates based upon the performance in a single laboratory.¹⁰

BILLING CODE 6580-50-M